

MITSUBISHI

Mitsubishi Safety Programmable Logic Controller

MELSEC **QS** series

QSCPU

User's Manual
(Function Explanation, Program Fundamentals)



QS001CPU

● SAFETY PRECAUTIONS ●

(Always read these instructions before using this equipment.)

Before using this product, please read this manual, the relevant manuals introduced in this manual, standard PLC manuals, and the safety standards carefully and pay full attention to safety to handle the product correctly.


In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Note that the  CAUTION level may lead to a serious consequence according to the circumstances. Always follow the instructions of both levels because they are important to personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

[Design Precautions]

DANGER

- When a safety PLC detects an error in an external power supply or a failure in PLC main module, it turns off all the outputs.
Create an external circuit to securely stop the power of hazard by turning off the outputs. Incorrect configuration may result in an accident.
- Create short current protection for a safety relay, and a protection circuit such as a fuse, and breaker, outside a safety PLC.
- When data/program change, or status control is performed from a PC to a running safety PLC, create an interlock circuit outside the sequence program and safety PLC to ensure that the whole system always operates safely.
For the operations to a safety PLC, pay full attention to safety by reading the relevant manuals carefully, and establishing the operating procedure.
Furthermore, for the online operations performed from a PC to a safety CPU module, the corrective actions against a communication error due to a cable connection fault, etc. should be predetermined as a system.
- All output signals from a safety CPU module to the CC-Link Safety system master module are prohibited to use.
These signals can be found in the CC-Link Safety System Master Module User's Manual.
Do not turn ON or OFF these signals by sequence program, since turning ON/OFF these output signals of the PLC system may cause malfunctions and safety operation cannot be guaranteed.
- When a safety remote I/O module has detected a CC-Link Safety error, it turns off all the outputs.
Note that the outputs in a sequence program are not automatically turned off.
If a CC-Link Safety error has been detected, create a sequence program that turns off the outputs in the program.
If the CC-Link Safety is restored with the outputs on, it may suddenly operate and result in an accident.
- To inhibit restart without manual operation after safety functions was performed and outputs were turned OFF, create an interlock program which uses a reset button for restart.

CAUTION

- Do not bunch the wires of external devices or communication cables together with the main circuit or power lines, or install them close to each other. They should be installed 100 mm (3.94 inch) or more from each other. Not doing so could result in noise that would cause erroneous operation.

[Installation Precautions]



CAUTION

- Use a safety PLC in the environment that meets the general specifications described in this manual. Using this PLC in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- While pressing the installation lever located at the bottom of module, insert the module fixing tab into the fixing hole in the base unit until it stops. Then, securely mount the module with the fixing hole as a supporting point.
Incorrect loading of the module can cause a failure or drop.
Secure the module to the base unit with screws.
Tighten the screw in the specified torque range.
If the screws are too loose, it may cause a drop of the screw or module.
Over tightening may cause a drop due to the damage of the screw or module.
- Completely turn off the externally supplied power used in the system before mounting or removing the module.
Not doing so could result in damage to the product.
- Do not directly touch the module's conductive parts or electronic components.
Doing so may cause malfunctions or a failure.

[Wiring Precautions]



DANGER

- Be sure to shut off all phases of the external supply power used by the system before wiring.
Not completely turning off all power could result in electric shock or damage to the product.
- When energizing or operating the module after installation or wiring, be sure to close the attached terminal cover.
Not doing so may result in electric shock.

[Wiring Precautions]

CAUTION

- Be sure to ground the FG terminals and LG terminals to the protective ground conductor.
Not doing so could result in electric shock or erroneous operation.
- Use a solderless terminal with insulation sleeve for wiring of a terminal block.
Use up to two solderless terminals for a single terminal.
- Use applicable solderless terminals and tighten them with the specified torque.
If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Wire the module correctly after confirming the rated voltage and terminal layout.
Connecting a power supply of a different rated voltage or incorrect wiring may cause a fire or failure.
- Tighten a terminal block mounting screw, terminal screw, and module mounting screw within the specified torque range.
If the terminal block mounting screw or terminal screw is too loose, it may cause a short circuit, fire, or malfunctions.
If too tight, it may damage the screw and/or the module, resulting in a drop of the screw or module, a short circuit or malfunctions.
If the module mounting screw is too loose, it may cause a drop of the screw or module.
Over tightening the screw may cause a drop due to the damage of the screw or module.
- Be sure there are no foreign substances such as sawdust or wiring debris inside the module.
Such debris could cause a fire, failure, or erroneous operation.
- The module has an ingress prevention label on its top to prevent foreign matter, such as wire offcuts, from entering the module during wiring.
Do not peel this label during wiring. Before starting system operation, be sure to peel this label because of heat dissipation.
- Install our PLC in a control panel for use.
Wire the main power supply to the power supply module installed in a control panel through a distribution terminal block.
Furthermore, the wiring and replacement of a power supply module have to be performed by a maintenance worker who acquainted with shock protection.
(For the wiring methods, refer to the QSCPU User's Manual (Hardware Design, Maintenance and Inspection))

[Startup and Maintenance precautions]



DANGER

- Do not touch the terminals while power is on.
Doing so could cause shock or erroneous operation.
- Correctly connect the battery. Also, do not charge, disassemble, heat, place in fire, short circuit, or solder the battery.
Mishandling of battery can cause overheating or cracks which could result in injury and fires.
- Turn off all phases of the external supply power used in the system when cleaning the module or retightening the terminal block mounting screws, terminal screws, or module mounting screws.
Not doing so could result in electric shock. Tighten a terminal block mounting screw, terminal screw, and module mounting screw within the specified torque range.
If the terminal block mounting screw or terminal screw is too loose, it may cause a short circuit, fire, or malfunctions.
If too tight, it may damage the screw and/or the module, resulting in a drop of the screw or module, a short circuit or malfunctions.
If the module mounting screw is too loose, it may cause a drop of the screw or module.
Over tightening the screw may cause a drop due to the damage of the screw or module.

[Startup and Maintenance precautions]

CAUTION

- The online operations performed from a PC to a running safety PLC (Program change when a safety CPU is RUN, device test, and operating status change such as RUN-STOP switching) have to be executed after the manual has been carefully read and the safety has been ensured.
Following the operating procedure predetermined at designing, the operation has to be performed by an instructed person.
When changing a program while a safety CPU is RUN (Write during RUN), it may cause a program breakdown in some operating conditions.
Fully understand the precautions described in the GX Developer's manual before use.
- Do not disassemble or modify the modules.
Doing so could cause a failure, erroneous operation, injury, or fire.
If the product is repaired or remodeled by other than the specified FA centers or us, the warranty is not covered.
- Use any radio communication device such as a cellular phone or a PHS phone more than 25cm(9.85 inch) away in all directions of the PLC.
Not doing so can cause a malfunction.
- Completely turn off the externally supplied power used in the system before mounting or removing the module.
Not doing so could result in damage to the product.
- Restrict the mounting/removal of a module, base unit, and terminal block up to 50 times (IEC61131-2-compliant), after the first use of the product.
Failure to do so may cause the module to malfunction due to poor contact of connector.
- Do not drop or give an impact to the battery mounted to the module.
Doing so may damage the battery, causing the battery fluid to leak inside the battery.
If the battery is dropped or given an impact, dispose of it without using.
- Before touching the module, always touch grounded metal, etc. to discharge static electricity from human body, etc.
Not doing so can cause the module to fail or malfunction

[Disposal Precautions]



CAUTION

- When disposing of this product, treat it as industrial waste.

[Transportation Precautions]



CAUTION

- When transporting lithium batteries, make sure to treat them based on the transport regulations.
(For details of the controlled models, refer to Appendix 5.)

REVISIONS

The manual number is given on the bottom left of the back cover.

Print Date	Manual Number	Revision
Sep., 2006	SH(NA)-080627ENG-A	First edition
Jun.,2007	SH(NA)-080627ENG-B	<div>Partial correction</div> Section 3.7.1, 3.7.2, 3.7.3, 4.2.2, 5.3.3, 6.10, 9.1, 9.2, 9.2.4, 9.2.8, 9.5

Japanese Manual Version SH-080608-B

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2004 MITSUBISHI ELECTRIC CORPORATION

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-QS Series of Safety Programmable Controllers. Before using the equipment, please read this manual carefully to develop full familiarity with the functions and performance of the QS series PLC you have purchased, so as to ensure correct use.

CONTENTS

CHAPTER1 OVERVIEW	1 - 1 to 1 - 11
1.1 Features	1 - 3
1.2 Program Storage and Operation	1 - 7
1.3 Devices and Instructions Convenient for Programming	1 - 9
1.4 How to Check the Serial No. and Function Version	1 - 10
CHAPTER2 PERFORMANCE SPECIFICATION	2 - 1 to 2 - 2
CHAPTER3 SEQUENCE PROGRAM EXECUTION	3 - 1 to 3 - 18
3.1 Sequence Program	3 - 2
3.1.1 Sequence program description method	3 - 3
3.1.2 Sequence program operation	3 - 4
3.2 Concept of Scan Time	3 - 5
3.3 Operation Processing	3 - 7
3.3.1 Initial processing	3 - 7
3.3.2 CC-Link Safety, MELSECNET/H refresh	3 - 7
3.3.3 I/O refresh	3 - 8
3.3.4 END processing	3 - 8
3.4 RUN, STOP Operation Processing	3 - 9
3.5 Operation Processing during Momentary Power Failure	3 - 11
3.6 Data Clear Processing	3 - 12
3.7 Numeric Values which can be Used in Sequence Programs	3 - 13
3.7.1 BIN (Binary Code)	3 - 16
3.7.2 HEX (Hexadecimal)	3 - 17
3.7.3 BCD (Binary Coded Decimal)	3 - 18
CHAPTER4 I/O NUMBER ASSIGNMENT	4 - 1 to 4 - 9
4.1 Definition of I/O Number	4 - 1
4.2 Concept of I/O Number Assignment	4 - 2
4.2.1 I/O numbers of base unit	4 - 2
4.2.2 I/O number of remote station	4 - 2
4.3 I/O Assignment by GX Developer	4 - 4

4.3.1	Purpose of I/O assignment by GX Developer.....	4 - 4
4.3.2	Concept of I/O assignment using GX Developer.....	4 - 5
4.3.3	Examples of I/O Number Assignment.....	4 - 8
4.4	Checking the I/O Numbers	4 - 9

CHAPTER5 MEMORIES AND FILES HANDLED BY CPU MODULE **5 - 1 to 5 - 18**

5.1	Memories by CPU Module	5 - 1
5.1.1	Memory configuration and storable data.....	5 - 1
5.1.2	Program memory	5 - 3
5.1.3	Standard ROM.....	5 - 7
5.1.4	Standard ROM program execution (boot run) and writing.....	5 - 9
5.2	Program File Structure	5 - 14
5.3	File Operation by GX Developer and Handling Precautions.....	5 - 16
5.3.1	File operation.....	5 - 16
5.3.2	Precautions for handling files	5 - 16
5.3.3	Memory capacities of files	5 - 17
5.3.4	File size units.....	5 - 18

CHAPTER6 FUNCTIONS **6 - 1 to 6 - 62**

6.1	Function List	6 - 1
6.2	Safety CPU Operation Mode	6 - 2
6.2.1	Safety CPU operation mode	6 - 2
6.2.2	Checking safety CPU operation mode	6 - 5
6.2.3	Safety CPU operation mode switching.....	6 - 8
6.2.4	Operation of each function in each safety CPU operation mode and CPU operation status •	6 - 14
6.2.5	Online operations that can be executed on the CPU module from GX Developer	6 - 16
6.3	CPU access password	6 - 18
6.4	PLC memory initialization	6 - 21
6.5	Setting to prevent continuous RUN in TEST MODE	6 - 25
6.6	Checking the ROM write count.....	6 - 27
6.7	Self-diagnostics Function.....	6 - 28
6.7.1	LED display for error.....	6 - 31
6.7.2	Cancel the error	6 - 31
6.8	Recording the operation contents and self-diagnostics error occurrence contents (operation · error history function)	6 - 34
6.9	Constant scan	6 - 38
6.10	Setting of Output (Y) Status when Changing between STOP and RUN	6 - 41
6.11	Clock Function.....	6 - 44
6.12	Remote Operation	6 - 47
6.12.1	Remote RUN/STOP	6 - 47
6.12.2	Remote RESET.....	6 - 50
6.12.3	Relationship of remote operation and CPU's RUN/STOP status	6 - 52
6.13	Monitor Function	6 - 53
6.14	Writing in Program during CPU Module RUN	6 - 54

6.14.1 Online change in ladder mode	6 - 54
6.15 Watchdog Timer (WDT)	6 - 58
6.16 CPU Module System Display by GX Developer	6 - 60
6.17 LED Display	6 - 62
6.17.1 Method to turn off the LED	6 - 62

CHAPTER7 COMMUNICATION WITH INTELLIGENT FUNCTION MODULE 7 - 1 to 7 - 2

7.1 Communication with CC-Link Safety master module	7 - 1
7.2 Communications with MELSECNET/H module	7 - 2

CHAPTER8 PARAMETERS 8 - 1 to 8 - 12

8.1 PLC Parameters	8 - 2
8.2 Network Parameters	8 - 10

CHAPTER9 DEVICE EXPLANATION 9 - 1 to 9 - 35

9.1 Device List	9 - 1
9.2 Internal User Devices	9 - 2
9.2.1 Input (X)	9 - 5
9.2.2 Output (Y)	9 - 7
9.2.3 Internal relay (M)	9 - 8
9.2.4 Annunciator (F)	9 - 9
9.2.5 Edge relay (V)	9 - 14
9.2.6 Link relay (B)	9 - 15
9.2.7 Link special relay (SB)	9 - 17
9.2.8 Timer (T)	9 - 18
9.2.9 Counter (C)	9 - 24
9.2.10 Data register (D)	9 - 28
9.2.11 Link register (W)	9 - 29
9.2.12 Link special register (SW)	9 - 31
9.3 Internal System Devices	9 - 32
9.3.1 Special relay (SM)	9 - 32
9.3.2 Special register (SD)	9 - 33
9.4 Nesting (N)	9 - 34
9.5 Constants	9 - 35
9.5.1 Decimal constant (K)	9 - 35
9.5.2 Hexadecimal constant (H)	9 - 35

CHAPTER10 CPU MODULE PROCESSING TIME 10 - 1 to 10 - 7

10.1 Scan Time	10 - 1
10.1.1 structure and calculation of scan time	10 - 1
10.1.2 Time required for each processing included in scan time	10 - 2
10.1.3 Factors that increase the scan time	10 - 5
10.2 Other Processing Times	10 - 7

CHAPTER11 PROCEDURE FOR WRITING PROGRAM TO CPU MODULE 11 - 1 to 11 - 4

11.1	Items to be examined for program creation	11 - 1
11.2	Procedure for writing program	11 - 2
11.3	Boot run procedure	11 - 4

APPENDICES**App - 1 to App - 25**

Appendix 1	Special Relay List	App - 1
Appendix 2	Special Register List.....	App - 5
Appendix 3	List of Parameter No.	App - 20
Appendix 4	Restrictions on Using MELSECNET/H Module in the Safety CPU Module.....	App - 22
Appendix 5	Precautions for Battery Transportation	App - 25

INDEX**INDEX - 1 to INDEX - 2**

CONTENTS

CHAPTER1 OVERVIEW

- 1.1 Features
-

CHAPTER2 SYSTEM CONFIGURATION

- 2.1 System Configuration
 - 2.2 Configuration of Peripheral Devices
 - 2.3 Confirming Serial No. and Function Version
-

CHAPTER3 GENERAL SPECIFICATIONS

CHAPTER4 CPU MODULE

- 4.1 Performance Specifications
 - 4.2 Part Names
 - 4.3 Switch Operation after Writing a Program
 - 4.4 Reset Operation
-

CHAPTER5 POWER SUPPLY MODULE

- 5.1 Specifications
 - 5.2 Precaution when connecting the uninterruptive power supply
 - 5.3 Names of Parts and Settings
-

CHAPTER6 BASE UNIT

- 6.1 Specification
 - 6.2 Part Names
-

CHAPTER7 BATTERY

- 7.1 Battery (Q6BAT)
 - 7.1.1 Battery Specifications
 - 7.1.2 Installation of Battery
-

CHAPTER8 CPU MODULE START-UP PROCEDURES

- 8.1 Procedure before Operating in the SAFETY MODE
-

CHAPTER9 EMC AND LOW VOLTAGE DIRECTIVES

- 9.1 Requirements for Conformance to EMC Directive
 - 9.1.1 Standards relevant to the EMC Directive
 - 9.1.2 Installation instructions for EMC Directive
 - 9.1.3 Cables
 - 9.1.4 Power Supply Module
 - 9.1.5 Others
- 9.2 Requirement to Conform to the Low Voltage Directive
 - 9.2.1 Standard applied for MELSEC-QS series PLC
 - 9.2.2 MELSEC-QS series PLC selection
 - 9.2.3 Power supply
 - 9.2.4 Control panel
 - 9.2.5 Grounding
 - 9.2.6 External wiring

CHAPTER10 LOADING AND INSTALLATION

- 10.1 Calculating Heat Generation of PLC
- 10.2 Module Installation
 - 10.2.1 Precaution on installation
 - 10.2.2 Instructions for mounting the base unit
 - 10.2.3 Installation and removal of module
- 10.3 Wiring
 - 10.3.1 The precautions on the wiring
 - 10.3.2 Connecting to the power supply module

CHAPTER11 MAINTENANCE AND INSPECTION

- 11.1 Daily Inspection
- 11.2 Periodic Inspection
- 11.3 Battery Life and Replacement Procedure
 - 11.3.1 Battery lives of CPU modules
 - 11.3.2 Replacement Procedure of the CPU Module Battery
- 11.4 When PLC Has been Stored without a Battery
- 11.5 When Battery Has Gone Flat during Storage of a PLC

CHAPTER12 TROUBLESHOOTING

- 12.1 Troubleshooting Basics
- 12.2 Troubleshooting Flowchart
 - 12.2.1 Troubleshooting category flow
 - 12.2.2 Flowchart for when the ERR terminal (negative logic) is off (opened)
 - 12.2.3 Flowchart for when the "POWER" LED is off
 - 12.2.4 When the "ALIVE" LED does not come on or is off
 - 12.2.5 Flowchart for when the "RUN" LED is off
 - 12.2.6 When the "RUN" LED is flashing
 - 12.2.7 Flowchart for when the "ERR." LED is on/flashing

- 12.2.8 When the "USER" LED is on
- 12.2.9 When the "BAT." LED is on
- 12.2.10 Flowchart for when a program cannot be read
- 12.2.11 Flowchart for when a program cannot be written

12.3 Error Code List

- 12.3.1 Error codes
- 12.3.2 Reading an error code
- 12.3.3 Error code list (1000 to 1999)
- 12.3.4 Error code list (2000 to 2999)
- 12.3.5 Error code list (3000 to 3999)
- 12.3.6 Error code list (4000 to 4999)
- 12.3.7 Error code list (5000 to 5999)
- 12.3.8 Error code list (8000 to 9000)

12.4 Canceling Errors

12.5 Error codes returned to request source during communication with CPU module

12.6 Special Relay List

12.7 Special Register List

APPENDICES

Appendix 1 External Dimensions

Appendix 1.1 CPU module

Appendix 1.2 Power supply module

Appendix 1.3 Main base unit

Appendix 2 Precautions for Battery Transportation

INDEX

ABOUT MANUALS

Introduction Manual

Before constructing or designing the safety-related system, be sure to read the following manual.

Manual Name	Manual No. (Model Code)
Safety Application Guide Explains the overview and construction method of the safety-related system, laying and wiring examples, application programs and others. (Sold separately)	SH-080613ENG (13JR90)

The following manuals are also related to this product.
In necessary, order them by quoting the details in the tables below.

Related Manuals

Manual Name	Manual Number (Model Code)
QSCPU User's Manual (Hardware Design, Maintenance and Inspection) Explains the specifications of the QSCPU, safety power supply modules, safety base unit and other. (Sold separately)	SH-080626ENG (13JR92)
QSCPU Programming Manual (Common Instructions) Explains how to use the sequence instructions and application instructions. (Sold separately)	SH-080628ENG (13JW01)
CC-Link Safety System Master Module User's Manual QS0J61BT12 Explains the specifications, procedures and settings up to operation, parameter settings and troubleshooting of the QS0J61BT12 type CC-Link Safety system master module. (Sold separately)	SH-080600ENG (13JR88)
CC-Link Safety System Remote I/O Module User's Manual QS0J65BTB2-12DT Explains the specifications, procedures and settings up to operation, parameter settings and troubleshooting of the CC-Link Safety system remote I/O module. (Sold separately)	SH-080612ENG (13JR89)
Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network) Explains the specifications for a MELSECNET/H network system for PLC to PLC network. It explains the procedures and settings up to operation, setting the parameters, programming and troubleshooting. (Sold separately)	SH-080049 (13JF92)
GX Developer Version 8 Operating Manual Explains the online functions of the GX Developer, such as the programming, printout, monitoring, and debugging methods. (Sold separately)	SH-080373E (13JU41)
GX Developer Version 8 Operating Manual (Safety PLC) Explains the added and updated GX Developer functions to support the safety PLC. (Sold separately)	SH-080576ENG (13JU53)

Remark

Printed materials are separately available for single item purchase. Order the manual by quoting the manual number on the table above (Model code).

HOW TO SEE THIS MANUAL IS ORGANIZED

Reference destination

A reference destination or reference manual is marked
☞.

Chapter heading

The index on the right side of the page shows the chapter of the open page at a glance.

5

MEMORIES AND FILES HANDLED BY CPU MODULE

MELSEC Q series

5.1.3 Standard ROM

(1) Definition of standard ROM

The standard ROM is used to execute boot run by the CPU module.
The standard ROM is used to save programs and parameters without battery backup.
The program stored in the standard ROM is booted (read) to the program memory (☞ Section 5.1.2) to perform operation.

(2) Storable data

The standard ROM can store parameters, programs and device comments.
Refer to Section 5.1.1 (2) for the list of data that can be stored into each memory.

(3) Checking the memory capacity

To check the memory capacity, choose [Online] → [Read from PLC] on GX Developer.
1) Select "Standard ROM" as the target memory on the Read from PLC screen.
2) Click the [Free space volume] button.
3) The memory capacity appears in the Total free space volume field.

Read from PLC

Connecting interface: [COM1] Station No. [1] PLC type: [Q100]

☞ Program memory [Standard ROM] Time: [00:04:25 16:21:50]

File selection: [Program] [Parameter] [Device] [Comment] [Other]

ParameterProg Cancel all selections Execute

Program 08/04/25 16:21:54 21

Memory 08/04/25 16:21:50

PLC/Network

Free space volume

Total free space volume: 127989 bytes

Refresh view

Change specification: [25] [1000]

Create file

Related functions: Transfer setup... Execute operation... Read PLC memory... Write PLC memory... Arrange PLC memory... Create file...

☞ 1) Select target memory.

☞ 2) Click [Free space volume] button.

☞ 3) Memory capacity is displayed.

Diagram 5.5 Memory capacity checking procedure

1 Overview

2 Performance Specification

3 Basic Program Execution Conditions

4 I/O Number Assignment

5 Memories and Files Handled by CPU Module

6 Functions

7 Connections with Component Modules

8 Parameters

5.1 Memories by CPU Module

5.1.3 Standard ROM

5 - 7

Section title

The section of the open page is shown at a glance.

In addition, this manual provides the following explanations.

POINT

Explains the matters to be especially noted, the functions and others related to the description.

Remark

Provides the reference destination related to the description on that page and the convenient information.

HOW TO USE THIS MANUAL

This manual is prepared for users to understand memory map, functions, programs and devices of the CPU module when you use QS Series PLCs.

The manual is classified roughly into three sections as shown below.

- | | |
|---------------------|--|
| 1) Chapters 1 | Describe the outline of the CPU module. |
| 2) Chapters 2 to 5 | Describe the performance specifications, executable program, I/O No. and memory of the CPU module. |
| 3) Chapter 6 | Describes the functions of the CPU modules. |
| 4) Chapter 7 | Describes communication with intelligent function modules. |
| 5) Chapters 8 and 9 | Describe parameters and devices used in the CPU modules. |
| 6) Chapter 10 | Describes the CPU module processing time. |
| 7) Chapter 11 | Describes the procedure for writing parameters and programs created at the GX Developer to the CPU module. |

Remark

.....

This manual does not explain the functions of power supply modules, base units, extension cables, memory cards and batteries of CPU module.

For these details, refer to the manual shown below.



QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

.....

GENERIC TERMS AND ABBREVIATIONS


Unless otherwise specified, this manual uses the following generic terms and abbreviations to explain the QS series CPU modules.

Generic Term/Abbreviation	Description
PLC	Abbreviation for Programmable Logic Controller.
Safety PLC	General name for safety CPU module, safety power supply module, safety main base unit, CC-Link safety master module and CC-Link safety remote I/O module.
Standard PLC	General name of each module for MELSEC-Q series, MELSEC-QnA series, MELSEC-A series and MELSEC-FX series. (Used for distinction from safety PLC.)
QS series	Abbreviation for Mitsubishi safety PLC MELSEC-QS series, MELSEC-QnA series, MELSEC-A series and MELSEC-FX series. (Used for distinction from safety PLC.)
QS001CPU	Abbreviation for the QS001CPU type safety CPU module.
CPU module	Other name for the QS001CPU.
GX Developer	General product name for the models SW8D5C-GPPW, SW8D5C-GPPW-A, SW8D5C-GPPW-V and SW8D5C-GPPW-VA.
QS034B	Abbreviation for the QS034B type safety main base unit.
Base unit	Other name for the QS034B.
QS061P	Abbreviation for the QS061P-A1 and QS061P-A2 type safety power supply modules.
Power supply module	Other name for the QS061P.
QS0J61BT12	Abbreviation for the QS0J61BT12 type CC-Link Safety system master module.
CC-Link Safety master module	Other name for the QS061BT12.
MELSECNET/H module	General name for the QJ71LP21-25, QJ71LP21S-25, QJ71LP21G and QJ71BR11 type MELSECNET/H network modules.
Intelligent function module	General name for the CC-Link Safety master module and MELSECNET/H module.
QS0J65BTB2-12DT	Abbreviation for the QS0J65BTB2-12DT type CC-Link Safety remote I/O module.
CC-Link Safety remote I/O module	Other name for the QS0J65BTB2-12DT.
Q series CPU module	General name for the Q00JCPU, Q00CPU, Q01CPU, Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, Q25HCPU, Q12PHCPU, Q25PHCPU, Q12PRHCPU and Q25PRHCPU modules.
Standard CPU module	Other name for the Q series CPU module. (Used for distinction from safety CPU modules.)
Battery	Abbreviation for the Q6BAT type battery.
Blank cover	Abbreviation for the QG60 type blank cover.
GOT	General name for the Mitsubishi Graphic Operation Terminal GOT-A*** series, GOT-F*** series and GOT1000 series.

CHAPTER1 OVERVIEW

This manual describes the programs, I/O number assignment method, functions and devices of the QS Series CPU Modules (QS001CPU).

For the power supply modules, base units and batteries, refer to the manual below.















 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

(1) List of QS Series CPU Module manuals

The QS series CPU module manuals are as shown below.

For details such as manual numbers, refer to "ABOUT MANUALS" in this manual.

Table1.1 List of manuals of QS Series CPU module

				
Purpose	QSCPU CPU Module User's Manual (Hardware)	QSCPU User's Manual (Hardware Design, Maintenance and inspection)	QSCPU User's Manual (Function Explanation, Program Fundamentals)	QSCPU Programming Manual (Common Instruction)
Confirmation of part names and specifications of the CPU module				
Confirmation of connection methods for the power supply module, base unit and I/O module				
Construction of the single CPU system (confirmation of start-up procedure and I/O number assignment)				
Confirmation of the sequence program configuration and memory				
Confirmation of the functions, parameters, and devices of the CPU module				
Confirmation of the troubleshooting and error codes				
Confirmation of usage of sequence instructions, basic instructions, application instructions, etc.				

1.1 Features

The QS series CPU module has the following new features:

(1) Safety PLC system can be constructed

The QS series PLCs have obtained the highest safety level (IEC61508 SIL3, EN954-1/ISO13849-1 Category 4) applicable to PLCs.




Figure 1.1 Safety PLC system

(2) The safety CPU operation mode is equipped for safe system operation

The CPU module is equipped with two safety CPU operation modes. "SAFETY MODE" for safe system operation and "TEST MODE" for system construction and maintenance.

These two modes prevent the user's erroneous operations for safe system operation.

(a) SAFETY MODE

SAFETY MODE is a mode for safe system operation. This mode prohibits the write operation from a programming tool and the device test operation during the system operation.

(b) TEST MODE

TEST MODE is a mode for maintenance. This mode enables the write operation from a programming tool and the device test operation to debug or maintain the sequence program.

(3) Enriched operation history and error history

The CPU module can record a total of 3000 operation/error history entries for the details of the CPU module operation by the user and for the errors occurred in the CPU module or the CC-Link Safety system.

Recording the details of the CPU module operation by the user into the operation/error history clarifies the occurrence order of operations and errors. Troubleshooting becomes easier by confirming the error/operation history.

The contents recorded in the operation/error history are shown in Table1.2.

Table1.2 Recorded contents of operation/error history

Information	Contents	History Information per Entry
Operation history information	User's operations for the CPU module are stored as a history. (Operations which change the CPU module status are recorded.)	<ul style="list-style-type: none"> • Operation code • Operation message • Operation execution date • Result code • Operation attached information
Error history information	The following errors are stored as a history. <ul style="list-style-type: none"> • Error/failure detected by self-diagnostics • Hardware error • Error detected by CC-Link Safety system 	<ul style="list-style-type: none"> • Error code • Error message • Occurrence date • Error information category (common information/individual information) • Error information (common information/individual information)

(4) Enhanced RAS

(a) Enhanced memory diagnostics

The memory diagnostics equipped with the CPU module are enhanced.

(b) Redundant CPU

The CPU module has two CPUs (CPU A and CPU B). The operation results of CPU A/CPU B are compared, and output only when the results are matched so that incorrect outputs can be prevented. (When the compared results are mismatched, the system stops.)




Figure 1.2 Redundant CPU

(c) Enhanced hardware diagnostics by hardware circuit

The diagnostic functions of the Table1.3 prevents incorrect outputs when a hardware error which cannot be detected by the OS occurs.

Table1.3 Hardware diagnostics function added to the QS series CPU module

Diagnostics	Diagnosis Contents
Overvoltage/ undervoltage detection	Overvoltage or undervoltage is detected for the power supply voltage provided from the power supply module to the CPU module.
Clock stop detection	The input clock stop to the CPU module internal circuit is detected.

- (5) USB interface is equipped
The CPU module is equipped with the USB interface to communicate with a programming tool.





Figure 1.3 Connection to a personal computer using USB

1.2 Program Storage and Operation

(1) Program storage

(a) Storage of program created by GX Developer

The program created by GX Developer can be stored into the program memory or standard ROM of the CPU module.



* 1 : The standard ROM is used to ROM the program memory.

Diagram 1.4 Memory configuration and storage destinations

(b) Program execution

The CPU module operates the program stored in the program memory.




Diagram 1.5 Execution of stored program

(c) Execution of program stored in standard ROM

Programs and data can also be stored into the standard ROM.

The programs stored in the standard ROM can be booted (read) to the program memory and executed when the PLC is powered ON or the CPU module is reset.




Diagram 1.6 Boot run

1.3 Devices and Instructions Convenient for Programming

The CPU module has devices and instructions convenient for program creation.
The main devices and instructions are outlined below.

(1) Flexible device designation

CPU modules allow devices to be specified flexibly.

(a) Word device bits are handled as contacts/coils

By specifying the bit of the word device, each bit of the word device can be handled as a contact/coil.




Diagram 1.7 Designation of word device bit

(b) Input need not be pulsed by use of differential contact

An input need not be pulsed by use of a differential contact (—|/|—|/|—).




Diagram 1.8 Use of differential contact

☒ POINT

The serial No. described on rating plate and that displayed in product information list of GX Developer may be different.






- The serial No. on rating plate shows the management information of products.
- The serial No. displayed in product information list of GX Developer shows the functions of products.

The functions of products are updated when a function is added.

CHAPTER2 PERFORMANCE SPECIFICATION

Table2.1 shows the performance specifications of the CPU module.

Table2.1 Performance Specifications

Item		QS001CPU	Remarks
Control method		Repetitive operation of stored program	----
I/O control mode		Refresh mode ^{*3}	----
Program language	Sequence control language	Relay symbol language, function block.	----
Processing speed (sequence instruction)	LD X0	0.10μs	----
	MOV D0 D1	0.35μs	----
Constant scan (Function for keeping regular scan time)		1 to 2000ms (Setting available in 1ms unit.)	Setting by parameters.
Program capacity ^{*1}		14k steps (56k bytes)	 Section 5.1.1 Section 5.1.2
Memory capacity ^{*1}	Program memory (drive 0)	128k bytes	 Section 5.1.2
	Standard ROM (drive 4)	128k bytes	 Section 5.1.3
Max. number of files stored	Program memory	3 ^{*2}	 Section 5.1.2
	Standard ROM	3 ^{*2}	 Section 5.1.3
No. of times of writing data into the standard ROM		Max.100000 times	----
No. of I/O device points		6144 points(X/Y0 to 17FF)	No. of points usable on program
No. of I/O points		1024 points(X/Y0 to 3FF)	No. of points accessible to the actual I/O module

^{*1} : The maximum number of executable sequence steps is as shown below.
(Program capacity) - (File head size (default: 34 steps))



 Refer to CHAPTER 5 for details of the program capacity and file.

^{*2} : Each of parameter, sequence program, SFC program, and device comment files can be stored.

^{*3} : The refresh mode batch-accesses I/O modules before start of sequence program operation.

2 PERFORMANCE SPECIFICATION

Table2.1 Performance Specifications (Continue)

Item		QS001CPU	Remarks
No. of device points	Internal relay [M]	6144 points by default (M0-6143) (changeable)	The number of points can be changed within the setting range.  Section 9.2
	Link relay [B]	2048 points by default (B0 to 7FF) (changeable)	
	Timer [T]	512 points by default (T0 to 511) (changeable) (Sharing of low- and high-speed timers)	
		The low- and high-speed timers are specified by the instructions. The measurement unit of the low- and high-speed timers is set up by parameters. (Low-speed timer: 1 to 1000ms, 1ms unit, 100ms by default) (High-speed timer: 0.1 to 100ms, 0.1ms unit, 10ms by default)	
	Retentive timer [ST]	0 point by default (sharing of the low- and high-speed retentive timers) (changeable) The low- and high-speed retentive timers are specified by the instructions. The measurement unit of the low- and high-speed retentive timers is set up by parameters. (Low-speed retentive timer: 1 to 1000ms, 1ms unit, 100ms by default) (High-speed retentive timer: 0.1 to 100ms, 0.1ms unit, 10ms by default)	
	Counter [C]	• Normal counter: 512 points by default (C0 to 511) (changeable)	
	Data register [D]	6144 points by default (D0 to 6143) (changeable)	
	Link register [W]	2048 points by default (W0 to 7FF) (changeable)	
	Annunciator [F]	1024 points by default (F0 to 1023) (changeable)	
	Edge relay [V]	1024 points by default (V0 to 1023) (changeable)	
	Link special relay [SB]	1536 points (SB0 to 5FF)	The number of device points is fixed.
	Link special register [SW]	1536 points (SW0 to 5FF)	
	Special relay [SM]	5120 points (SM0 to 5119)	
	Special register [SD]	5120 points (SD0 to 5119)	
RUN/PAUSE contact		One contact can be set up in X0 to 17FF for each of RUN. No PAUSE contact.	Setting by parameters.
Timer function		Year, month, date, hour, minute, second and day-of-week (leap year automatically identified) Accuracy: -3.18 to +5.25s (TYP. +2.14s) / d at 0°C Accuracy: -3.18 to +2.59s (TYP. +2.07s) / d at 25°C Accuracy: -12.97 to +3.63s (TYP. -3.16s) / d at 55°C	 Section 6.11
Allowable instantaneous power failure period		Varies depending on the power supply module	----
5VDC internal current consumption		0.43A	----
External dimensions	H	98mm	----
	W	55.2mm	----
	D	115mm	----
Weight		0.29kg	----
Protection of degree		IP2X	----

Remark

Refer to the following manual for the general specifications.

 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

CHAPTER3 SEQUENCE PROGRAM EXECUTION

The CPU module executes a program in the following order




Diagram 3.1 Program execution order

3.1 Sequence Program

A sequence program is created using the sequence instructions, basic instructions, application instructions, etc.




Diagram 3.2 Sequence program

Remark

Refer to the following manual for the sequence instructions, basic instructions and application instructions.

☞ QSCPU Programming Manual (Common Instructions)

3.1.1 Sequence program description method

The sequence program is created with the ladder mode of GX Developer. The ladder mode is based on the concept of a sequence circuit of relay control. It enables programming in representation close to a sequence circuit. In the ladder mode, programming is performed in ladder block units. A ladder block is the minimum unit for performing sequence program operation, which starts from the left side vertical bus bar and ends at the right side vertical bus bar.




Diagram 3.3 Ladder mode

3.1.2 Sequence program operation

The CPU module calculates in order from the left to the right side vertical bus and from top to bottom.




Diagram 3.4 Comparison between ladder mode and list mode

(1) Execution operation of sequence program

The sequence program is executed from Step 0 to the END instruction, where END processing is performed.

After the END processing, the program restarts operation from Step 0.




Diagram 3.5 Sequence program

3.2 Concept of Scan Time

(1) Scan time

Scan time is a period from the time when the CPU module starts the sequence program operation from Step 0 until it executes Step 0 of the same sequence program again.

The scan time consists of the sequence program execution time and the END processing time.

(a) Scan time storage location

The CPU module measures the current value and minimum and maximum values of the scan time and stores them into the special registers (SD520, SD521, SD524 to 527).

The scan time can be checked by monitoring SD520, SD521 and SD524 to 527.



Diagram 3.6 Scan time storage location

When SD520 is 3 and SD521 is 400, the scan time is 3.4ms.

(b) Accuracy and measurement of scan time

The accuracy of each scan time stored into the special registers is ± 0.1 ms.

(c) Scan time watch

The CPU module has scan time watch timers (watchdog timers). (👉 (2) in this section)

(2) WDT (Watchdog timer)

The watchdog timer (hereafter abbreviated to the WDT) watches the scan time. The default value is 200ms.

(a) WDT error

A WDT error is 10ms.

When the WDT (t) is set to 10ms, a "WDT ERROR" occurs within a scan time range of $10\text{ms} < t < 20\text{ms}$.

(b) WDT Setting

The WDT setting can be changed within a range of 10ms to 2000ms in the PLC RAS of the PLC parameter dialog box. (Setting unit: 10ms)




Diagram 3.7 PLC RAS (WDT Setting)

(3) Function that repeats program at fixed intervals

The constant scan function (see Section 6.9) allows a program to be executed repeatedly at fixed intervals.

When the constant scan is set, a program is executed at intervals of the preset constant scan time.

3.3 Operation Processing

This section explains the operation processing of the CPU module.

3.3.1 Initial processing

Initial processing is a preprocessing for execution of the sequence program operation. When the PLC is power-on or the CPU module reset is canceled, the following processing is executed only once.

- System setting
- Boot from the standard ROM*
- Safety CPU operation mode setting
- Self-diagnostics
- CC-Link Safety data setting
- Start of the MELSECNET/H network information setting and network communication
- CPU operation status determination


When the initial processing is completed, the CPU module is placed in the operation status set by the RUN/STOP/RESET switch. (→ Section 3.4)

*: In SAFETY MODE, booting is executed from the standard ROM regardless of the PLC parameter boot file settings.

In TEST MODE, booting is executed from the standard ROM if booting from the standard ROM is set at the PLC parameter boot file setting.

POINT

1. The CPU module's RUN/STOP/RESET switch is shown in the figure below.



2. When a parameter or program has been changed in the STOP status, reset the CPU with the RUN/STOP/RESET switch.

3.3.2 CC-Link Safety, MELSECNET/H refresh

Refresh is executed in the refresh range set with CC-Link and MELSECNET in the network parameters.

CC-Link Safety and MELSECNET/H refresh is executed before the start of sequence program operations.

When constant scan is executed, CC-Link Safety and MELSECNET/H refresh is executed at each constant scan time.

3.3.3 I/O refresh

I/O data between CC-Link Safety master module and MELSECNET/H module is refreshed by I/O refresh.

I/O refresh is followed by CC-Link Safety and MELSECNET/H refresh.

3.3.4 END processing

This is a post-processing to return the sequence program execution to step 0 after completing the whole sequence program operation processing once.

The END processing includes the following.

- Self-diagnostic processing (☞ Section 6.7)
- Communication with GX Developer
- Watchdog timer reset processing (☞ Section 6.15)
- Setting values in the special relays/special registers in the set timing END processing.
(☞ Appendix 1, ☞ Appendix 2)
- Constant wait processing

☒ POINT

When the constant scan function(☞ Section 6.9) is set, result at END processing is stored until when END processing is completed or the next scan starts.

3.4 RUN, STOP Operation Processing

CPU module has two types of operation status; RUN and STOP status.
CPU module operation processing is explained below:

(1) RUN Status Operation Processing

RUN status indicate that the sequence program operation is performed from step 0 to END instruction to step 0 repeatedly.

(a) Output status when changing into RUN status

When changing into the RUN status, the CPU module either outputs the output (Y) status saved in the STOP status or outputs the operation result after one scan depending on the STOP → RUN-time output mode setting of the parameter dialog box. (☞ Section 6.10)

(b) Processing time before operation start

The processing time taken from switching STOP to RUN until the operation start of the sequence program varies with the system configuration and parameter settings. (Normally 0.1 s)

(2) STOP Status Operation Processing


The STOP status means that the sequence program operation is stopped by the RUN/STOP/RESET switch or the remote STOP function. (☞ Section 6.12.1)
The CPU module is also placed in the STOP status when a stop error occurs.

(a) Output status when changing into STOP status

When changing into the STOP status, the CPU module saves the output (Y) status and turns all output points OFF.
The device memory of other than the output (Y) is retained.

(3) CPU module operation processing at switch operation

Table3.1 Operation processing at switch operation

RUN/STOP status	CPU module operation processing			
	Sequence program operation processing	External output	Device memory	
			M,T,C,D	Y
RUN→STOP	Executes up to the END instruction and stops.	Saves the output (Y) status immediately before switching to the STOP status, and turns all points OFF.	Saves the device memory status immediately before switching to the STOP status.	Saves the output (Y) status immediately before switching to the STOP status, and turns all points OFF.
STOP→RUN	Starts at step 0.	Determined by the "STOP→RUN-time output mode" in the PLC parameter dialog box.	Uses the device memory status when the CPU module had been set to STOP status.	Determined by the "STOP→RUN-time output mode" in the PLC parameter dialog box. ( Section 6.10)

POINT

The CPU module performs the following in any of RUN and STOP status:

- I/O refresh processing
- Automatic refresh processing of CC-Link Safety
- MELSECNET/H module refresh processing
- Self-diagnostic processing
- Communication processing with GX Developer

If placed in the STOP status, therefore, the CPU module can perform I/O monitor and test operation using GX Developer.

3.5 Operation Processing during Momentary Power Failure

When the input voltage supplied to the power supply module drops below the specified range, the CPU module detects a momentary power failure and performs the following operation.

(1) When momentary power failure occurs for a period shorter than the permitted power failure time

The output is maintained when the momentary power failure occurs, and error history are logged. Then the system interrupts the operation processing.

(The timer clock continues.)

(a) When recovered from momentary power failure

When a momentary power failure ends, the operation processing is resumed.

(b) Watchdog timer (WDT) measurement during momentary power failure

Even if the operation is interrupted due to momentary power failure, the watchdog timer (WDT) measurement continues. For example, if the GX Developer PLC parameter mode WDT setting is set at 200 ms, when a momentary power failure of 15 ms occurs at scan time 190 ms, the watchdog timer error is set.




Diagram 3.8 Operation during momentary power failure

(2) When momentary power failure occurs for a period longer than the permitted power failure time

CPU module starts initially.

The same operation processing as that after the following operation occurs.

- Power ON
- Resetting using RUN/STOP/RESET switch.
- Remote setting using GX Developer

3.6 Data Clear Processing

This section explains how to clear CPU module data

(1) Data clear methods

There are the following six ways to clear CPU module data.

- (a) Reset with the RUN/STOP/RESET switch, GX Developer.
- (b) Restarting the PLC System
- (c) PLC memory clear using GX Developer
- (d) PLC memory format using GX Developer
- (e) PLC memory initialization using GX Developer
- (f) History clear using GX Developer (operation and error history clear)

(2) Data That Can and Cannot Be Cleared with Each Data Clearing Method.

Table3.2 shows which data can and cannot be cleared by the methods shown in (1) (a) to (f).

Table3.2 That Can and Cannot Be Cleared with Each Data Clearing Method

Data item	Data clear methods					
	Reset operation	Power restart	PLC memory clear	PLC memory format	PLC memory initialization	Clear history
Program memory data	×	×	×	○	○	×
Standard ROM data*1	×	×	×	×	○	×
Device data	○	○	○	×	○	×
Safety CPU operation mode	×	×	×	×	○*2	×
CPU access password	×	×	×	×	○	×
Clock data	×	×	×	×	○	×
Operation and error history	×	×	×	×	○*3	○*4
ROM write count	×	×	×	×	×	×

○ : Data cleared × : Data not cleared

- * 1 : When the program memory is copied into ROM using GX Developer, the standard ROM data is first cleared, then the program memory is written into standard ROM
- * 2 : When PLC memory initialization is executed, the safety CPU operation mode becomes TEST MODE.
- * 3 : After the history is erased, the following PLC memory initialization operation and error history is recorded.
 - OP005 : FSYSTEM INITIALIZE PLC MEMORY
 - OP100 : POWER ON
 - 2200 : MISSING PARAMETER
- * 4 : After the operation and error history is erased, the following operation history is recorded.
 - OP200 : CLEAR OPERATION/ERROR LOG

Remark

For details on GX Developer operation methods, refer to the following manual.

- ☞ GX Developer Version 8 Operating Manual
- ☞ GX Developer Version 8 Operating manual (Safety PLC)

3.7 Numeric Values which can be Used in Sequence Programs

Numeric and alphabetic data are expressed by "0" (OFF) and "1" (ON) numerals in the CPU module.

This expression form is called "binary code" (BIN).

The hexadecimal (HEX) expression form in which BIN data are expressed in 4-bit units, and the BCD (binary coded decimal) expression form are applicable to the CPU module.

Table3.3 shows the numeric expressions of BIN, HEX, BCD and DEC (decimal).

Table3.3 BIN, HEX, BCD, and Decimal Numeric Expressions

DEC (Decimal)	HEX (Hexadecimal)	BIN (Binary)				BCD(Binary Coded Decimal)			
0	0				0				0
1	1				1				1
2	2				10				10
3	3				11				11
•	•				•				•
•	•				•				•
•	•				•				•
9	9				1001				1001
10	A				1010			1	0000
11	B				1011			1	0001
12	C				1100			1	0010
13	D				1101			1	0011
14	E				1110			1	0100
15	F				1111			1	0101
16	10			1	0000			1	0110
17	11			1	0001			1	0111
•	•				•				•
•	•				•				•
•	•				•				•
47	2F			10	1111			100	0111
•	•								
•	•								
•	•								
32766	7FFE	0111	1111	1111	1110			--	
32767	7FFF	0111	1111	1111	1111			--	
-32768	8000	1000	0000	0000	0000	1000	0000	0000	0000
-32767	8001	1000	0000	0000	0001	1000	0000	0000	0001
•	•								
•	•								
•	•								
-2	FFFE	1111	1111	1111	1110			--	
-1	FFFF	1111	1111	1111	1111			--	

(1) Numeric value input from outside to CPU module

When setting a numeric value from an external digital switch or similar device to the CPU module, BCD (binary coded decimal) can be used as the same setting in DEC (decimal) by the method given in (b).

(a) Numeric values handled in CPU module

The CPU module performs operation in BIN (binary).

If the value set in BCD is used as-is, the CPU module recognizes the set value as a BIN and performs operation.

Hence, operation is performed using the value different from the set value.

(☞ (b) below)

(b) How to enter numeric value without taking into account BIN notation

Use the BIN instruction to convert the data set in BCD into BIN used in the CPU module.

Using the BIN instruction allows users to set numeric value data from the outside without taking into account BIN notation.




Diagram 3.9 Import of data from digital switch to CPU module

Remark

Refer to the following manual for details of the BIN instruction.

☞ QSCPU Programming Manual (Common Instructions)

(2) Numeric value output from CPU module to outside

A digital display or similar device is available to externally display the numeric value operated by the CPU module.

(a) How to output numeric value

The CPU module performs operation in BIN.

If binary values used in the CPU module are output as they are to a digital display, they will not displayed correctly.

Therefore, the BCD instruction is used to convert the data operated in BIN into BCD used by the external display or similar device.

Using the BCD instruction allows the same display as in DEC (decimal) to be provided on the external display or similar device.




Diagram 3.10 Display of CPU module operation data by digital display

Remark

Refer to the following manual for details of the BCD instruction.

☞ QSCPU Programming Manual (Common Instructions)

3.7.1 BIN (Binary Code)

(1) Binary code

Binary data is represented by 0 (OFF) and 1 (ON).

Decimal notation uses the numerals 0 through 9. When counting beyond 9, a 1 is placed in the 10s column and a 0 is placed in the 1s column to make the number 10. In binary notation, the numerals 0 and 1 are used. A carry occurs after 1 and the number becomes 10 (decimal 2).

Table3.4 shows the numerical notation by BIN and DEC.

Table3.4 Comparison between Binary and Decimal Notations

DEC (Decimal)	BIN (Binary)
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001
10	1010
11	1011

(2) Binary numeric expression

(a) Bit configuration in BIN notation used in CPU module

Each CPU module register (data registers, link registers, etc.) consists of 16 bits.

(b) Numeric data available for CPU module

Each CPU module register can store numeric values of -32768 to 32767.

Diagram 3.11 shows the numeric notation for CPU module registers.




Diagram 3.11 Numeric Expressions for CPU module Registers

POINT

To each bit of each register, a 2^n value is assigned.

Note that the most significant bit is used for distinction of sign (positive or negative).

- 1) When most significant bit is "0"...Positive
- 2) When most significant bit is "1"...Negative

3.7.2 HEX (Hexadecimal)

(1) Hexadecimal notation

In hexadecimal notation, 4 binary bits are expressed in 1 digit.

If 4 binary bits are used in binary notation, 16 different values from 0 to 15 can be represented.


Since hexadecimal notation represents 0 to 15 in 1 digit, letters A_H to F_H are used to represent the numbers 10 to 15.

Then, a carry occurs after F_H.

Table3.5 shows the numeric expressions of BIN, HEX and DEC (decimal).

Table3.5 Comparison of BIN, HEX, and DEC Numeric Expressions

DEC (Decimal)	HEX (Hexadecimal)	BIN (Binary)	
0	0		0
1	1		1
2	2		10
3	3		11
•	•		•
•	•		•
•	•		•
9	9		1001
10	A		1010
11	B		1011
12	C		1100
13	D		1101
14	E		1110
15	F		1111
16	10	1	0000
17	11	1	0001
•	•		•
•	•		•
•	•		•
47	2F	10	1111


Carry

(2) Hexadecimal numeric expression

CPU module registers (data registers, link registers, etc.) consist of 16 bits.

For 16 bits, 0 to FFFF_H can be specified in hexadecimal.

POINT

The CPU module regards data stored in HEX as BIN.

For example, if FFFF_H is stored into a register in HEX, the CPU module performs operation, regarding the value of a register as -1.

3.7.3 BCD (Binary Coded Decimal)

(1) BCD notation

BCD (binary coded decimal) is a numbering system in which one digit of DEC (decimal) is expressed in BIN (binary).

Though it uses 4-bit representation like hexadecimal notation, it does not use letters A_H to F_H.

Table 3.6 shows the numeric expressions of BIN, BCD and DEC.

Table 3.6 Comparison of BIN, BCD, and DEC Numeric Expressions

DEC (Decimal)	BIN (Binary)	BCD (Binary Coded Decimal)	
0	0000		0
1	0001		1
2	0010		10
3	0011		11
4	0100		100
5	0101		101
6	0110		110
7	0111		111
8	1000		1000
9	1001		1001
10	1010	1	0000
11	1011	1	0001
12	1100	1	0010

Carry

(2) BCD numeric expression

CPU module registers (data registers, link registers, etc.) consist of 16 bits.

In case of 16 bits, 0 to 9999 can be specified in BCD.

POINT

The CPU module regards value stored in BCD as BIN.

For example, if 8000 is stored in BCD, the CPU module performs operation, regarding the value as -32768.

When performing arithmetic operation between values stored in BCD and any values in the CPU module, use the operation instruction of the BCD.

CHAPTER4 I/O NUMBER ASSIGNMENT

This chapter explains the I/O number assignment required for the CPU module to communicate data with I/O modules and/or intelligent function modules.

4.1 Definition of I/O Number

I/O numbers indicate the addresses used in a sequence program to input or output ON/OFF data between the CPU module and other modules.

(1) Input and output of ON/OFF data

Input (X) is used to input ON/OFF data to the CPU module, and output (Y) is used to output ON/OFF data from the CPU module.

(2) I/O number expressions

I/O numbers are expressed as hexadecimal.

4.2 Concept of I/O Number Assignment

4.2.1 I/O numbers of base unit

At power-on or reset cancel, the CPU module assigns I/O numbers.

I/O numbers are assigned automatically from the right side of the CPU module of the main base unit.

When two CC-Link Safety master modules and one MELSECNET/H module are mounted on the main base unit, the I/O numbers are as shown in Diagram 4.1




Diagram 4.1 I/O number assignment example

If the base unit has empty slots mounted with no CC-Link Safety master modules or no MELSECNET/H module are mounted, the points designated at the "I/O assignment" tab screen in the "(PLC) Parameter" dialog box are assigned to the empty slots. (Default value is 16 points.)

Remark

The head I/O can be changed for each slot with the GX Developer I/O assignment.

4.2.2 I/O number of remote station


In the CC-Link Safety system, CPU module input (X) and output (Y) can be assigned to remote station I/O modules and controlled.

(1) CPU module I/O numbers that can be used at remote stations

When two CC-Link Safety master modules and one MELSECNET/H module are mounted on the main base unit, X/Y0 - X/Y5F are used.

When using CPU module input (X) and output (Y) for remote station I/O numbers, use X/Y60 or later.

[System configuration]



[I/O number assignment]




Diagram 4.2 Remote station I/O number assignment

Remark

"Empty" can be assigned in the following areas.

- Refresh area between the first CC-Link Safety master module and the second CC-Link Safety master module.
- Refresh area between the second CC-Link Safety master module and the MELSECNET/H module.

POINT

1. Inputs (X) and outputs (Y) can be used for MELSECNET/H network module link I/O (LX, LY) refresh destinations (devices on the CPU module side).
2. When using multiple CC-Link Safety master modules, make sure that refresh destination I/O numbers are not duplicated.
3. When using a CC-Link Safety master module and a MELSECNET/H module, make sure that refresh destination I/O numbers are not duplicated.

4.3 I/O Assignment by GX Developer

This section describes the I/O assignment using GX Developer.

4.3.1 Purpose of I/O assignment by GX Developer

Perform I/O assignment setting by GX Developer in the following cases.

(1) Preventing I/O numbers from changing when converting modules

You can avoid the change in the intelligent function module is removed due to a malfunction.

(2) Changing the I/O numbers to those used in the program

When the designed program's I/O numbers are different from the actual system I/O numbers, each module's I/O number of base units can be set to program-I/O number.

POINT

1. The I/O assignment setting becomes valid when the PLC is powered OFF and then ON or the CPU module is reset.
2. If an intelligent function module breaks down without making I/O assignment settings using GX Developer, it may lead to malfunction of the module, changing I/O numbers of the modules after the broken one.
Therefore, it is recommended to make I/O assignment setting using GX Developer.

4.3.2 Concept of I/O assignment using GX Developer

In I/O assignment, the "Type (module type)", "Points (I/O points)" and "Start XY" (starting I/O number) can be set for each slot of the base units.

For example, to change the number of occupied I/O points of the designated slot, only the number of occupied I/O points can be designated.

The items other than designated are set to the status where the base unit is installed.

(1) I/O assignment

The I/O assignment is conducted at the "I/O assignment" tab screen in the "(PLC) Parameter" dialog box.

Diagram 4.3 I/O assignment

(a) Slot

The slot number and what number of the main base unit the slot is are displayed. What number of the main base unit the slot is means the number of slots from 0 slot of the main base unit.

(b) Type

Select "Intelli." for the slot mounting CC-Link Safety master module and MELSECNET/H module.

For an empty slot, select empty.

If the type is not designated, the type of the actually mounted module is used.

(c) Model name

Set the mounted module model name within 16 characters.

The specified model name is not used for the CPU module. (It is used as a user's memo.)

(d) Points

To change the number of occupied I/O points of each slot, select it from the followings:

- 0(0 point)
- 16(16 points)
- 32(32 points)
- 48(48 points)
- 64(64 points)
- 128(128 points)
- 256(256 points)
- 512(512 points)
- 1024(1024 points)

If the number of occupied I/O points is not designated for a slot, the one of the actually mounted module is used.

(e) Start XY

When the I/O number of each slot is changed, you should designate the head I/O number according to the change.

If Start XY is not designated for a slot, the I/O number continuing from the last number of the currently designated slot is assigned.

(2) Precautions for I/O assignment

(a) Slot status after I/O assignment

When I/O assignment setting has been made to a slot, that setting has precedence over the mounted module.

1) When the preset number of points is less than the number of mounted intelligent function module points

"MODULE LAYOUT ERROR" occurs.

2) Mounted module and I/O assigned module type

The mounted module type and the set type in the I/O assignment setting must be the same.

If not, normal operation will not be performed.

For the intelligent function module, make sure that the numbers of I/O points are the same.

Table4.1 describes the operations performed when the mounted module type differs from the one in the I/O assignment setting.

Table4.1 List of operations performed when mounted module differs from I/O assignment

Mounted module	I/O assignment setting	Result
Empty slot	Intelli.	Empty slot
All modules	Empty	Empty slot

3) Last I/O number

In I/O assignment, set the last I/O number not to exceed the maximum value (CHAPTER 2) of the I/O points.

An error ("MODULE LAYOUT ERROR") will occur if the last I/O number exceeds the maximum value of the I/O points. (System monitor of GX Developer shows "****" as an I/O address.)

(b) Precautions for automatic start XY assignment by CPU module

When the start XY is not yet entered, the CPU module automatically assigns it. In the case of 1) or 2) below, therefore, the start XY setting of each slot may overlap the one assigned by the CPU module.

- 1) Settings of I/O numbers were exchanged in the start XY
- 2) There are slots with start XY setting and those without start XY setting (automatically assigned slot)

The following example Diagram 4.4 shows overlapping start XY.




Diagram 4.4 I/O assignment with overlapping start XY




Diagram 4.5 Start XY set by above I/O assignment

Be extremely careful not to overlap the start XY of each slot. Overlapping start XY will result in an error ("MODULE LAYOUT ERROR").

4.3.3 Examples of I/O Number Assignment

The following example shows I/O number assignment made when I/O assignment setting is performed using GX Developer.

(1) When setting the number of I/O points for mounted modules

Set slots where CC-Link Safety master module or MELSECNET/H module is mounted to 32 points so that the I/O numbers do not change when the module is removed due to the breakdown of CC-Link Safety master module or MELSECNET/H module.

(a) System configuration and I/O number assignment




Diagram 4.6 System configuration and I/O number assignment

(b) I/O assignment with GX Developer

Set slots No. 0 to 2 on the GX Developer I/O assignment setting screen to "32 points".

Select 32 points. (When the type is not selected, the type of the installed module will be selected.)

Assigning the I/O address is not necessary as the CPU does it automatically. Leaving this setting blank will not cause an error to occur.

Standard setting

	Base model name	Power model name	Extension cable	Slots
Main				
Ext.Base1				
Ext.Base2				
Ext.Base3				
Ext.Base4				

Base mode

Auto (selected)

Detail

8 Slot Default

12 Slot Default

Import Multiple CPU Parameter

Read PLC data

Acknowledge XY assignment

Multiple CPU settings

Default

Check

End

Cancel

Diagram 4.7 I/O assignment

4.4 Checking the I/O Numbers

The modules mounted on the main base unit and their I/O numbers can be checked using the GX Developer system monitor. (☞ Section 6.16)

CHAPTER5 MEMORIES AND FILES HANDLED BY CPU MODULE

5.1 Memories by CPU Module

5.1.1 Memory configuration and storable data

This section explains the memories handled by the CPU module and the data that can be stored into the memories.

(1) Memory configuration




Diagram 5.1 Data handled by CPU module

(a) Program memory (👉 Section 5.1.2)

The program memory stores the program used by the CPU module to perform operation.

(b) Standard ROM (👉 Section 5.1.3)

The standard ROM is used to execute boot run by the CPU module.

(2) Data that can be stored into memories

Table5.1 indicates the data that can be stored into the program memory, standard RAM and standard ROM and the corresponding drive Nos.

Table5.1 Storable data and storage locations

Drive No.	CPU module built-in memories		File name and extension
	Program memory	Standard ROM	
	0	4	
Parameter	◎	○	PARAM.QPA
Sequence program	◎	○	MAIN.QPG
Device comment	○	○	MAIN.QCD
User setting system area ^{*1}	○	×	--

◎ : Necessary data, ○ : Storable data, × : Unstorable data

* 1 : Set the area used by the system. (☞ Section 5.1.2(3) (b))

(3) Memory capacities and formatting necessities

Table5.2 indicates the memory capacity and formatting necessity of each memory.

Table5.2 Formatting necessity

	QS001CPU	Formatting
Program memory	128k byte	Necessary ^{*1}
Standard ROM	128k byte	Unnecessary

* 1 : Before use, be sure to format the memory using GX Developer.

5.1.2 Program memory

(1) Definition of program memory

The program memory stores the program used by the CPU module to perform operation.

The program stored in the standard ROM is booted (read) to the program memory to perform operation.

(2) Storable data

The program memory can store parameters, programs, device comments, and user setting system area data.

Refer to Section 5.1.1 (2) for the list of data that can be stored into program memory.

POINT

If the total volume of the data to be stored into the program memory exceeds its capacity, examine reducing the user setting system area data.

(3) Before using the program memory

Before using the program memory, be sure to format it by GX Developer.

(a) Formatting

When formatting, display the PLC memory format screen with GX Developer [Online] → [Format PLC memory]. This is done selecting "Program memory/Device memory" as the target memory on the PLC memory format screen.




Diagram 5.2 Program memory formatting

(b) Create a user setting system area

When formatting the program memory, set the user setting system area capacity.

1) Do not create a user setting system area


The program memory is formatted without the user setting system area being created.

2) Create a user setting system area

The user setting system area is created during formatting.


There are the following user setting system areas (Table5.3).

Table5.3 User setting system area type

System area type	Description
Online change area of multiple blocks (Online change area of FB definition)	Setting this area enables multiple blocks of data to be changed online. Refer to the following manual for the number of blocks to which online change can be made in this area setting.  GX Developer Operating Manual

POINT


When the user setting system area is created, the available area decreases by the number of created area steps.

The memory capacity can be checked from the Read from PLC screen of GX Developer. ( (3) (c) in this section)

(c) Checking the memory capacity after formatting

To check the memory capacity, choose [Online] → [Read from PLC] on GX Developer.

- 1) Select "Program memory/Device memory" as the target memory on the Read from PLC screen.
- 2) Click the **Free space volume** button.
- 3) The memory capacity appears in the Total free space volume field.



- 2) Click **Free space volume** button.
- 3) Memory capacity is displayed.

Diagram 5.3 Memory capacity checking procedure

(4) Write to program memory

When writing data to program memory, display the writing to PLC screen with GX Developer [Online] → [Write to PLC].

Select "Program memory/Device memory" as the target memory on the Write to PLC screen and write data to the PLC.




Diagram 5.4 Write to PLC screen

POINT

The file size has the minimum unit. (☞ Section 5.3.4)

The occupied memory capacity may be greater than the actual file size.

5.1.3 Standard ROM

(1) Definition of standard ROM

The standard ROM is used to execute boot run by the CPU module.

The standard ROM is used to save programs and parameters without battery backup.

The program stored in the standard ROM is booted (read) to the program memory

(☞ Section 5.1.2) to perform operation.

(2) Storable data

The standard ROM can store parameters, programs and device comments.

Refer to Section 5.1.1 (2) for the list of data that can be stored into each memory.

(3) Checking the memory capacity

To check the memory capacity, choose [Online] → [Read from PLC] on GX Developer.

1) Select "Standard ROM" as the target memory on the Read from PLC screen.

2) Click the **Free space volume** button.

3) The memory capacity appears in the Total free space volume field.




Diagram 5.5 Memory capacity checking procedure

(4) Write to standard ROM

For details on writing to the standard ROM, refer to Section 5.1.4 (3).

✖POINT

The file size has the minimum unit. (☞ Section 5.3.4)

The occupied memory capacity may be greater than the actual file size.

(5) How to use the program stored in the standard ROM

Since operation cannot be executed by the program stored in the standard ROM, use that program by booting (reading) it to the program memory. (☞ Section 5.1.4)

5.1.4 Standard ROM program execution (boot run) and writing

(1) Standard ROM program execution (boot run)

(a) Standard ROM program execution

The CPU module performs operation of the program stored in the program memory.

It does not operate the program stored in the standard ROM.

The program stored in the standard ROM is booted (read) to the program memory to perform operation.




Diagram 5.6 Boot run

1) SAFETY MODE

In SAFETY MODE, boot run is executed regardless of the boot settings made by GX Developer.

2) TEST MODE

Boot run can be executed by setting "Execute boot run" in the boot settings made by GX Developer and writing to the standard ROM.

POINT

In TEST MODE, when debugging was executed with the program memory parameters and program, write to the standard ROM at the time of switching from the TEST MODE to the SAFETY MODE.

(2) Procedure up to boot run and stopping boot run (in TEST MODE)

(a) Procedure for boot run

The following provides the procedure for boot run.

1) Program creation by GX Developer

Create a program for executing boot run.

2) Boot file by GX Developer

Set "Do boot from Standard ROM" in the Boot file of the PLC parameter dialog box.




Diagram 5.7 Boot file

3) Write to standard ROM by GX Developer

- Choose [Online] → [Write to PLC] on GX Developer and write the files to the program memory.
- Choose [Online] → [Write to PLC (Flash ROM)] → [Write the program memory to ROM...] on GX Developer, and write to the standard ROM the files written to the program memory. (✎) (3) in this section)

4) Program execution

When you carry out the following operations, the system boots from the standard ROM.

- Restarting the PLC power
- Reset end with the CPU module RUN/STOP/RESET switches.
- Remote reset using GX Developer.

5) Check for normal boot completion

Whether the boot is normally completed or not can be checked by the special relay (SM660) status.

Refer to Appendix 1 for the special relay.

(b) Operation to stop boot run

Perform the following operation using GX Developer to stop boot run and execute operation by the parameter program written to the program memory.

- 1) Remove the checkmark from "Boot from standard ROM" in the PLC parameter boot file settings.
- 2) Write parameters and sequence program data to the program memory.
- 3) Choose [Online] → [Write to PLC (Flash ROM)] → [Write the program memory to ROM...].

(c) Precautions for standard ROM program execution**1) Files stored into standard ROM**

Before executing boot run, store the following files into the standard ROM.

- Parameter *1
- Program *1
- Device comment

* 1 : Must be stored into the standard ROM.

2) Online change during boot run

If online change is made to a program in the program memory during boot run from the standard ROM, the change is not updated on the program in the boot source standard ROM.

Hence, write the program to the standard ROM (✎) (3) in this section) when the CPU module is put in a STOP status.

3) When program memory contents change at power OFF → ON or reset

When you write the PLC program into program memory and switch the PLC power OFF → ON or end the CPU module reset, if the contents of the program memory change, it is possible that boot operations are being used.

Refer to "(2)(b) Operation to stop boot run" in this section, and stop the boot run.

(3) Write to standard ROM

The program memory files are written to the standard ROM by batch-copying them to the standard ROM.

(a) Before write

Check the following points before writing the files to the standard ROM.

1) Saving the standard ROM files

When files are written to the standard ROM, all files previously stored in the standard ROM are automatically deleted.

Before writing files to the standard ROM, choose [Online] → [Read from PLC] on GX Developer and save the stored files using GX Developer in advance.

2) Preparation of files to be written

Since all files stored in the standard ROM are automatically deleted when files are to be written to the standard ROM, prepare all files to be stored in advance.

(b) Write procedure

The procedure to write files to the standard ROM will be explained.

- 1) Choose [Online] → [Write to PLC (Flash ROM)] → [Copy program memory data into ROM] on GX Developer.
- 2) The Write the program memory to ROM screen appears.




Diagram 5.8 Copy program memory data into ROM screen

- 3) Select the write destination and copy the program memory files to the standard ROM.

(4) Additions/changes to standard ROM files (in TEST MODE)

Since all files stored in the standard ROM are automatically deleted when files are to be written to the standard ROM, additions/changes to the stored files cannot be made directly.

Observe the following steps.

- 1) Choose [Online] → [Read from PLC] on GX Developer and read all files from the standard ROM.
- 2) Make necessary additions/changes to the read files.
- 3) Write the modified files to the program memory.
- 4) Choose [Online] → [Write to PLC (Flash ROM)] → [Write the program memory to ROM...], and copy these files to the program memory.

(5) Precautions (in TEST MODE)**(a) Setting of check at communication time of GX Developer**

When files are written to the standard ROM with the communication time check time set to 180 seconds or less on GX Developer, they are checked 180 seconds.

5.2 Program File Structure

A program file consists of a file header, execution program and allocate memory for online change.




Diagram 5.9 Program file structure

(1) Structure details

The capacity of the program stored in the program memory of the CPU module is the total of the above three areas.

(a) File header

This area stores the file name, size, creation date, etc.

The file header size ranges from 26 to 35 steps (104 to 140 bytes) depending on the device setting of the PLC parameter dialog box.

(Default: 34 steps)

(b) Execution program

This area stores the created program.

(c) Allocate memory for online change

This area is used when online change that increases the number of steps is performed by GX Developer.

When such an online change is performed by GX Developer, the number of remaining allocate memory for online change is displayed.

1) Default number of allocate memory for online change

The default setting is 500 steps (2000 bytes).

2) Changing the number of allocate memory for online change

The number of allocate memory for online change can be changed by GX Developer (by choosing [Online] → [Write to PLC] → <Program>, tab).

When the number of steps is insufficient for online change, it can be set again.

(☞ Section 6.14.1)

(2) Display of program capacity by GX Developer

During programming by GX Developer, the program capacity (sum of the file header capacity and the numbers of steps in the created program) is displayed in terms of the number of steps as shown in Diagram 5.10.

When a program is created, the capacity of the created program can be confirmed.





Diagram 5.10 Program capacity display

POINT

- The program capacity displayed during programming by GX Developer is the capacity of the file header and execution program and does not include the capacity of the allocate memory for online change (500 steps).

(Example) The capacity of the program having the execution program area of 491 steps is displayed on GX Developer as shown below. (The file header default is 32 steps.)



Display on GX Developer:
34 steps + 491 steps = 525 steps.

Diagram 5.11 File status on GX Developer

- Since a file is stored in file size units on the program memory, the program capacity displayed during programming by GX Developer may differ from the capacity of the program file on the CPU module. (See Section 5.3.4)

5.3 File Operation by GX Developer and Handling Precautions

5.3.1 File operation

The files stored in program memory and the standard ROM can be operated with GX Developer online operations.

However, the file operations that can be executed depend on the safety CPU operation mode and the CPU module RUN/STOP status.

( Refer to Section 6.2.5)

5.3.2 Precautions for handling files

(1) About power-off (including resets) during file operations

When the PLC is power-off or a CPU module is reset during file operations with GX Developer, the files in each memory become uncertain.

During file operations with GX Developer, do not power-off the PLC or reset a CPU module.

5.3.3 Memory capacities of files

When using the program memory or standard ROM, calculate the rough size of each file according to Table5.4.

Table5.4 Memory capacity calculation for files

Function	Rough file capacity (unit: byte)
Drive heading	70
Parameter	Default: 316 (increases depending on the parameter setting) Reference Boot setting → 100 MELSECNET/H setting made → Max. 156 increased CC-Link setting made → $22 + 572 \times (\text{number of modules of CC-Link Safety}) + 76 \times (\text{number of safety remote stations}) + 4 \times (\text{number of safety remote station parameter settings})$
Sequence program	$134^* + (4 \times ((\text{number of steps}) + (\text{number of allocate memory for online change})))$
Device comment	$80 + (\text{sum of comment data sizes of devices})$ • Comment data size of one device = $10 + 10210 \times a + 40 \times b$ • a : Quotient of $((\text{device points})/256)$ • b : Remainder of $((\text{device points})/256)$
Multi-block online program change	Value set at formatting (0/1.25k/2.5k)

* : 134 is the default value (It can be increased or decreased by parameter setting.)

5.3.4 File size units

(1) What is file size unit?

The minimum unit for writing a file to a memory area is called as a file size unit.

The CPU module file size unit is 4 bytes.




Diagram 5.12 Program memory, standard ROM file size units

CHAPTER6 FUNCTIONS

Function of CPU module is as follows:

6.1 Function List

Functions of CPU module are listed in Table6.1.

The Nos. in the "CPU module" field correspond to the CPU modules as indicated below.

Table6.1 CPU module function list

Item	Description	Safety CPU operation mode		Reference
		SAFETY MODE	TEST MODE	
Safety CPU operation mode	This function selects whether to normally operate the CPU module as part of the safety device or to carry out maintenance on the CPU module using program changes and device test functions.	○	○	Section 6.2
CPU access password	This function prevents incorrect operations from GX Developer connected by mistake.	○	○	Section 6.3
PLC memory initialization	This function erases user data written to the CPU module. When the PLC memory is initialized, data is returned to its factory settings status.	○	○	Section 6.4
Setting for preventing continuous RUN in TEST MODE	This function prevents the PLC system from running continuously for long periods in TEST MODE.	×	○	Section 6.5
ROM write count check	This function checks the number of writing to ROM.	○	○	Section 6.6
Self-Diagnosis function	This function enables the CPU module to check for failures.	○	○	Section 6.7
Operation/error history	This function records the operations that have been executed to the CPU module from the outside and the self-diagnostics errors that have occurred in the CPU module in the past.	○	○	Section 6.8
Constant scan	This function executes the program at a constant frequency.	○	○	Section 6.9
Output status selection function for transition from STOP status to RUN status	This function selects the output Y status (output before STOP/output after the calculation execution) when the CPU module is set from STOP status to RUN status.	○	○	Section 6.10
Clock function	This function executes the CPU module internal clock.	○	○	Section 6.11
Remote RUN/STOP	This function stops and starts operating the CPU module.	○	○	Section 6.12.1
Remote RESET	This function resets the CPU module when the CPU module is in a STOP status.	○	○	Section 6.12.2
Monitoring function	This function monitors the status of programs and devices on the CPU module by operating from the GX Developer.	○	○	Section 6.13
Online change	This function writes programs when the CPU module is in the RUN status.	×	○	Section 6.14
Watchdog timer	This function monitors operational delays caused by CPU module's hardware and program errors.	○	○	Section 6.15
System display	This function connects to the GX Developer and monitors system configuration.	○	○	Section 6.16
LED display	This function enables the front-mounted LEDs to indicate the operating conditions of the CPU module.	○	○	Section 6.17

○ : Available × : N/A

6.2 Safety CPU Operation Mode

6.2.1 Safety CPU operation mode

The safety CPU operation mode has "SAFETY MODE" and "TEST MODE".
Switch the safety CPU operation mode by operations from GX Developer.

(1) SAFETY MODE

This mode is used for the main operation of the safety-related system.
In SAFETY MODE, to protect this system while it is operating, operations that change safety PLC control, such as writing to PLC and device test, are prohibited.




Diagram 6.1 SAFETY MODE operation

(2) TEST MODE

This mode is used for system start-up and maintenance.

In this mode, all the GX Developer functions, such as PLC writing and device testing, can be used.




Diagram 6.2 TEST MODE operation

Remark

For details on the GX Developer operations that can be executed in SAFETY MODE and in TEST MODE, refer to the GX Developer Operating Manual (Safety PLC).

(3) Safety CPU operation mode switching

Diagram 6.3 shows the state when the safety CPU operation mode is switched.




Diagram 6.3 State when the safety CPU operation mode is switched

POINT

1. Safety CPU operation mode information is retained by the CPU module battery.
When using the CPU module, connect the battery included in the CPU module.
2. Programs cannot be executed in "SAFETY MODE (wait-for-restart)".
(Even if the RUN/STOP/RESET switch is operated STOP → RUN or a remote RUN is executed from GX Developer, the safety CPU module does not go into the Run status.)
3. In the following cases, the unit starts up in TEST MODE
 - The first power-on after the unit is purchased.
 - When the safety CPU operation mode became unstable due to low battery. (The operation contents "OP001:SYSTEM INITIALIZE OPERATION MODE" are stored in the operation/error history.)

6.2.2 Checking safety CPU operation mode






The safety CPU operation mode of the CPU module can be checked with the following methods.

- Checking with the LEDs on the front of the CPU module
- Checking with the GX Developer online operation screen
- Checking with a special relay or a special register

(1) Checking with the LEDs on the front of the CPU module

The current safety CPU operation mode can be checked with the "ALIVE" LED and "TEST" LED on the front of the CPU module.

Table6.2 Checking safety CPU operation mode with the "ALIVE" LED and "TEST" LED

TEST MODE	SAFETY MODE (wait-for-restart)	SAFETY MODE
<div> <div>ON</div> <div>ALIVE </div> </div> <div> <div>ON</div> <div> TEST</div> </div> <div>RUN <input type="checkbox"/></div> <div>ERR. <input type="checkbox"/></div> <div>USER <input type="checkbox"/></div> <div>BAT. <input type="checkbox"/></div>	<div> <div>ON</div> <div>ALIVE </div> </div> <div> <div>Flashing</div> <div> TEST</div> </div> <div>RUN <input type="checkbox"/></div> <div>ERR. <input type="checkbox"/></div> <div>USER <input type="checkbox"/></div> <div>BAT. <input type="checkbox"/></div>	<div> <div>ON</div> <div>ALIVE </div> </div> <div> <div>OFF</div> <div><input type="checkbox"/> TEST</div> </div> <div>RUN <input type="checkbox"/></div> <div>ERR. <input type="checkbox"/></div> <div>USER <input type="checkbox"/></div> <div>BAT. <input type="checkbox"/></div>

(2) Checking with the GX Developer online operation screen

The current safety CPU operation mode of the CPU module is displayed on the GX Developer online operation screen (PLC diagnostics, remote operation, etc.)

The safety CPU operation mode can be checked when executing remote operations etc. with GX Developer.




Diagram 6.4 Safety CPU operation mode display using GX Developer

(3) Checking with a special relay or a special register

The current safety CPU operation mode is stored in the special relay SM560 (TEST MODE flag) and special register SD560 (safety CPU operation mode) in the CPU module.

The safety CPU operation mode can be externally displayed using SM560 or SD560 in a program.

The safety CPU operation mode can be also checked by monitoring SM560 or SD560 with GX Developer.

Table6.3 Special relay/special register for confirming safety CPU operation mode

Device name	Name	Description
SM560	TEST MODE flag	Shows whether the current safety CPU operation mode is TEST MODE or not. <ul style="list-style-type: none"> • OFF: SAFETY MODE or SAFETY MODE (wait-for-restart) • ON: TEST MODE
SD560	Safety CPU operation mode	Shows the current safety CPU operation mode. <ul style="list-style-type: none"> • 0: SAFETY MODE • 1: TEST MODE • 2 : SAFETY MODE (wait-for-restart)

6.2.3 Safety CPU operation mode switching

To switch the safety CPU operation mode, execute the GX Developer "safety CPU operation mode switching" operation.

(1) Safety CPU operation mode switching conditions

The safety CPU operation mode can be switched in the states shown in Table6.4.

Table6.4 Conditions under which the safety CPU operation mode can be switched

Safety CPU operation mode switching conditions	TEST MODE to SAFETY MODE	SAFETY MODE to TEST MODE
CPU operation status	STOP status (which does not include one due to stop error)	STOP status (which includes one due to stop error)
Program and parameters of GX Developer and program memory:	Should be the same.	-
Other GX Developer operations, such as PLC writing and device testing:	Should not be executed.	-
Other safety CPU operation mode switching operations using GX Developer:	Should not be executed.	Should not be executed.

(2) Safety CPU operation mode switching procedure

This explains the procedure for switching the safety CPU operation mode by operating the GX Developer "safety CPU operation mode switching".

(a) TEST MODE to SAFETY MODE switching

Diagram 6.5 shows the procedure for TEST MODE to SAFETY MODE switching using GX Developer.




Diagram 6.5 TEST MODE to SAFETY MODE switching




Diagram 6.5 TEST MODE to SAFETY MODE switching (continued)





Diagram 6.5 TEST MODE to SAFETY MODE switching (continued)

SAFETY MODE (wait-for-restart)
You can return to TEST MODE by switching the safety CPU operation mode using GX Developer. Switching the safety CPU operation mode using GX Developer enables to return to the TEST MODE.

(b) SAFETY MODE to TEST MODE switching

Diagram 6.6 shows the procedure for SAFETY MODE to TEST MODE switching using GX Developer.



Continued to the next page

Diagram 6.6 SAFETY MODE to TEST MODE switching




Figure 6.6 SAFETY MODE to TEST MODE switching (continued)

6.2.4 Operation of each function in each safety CPU operation mode and CPU operation status

Table6.5 shows whether each function can be executed or not in each safety CPU operation mode and CPU operation status.


Table6.5 Whether each function can be executed or not in each safety CPU operation mode and CPU operation status

No.	Safety CPU operation mode			Test mode					
	CPU operation status			RUN status	Stop status	Stop error *1	during switching from STOP to RUN	During initial processing	
1	Execution of program			○	×	×	×	×	
2	CC-Link Safety	CPU → CC-Link refresh	RY, RWw	○	○ *2	×	×	×	
			SB, SW	○	○	×	×	×	
		CC-Link → CPU refresh	RX, RWr	○	○	×	×	×	
			SB, SW	○	○	○	×	×	
		Operation of CC-Link remote I/O station	RY to external output	○	○	○ (OFF output)	○	×	
			external output to RX	○	○	○	○	×	
3	MELSECNET/H	CPU → MELSECNET/H refresh	B, W	○	○	×	×	×	
			SB, SW	○	○	×	×	×	
		MELSECNET/H → CPU refresh	B, W	○	○	×	×	×	
			SB, SW	○	○	○	×	×	

○: The function operates. ×: The function does not operate. —: This combination does not exist.

* 1: Indicates the stop error due to moderate error or severe error.

For details on moderate errors and severe errors, refer to the following manual.

 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

* 2: [Case of CPU STOP setting] of CC-Link Safety parameter leads to the following operation.

- When [Clears compulsorily] is selected at [Case of CPU STOP setting]: OFF output
- When [Clears compulsorily] is not selected at [Case of CPU STOP setting]: RY status output

	Safety mode (wait-for-restart)					Safety mode				
	RUN status	STOP status	Stop error *1	during switching from STOP to RUN	During initial processing	RUN status	STOP status	Stop error *1	during switching from STOP to RUN	During initial processing
	—	x	x	—	—	○	x	x	x	x
	—	○ (OFF output)	x	—	—	○	○ (OFF output)	x	x	x
	—	○	x	—	—	○	○	x	x	x
	—	○	x	—	—	○	○	x	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○ (OFF output)	—	—	○	○	○ (OFF output)	○	x
	—	○	○	—	—	○	○	○	○	x
	—	○	x	—	—	○	○	x	x	x
	—	○	x	—	—	○	○	x	x	x
	—	○	x	—	—	○	○	x	x	x
	—	○	○	—	—	○	○	○	x	x

○: The function operates. x: The function does not operate. —: This combination does not exist.

* 1: Indicates the stop error due to moderate error or severe error.

For details on moderate errors and severe errors, refer to the following manual.



QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

6.2.5 Online operations that can be executed on the CPU module from GX Developer

Table6.6 shows the online operations that can be executed on the CPU module from GX Developer.

Table6.6 Online operations that can be executed on the CPU module from GX Developer

No.	Safety CPU operation mode		Test mode					
	CPU operation status		RUN status	STOP status	Stop error *1	during switching from STOP to RUN	During initial processing	
1	File operation	Write to PLC	×	○	○	×	×	
		Read from PLC	○	○	○	×	×	
		Verify with PLC	○	○	○	×	×	
		Delete PLC data	×	○	○	×	×	
2	Drive operation	Arrange PLC memory	×	○	○	×	×	
		Format PLC memory	×	○	○	×	×	
		Drive title registration	×	○	○	×	×	
		Drive title deletion	×	○	○	×	×	
		Write the program memory to ROM	×	○	○	×	×	
3	PLC memory operation	Clear PLC memory	×	○	○	×	×	
4	Program change	Writing in Program during CPU Module RUN	○	○	○	×	×	
		Writing in T/C set value during CPU Module RUN	○	○	○	×	×	
5	Monitor	Ladder monitor	○	○	○	×	×	
		Device batch monitor	○	○	○	×	×	
		Entry data monitor	○	○	○	×	×	
		Buffer memory batch	○	○	○	×	×	
		Program monitor list	○	○	○	×	×	
6	Device test		○	○	○	×	×	
7	Remote operation	Remote RUN	○	○	×	×	×	
		Remote STOP	○	○	×	×	×	
		Remote RESET	×	○	○	×	×	
8	Set clock	Reading Time Data	○	○	○	×	×	
		Changing the clock data	○	○	○	×	×	
9	Diagnostics	PLC diagnostics	○	○	○	×	×	
		Operation . error history clear	○	○	○	×	×	
		MELSECNET(II)/10/H diagnostics	○	○	○	×	×	
		CC-Link / CC-Link/LT diagnostics	○	○	○	×	×	
		System monitor	○	○	○	×	×	
10	Safety CPU operation	Test mode to safety mode switching	×	○	×	×	×	
		Safety mode to test mode switching	—	—	—	—	—	
11	CPU Access password	Registering a CPU access password	×	○	○	×	×	
		Changing a CPU access password	×	○	○	×	×	
12	Safety CPU Operation	PLC memory initialization	×	○	○	×	×	

○: The function operates. ×: The function does not operate. -: This combination does not exist.

* 1: Indicates the stop error due to moderate error or severe error.

For details on moderate errors and severe errors, refer to the following manual.


 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

	Safety mode (wait-for-restart)					Safety mode				
	RUN status	STOP status	Stop error *1	during switching from STOP to RUN	During initial processing	RUN status	STOP status	Stop error *1	during switching from STOP to RUN	During initial processing
	—	x	x	—	—	x	x	x	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	○	○	x	x	x
	—	x	x	—	—	○	○	x	x	x
	—	○	○	—	—	x	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	x	x	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	x	x	—	—	x	x	x	x	x
	—	○	○	—	—	○	○	○	x	x
	—	○	○	—	—	○	○	○	x	x
	—	x	x	—	—	○	○	○	x	x
	—	—	—	—	—	—	—	—	—	x
	—	○	○	—	—	x	○	○	x	x
	—	x	x	—	—	x	x	x	x	x
	—	x	x	—	—	x	x	x	x	x
	x	○	○	x	x	x	○	○	x	x

○: The function operates. x: The function does not operate. -: This combination does not exist.

* 1: Indicates the stop error due to moderate error or severe error.

For details on moderate errors and severe errors, refer to the following manual.

 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

6.3 CPU access password

(1) What a CPU access password is

To prevent incorrect operations from a GX Developer connected by mistake, the CPU module authenticates access using a password.

This password for authenticating access is called as the CPU access password.

The CPU access password must be set in both the GX Developer project and the CPU module.

When an operation changing control (for example, a program change) is executed from GX Developer, the CPU module compares the GX Developer project and CPU module passwords.

The operation from GX Developer is permitted only when the passwords match.




Diagram 6.7 CPU access password

(2) CPU access password setting and characters that can be used

(a) CPU access password setting

The CPU access password is set on the CPU access password registration/change screen of GX Developer.

The CPU access password set is registered in the project.

For details on CPU access password registration/change operations, refer to the GX Developer Manual (Safety PLC).




Diagram 6.8 CPU access password registration/change screen

(b) Types and number of characters that can be used for CPU access passwords

Set a CPU access password made up of 6 - 14 single-byte Latin letters, numbers, and symbols (the shaded section of Table6.7).

(Uppercase and lowercase letters are differentiated.)

Table6.7 Characters that can be used for CPU access passwords

	MSD								
		0	1	2	3	4	5	6	7
LSD		000	001	010	011	100	101	110	111
0	0000	NUL	DLE	(SP)	0	@	P	`	p
1	0001	SOH	DC1	!	1	A	Q	a	q
2	0010	STX	DC2	"	2	B	R	b	r
3	0011	ETX	DC3	#	3	C	S	c	s
4	0100	EOT	DC4	\$	4	D	T	d	t
5	0101	ENQ	NAK	%	5	E	U	e	u
6	0110	ACK	SYN	&	6	F	V	f	v
7	0111	BEL	ETB	'	7	G	W	g	w
8	1000	BS	CAN	(8	H	X	h	x
9	1001	HT	EM)	9	I	Y	i	y
A	1010	LF	SUB	*	:	J	Z	j	z
B	1011	VT	ESC	+	;	K	[k	{
C	1100	FF	FS	,	<	L	¥	l	
D	1101	CR	GS	-	=	M]	m	}
E	1110	SO	RS	.	>	N	^	n	~
F	1111	SI	US	/	?	O	_	o	DEL

POINT


- At the factory setting, CPU access password is not set in the CPU module.
When using the CPU module, set the CPU access password with GX Developer and register it in the CPU module.
(GX Developer online operation is not possible unless the CPU access password is registered to the CPU module.)
- The user must manage the CPU access password carefully.
If a CPU access password has already been set in the CPU module, writing to the PLC is not possible unless that same password is set in the GX Developer project.
Also, the set password cannot be changed.
If you lose the CPU access password, it is necessary to initialize the CPU module by initializing the PLC memory, then write the project to the PLC again.
For details on how to initialize the PLC memory, refer to Section 6.4.
- The CPU access password can be registered to the CPU module in the following cases.
 - CPU operation mode: TEST MODE
 - CPU operation status: STOP status
- Set a different CPU access password for each CPU module.

6.4 PLC memory initialization

(1) What PLC memory initialization is

PLC memory initialization erases user data written in the CPU module.
When you initialize the PLC memory, data is returned to its factory settings.

After PLC memory initialization is executed, the system automatically resets → cancels the reset, then the initialization processing is executed again.



*: OP005:SYSTEM INITIALIZE PLC MEMORY is recorded in the operation · error history.

Diagram 6.9 PLC memory initialization operation overview

(2) Contents of PLC memory initialization processing

Table6.8 shows the contents of PLC memory initialization processing.

Table6.8 Contents of PLC memory initialization processing

Item	Contents of initialization processing
Program memory	The data is erased.(State in which not even one file exists)
Standard ROM	The data is erased.(State in which not even one file exists)
CPU access password	Not registered
Safety CPU operation mode	Enters TEST MODE.
Operation/error history	After the history is erased, the following operation/error history is recorded. <ul style="list-style-type: none"> • OP005: SYSTEM INITIALIZE PLC MEMORY • OP100: POWER ON • 2200: MISSING PARAMETER
Clock data	Initializes to 2005/01/01 00:00:00.
ROM write count	2 is added

(3) PLC memory initialization execution possible/not possible

PLC memory initialization can be executed in the following cases.

Safety CPU operation mode	SAFETY MODE		SAFETY MODE (wait-for-restart)	TEST MODE	
CPU operation status	RUN	STOP	STOP	RUN	STOP
PLC memory initialization execution possible/not possible	×	○	○	×	○

○ : Can be executed, × : Cannot be executed

(4) PLC memory initialization procedure

Diagram 6.10 shows the PLC memory initialization procedure with GX Developer.




Diagram 6.10 PLC memory initialization procedure




Figure 6.10 PLC memory initialization procedure (continued)

(5) Precautions

(a) PLC memory initialization when the CPU module error occurs

If the PLC memory is initialized when the errors like [INTERNAL CPU COMMUNICATION ERROR] (error code: 8070 to 8074) occur, the communication error may occur at the time of writing from the GX Developer to the CPU module. Initialize the PLC memory after confirming that the above-mentioned error does not occur.

For how to deal with [INTERNAL CPU COMMUNICATION ERROR] (error code: 8070 to 8074), refer to the error code list described in the QSCPU User's Manual (Hardware Design, Maintenance and Inspection).

(b) Communication with GX Developer during PLC memory initialization

Online operation from GX Developer to the CPU module cannot be executed during the PLC memory initialization.

Execute online operation from GX Developer after the PLC memory initialization is completed.

6.5 Setting to prevent continuous RUN in TEST MODE

(1) What the setting to prevent continuous RUN in TEST MODE is

The setting to prevent continuous RUN in TEST MODE is for preventing a continuous RUN for a long time in TEST MODE.

If the RUN state in TEST MODE exceeds the restriction time (continuous RUN tolerance time in TEST MODE), the "TEST MODE TIME EXCEEDED" (error code: 8100) continuation error occurs.

(2) Measuring the continuous RUN operation time in TEST MODE

(a) Measurement start

When the CPU module goes into RUN status in TEST MODE, the measurement of the RUN continuous time in TEST MODE starts.

(b) Measurement stop

When the CPU module goes into the state below, the measurement of the continuous RUN operation time in TEST MODE is stopped and the measurement value is cleared.

- When the CPU module is put into the STOP status
- When the PLC is power-off
- When the CPU module is reset




Diagram 6.11 Measurement period for continuous RUN operation time in TEST MODE

Remark

1. The continuous RUN operation time in TEST MODE is not measured during operation in SAFETY MODE.
2. Measurement of the continuous RUN time in TEST MODE continues even if the operating time in TEST MODE exceeds the set continuous RUN tolerance time and the "TEST MODE TIME EXCEEDED" (error code: 8100) continuation error occurs.

(3) Setting the TEST MODE continuous RUN tolerance time

The continuous RUN tolerance time in TEST MODE is set with the PLC parameter safety setting screen.




Diagram 6.12 PLC parameter safety setting screen

(4) Checking the continuous RUN operation time in TEST MODE

The continuous RUN operation time in TEST MODE is stored in special registers SD561 and SD562.

The continuous RUN operation time in TEST MODE can be checked by monitoring special registers SD561 and SD562.

Also, if the "TEST MODE TIME EXCEEDED" continuation error occurs, special relay SM561 turns ON.

Table6.9 Special relay and special registers storing the results of measuring the TEST MODE continuous RUN time

Special relay, special register number	Description	Remark
SM561	<ul style="list-style-type: none"> Turns ON when the continuous RUN operation time in TEST MODE exceeds the continuous RUN tolerance time that has been set. 	<ul style="list-style-type: none"> Updated when changed. When the error is canceled, SM561 is turned OFF.
SD561	<ul style="list-style-type: none"> The continuous RUN operation time in TEST MODE is stored as a binary value.(in seconds) The data is stored in the range 1 to 2147483647. 	<ul style="list-style-type: none"> Updated in the processing for the end of each scan Continues storing of the measured values into memory even if the "TEST MODE TIME EXCEEDED" continuation error occurs.
SD562	<ul style="list-style-type: none"> When the measured value is cleared, SD561 and SD562 are also cleared. 	<ul style="list-style-type: none"> When the error is canceled, SD561 and SD562 are cleared.

6.6 Checking the ROM write count

The ROM write count is up to 100,000.

When the ROM write count exceeds 100,000, the continuation error "EXCEED MAX FLASH ROM REWRIT. ERR." (error code: 1610) occurs.

When the [EXCEED MAX FLASH ROM REWRIT. ERR.] (error code: 1610) occurs, the CPU may not write to the ROM, which needs to replace the CPU module.

(1) Method for checking the ROM write count

The ROM write count is stored in special registers SD232 and SD233.

The current ROM write count can be checked by monitoring special registers SD232 and SD233.

Also, if the ROM write count exceeds 100,000, special relay SM232 turns ON.

Table6.10 ROMwrite count check special relay and special registers

Special relay, special register number	Description	Remark
SM232	Turns ON if the ROM write count exceeds 100,000.	-
SD232	The ROM write count is stored as a binary value.	The ROM write count continues to be stored even if it exceeds 100,000.
SD233		

(2) Operation counted as ROM writes

Below are the operations counted as a ROM write.

(a) Writing parameters or program to the standard ROM

There are two types of writing parameters and programs to ROM

- Writing program memory to ROM using GX Developer
- Writing program memory to ROM when switching from TEST MODE to SAFETY MODE

(b) Registering the CPU access password from GX Developer

(c) PLC memory initialization

POINT

- The following shows the count value at the time of writing to ROM.
 - Writing the program memory to ROM:6
 - Registration/change of the CPU access password from GX developer :2
 - PLC memory initialization:2
- At the factory, the OS etc. are written to the ROM of the safety CPU module. Therefore, the ROM write count is increased by the number of ROM writes at the factory.

6.7 Self-diagnostics Function

(1) What the self-diagnostics function is

The self-diagnostics function diagnoses presence or absence of an error in the CPU module by itself.

The objectives of the self-diagnostics function are the prevention of malfunction of the CPU module and preventive maintenance.

(2) Self-diagnostics timing

If an error occurs when the CPU module is power on or while the CPU module is running, the self-diagnostics function detects and displays the error, and executes the CPU module operations stop etc.

(3) Checking an error

(a) LEDlit

When the CPU module detects an error, it lights up the "ERR." LED.

(b) The storage destination and checking of the error definition

If the CPU module detects an error, it turns ON special relays (SM0 and SM1) and stores the error definition (error code) in a special register (SD0).

If the CPU module detects multiple errors, it stores the error code of the latest error into SD0.

Use the special relay and the special register in a program to establish the PLC or mechanical system interlock.

(4) Checking the operation/error history

The CPU module records 3000 incidents of the operation/error history.

( Section 6.8)

The operation/error history can be checked by using GX Developer [Diagnostics] → [PLC diagnostics].

The operation/error history is backed up by battery even if the PLC is power-off.

(5) CPU module operation when an error is detected (Stop error/continuation error)

When an error is detected by the self-diagnostics, the CPU module has the following two types of operations.

(a) When an error that stops CPU module operations is detected

At the point when the CPU module detects the error, it stops operations and turns all external output OFF. (Device memory output (Y) is held.)

The error which stops operation is referred to as a stop error.

(b) When an error that allows CPU module operations to continue is detected

Even when the CPU module detects the error, it continues to execute the program.

The error which continues operation is referred to as a continuation error.

(6) Self-diagnostics list

Here is a list of the self-diagnostics executed by the CPU module.

The error messages in the "Error message" column in Table6.11 can be checked using GX Developer [Diagnostics] → [PLC Diagnostics].

Table6.11 Self-diagnostics list

No.	Detailed item/ Diagnostics subject	Diagnostics description	Diagnostics timing	Error occurring when error is detected	
				Error code	Error message
1	RAM diagnostics	Is the CPU module internal memory destroyed?	When power-on When reset canceled	1131,1132,1133, 1136,1137	RAM ERROR
			Always	1141,1142,1143, 1146	
2	F/W diagnostics	Is F/W stored in ROM corrupted?	When power-on When reset canceled When an END instruction executed	8060	INCORRECT FIRMWARE
3	Operation circuit diagnostics	Are the operation circuits for sequential processing in the CPU module working correctly?	When power-on When reset canceled When an END instruction executed	1210	OPERATION CIRCUIT ERROR
4	Program verify	Are any files stored in program memory corrupted?	When power-on When reset canceled	8031	INCORRECT FILE
			When an END instruction executed	8032	
5	Output data verify	Do the operation results that are output from CPUs A/B match?	When an END instruction executed	8050	SAFETY OUTPUT VERIFY ERROR
6	Time monitoring	Do CPUs A/B have the same OS execution state?	Always	8020	CPU A & B CAN'T BE SYNCHRONIZED
			When an END instruction executed	8021	
7	Microcomputer diagnostics	Are the registers used with the CPU module working correctly?	When power-on When reset canceled	8000	INTERNAL REGISTER ERROR
			When an END instruction executed	8010	INTERNAL BUS ERROR
8	Power supply voltage monitoring	Is the safety CPU module operating at a voltage within the range for which operation is assured?	Always	8080	POWER SUPPLY ERROR
9	Power supply voltage monitoring circuit diagnostics	Are the circuits that monitor the power supply voltage working correctly?	When an END instruction executed	8090	VOLTAGE DIAGNOSIS ERROR
10	Clock stop detection	Is input clock to the CPU module internal circuit stopped?	Always	8120	WDT CLOCK CHECK ERROR
11	CPU module OS	Check that the main CPU is not going out of control but is operating normally.	Always	1000, 1006	MAIN CPU DOWN
12	CPU module hardware	Is the hardware below for the CPU module working correctly? • Main CPU • Clock element • RUN/STOP/RESET switch	Always	1001, 1002, 1003, 1004	MAIN CPU DOWN
13	Power supply module	Has the power supply module failed?	Always	1009	MAIN CPU DOWN
14	Program	Was the END instruction executed at the end of the user program?	When an END instruction executed	1010	END NOT EXECUTE
15	CPU module, base unit, CC-Link Safety master module, MELSECNET/H module	Was an invalid interrupt generated within the CC-Link Safety master module, MELSECNET/H module, base unit, or CPU module?	During interrupt	1311	I/O INTERRUPT ERROR
16	Module state during operation	Are the CC-Link Safety master module and MELSECNET/H module operating normally?	When power-on When reset canceled	1401	INTELLIGENT FUNCTION MODULE DOWN
			When an END instruction executed	1403	

(Continued to the next page)

Table 6.11 Self-diagnostics list (continued)

No.	Detailed item/ Diagnostics subject	Diagnostics description	Diagnostics timing	Error occurring when error is detected	
				Error code	Error message
17	Route for communications with CC-Link Safety Master module, MELSECNET/H module	<ul style="list-style-type: none"> Are communications with the CC-Link Safety master module and the MELSECNET/H module normal? Is the base unit operating normally? 	When power-on When reset canceled	1411	CONTROL-BUS ERROR
			Always	1413	
			When an END instruction executed	1414, 1415	
18	Input power supply to power supply module	<ul style="list-style-type: none"> Is input power supply being supplied normally to the power supply module? Has a momentary power failure occurred in the input power supply to the power supply module? 	Always	1500	AC DOWN
19	Battery	Is the voltage of the battery mounted to the CPU module at least at the standard value?	Always	1600	BATTERY ERROR
20	ROM write count	Is the ROM write count within the assured write count (100,000)?	When an END instruction executed	1610	EXCEED MAX FLASH ROM REWRIT. ERR.
21	Module mounting state during operation	Has the status of the CC-Link Safety master module or MELSECNET/H module as mounted or not mounted changed since the power-on or the reset canceled?	When an END instruction executed	2000	MODULE VERIFY ERROR
22	Module configuration	<ul style="list-style-type: none"> Are the CC-Link Safety master module and MELSECNET/H module mounted according to the PLC parameter I/O assignment settings? Do CC-Link Safety master module and MELSECNET/H module exceed number of mountable modules? Are head I/O numbers of CC-Link Safety master module and MELSECNET/H module duplicated? 	When power-on When reset canceled	2100, 2106, 2107	MODULE LAYOUT ERROR
		Does the mounting module exceed the number of I/O points?	When power-on When reset canceled	2124	MODULE LAYOUT ERROR
		Is a module that cannot be used (I/O module, intelligent function module, GOT) mounted?	When power-on When reset canceled	2125	MODULE LAYOUT ERROR
23	Parameter configuration	Are there parameters in the CPU module?	When power-on When reset canceled	2200	MISSING PARAMETER
24	Parameter setting	Do the PLC parameter settings follow the specifications?	When power-on When reset canceled	3000, 3001, 3003, 3004, 3008	PARAMETER ERROR
		Do the [MELSECNET/H] network parameter settings follow the specifications?	When power-on When reset canceled	3100, 3101, 3102, 3104	NETWORK PARAMETER ERROR
		Do the CC-Link Safety parameter settings follow the specifications?	When power-on When reset canceled	3105, 3106, 3107	CC-LINK PARAMETER ERROR
25	Program	Is the program instruction code correct? (Are program instruction codes corrupted?)	When power-on When reset canceled For STOP → RUN	4000	INSTRUCTION CODE ERROR
		Is the program extended instruction (S.QSABORT instruction) format correct?	When power-on When reset canceled For STOP → RUN	4002, 4003, 4004	INSTRUCTION CODE ERROR
		Is there an END instruction in the program?	When power-on When reset canceled For STOP → RUN	4010	MISSING END INSTRUCTION
		When instructions are executed, does the input data handed over to the instruction follow the instruction specifications?	When instruction is executed	4100, 4101	OPERATION ERROR
26	Scan time	Is the scan time within the WDT time limit setting?	Always	5001	WDT ERROR
		When a constant scan time is set, can one scan be ended within the constant scan time?	Always	5010	PROGRAM SCAN TIME OVER
27	Operation time in TEST MODE	Is the operation time in TEST MODE within the restriction value?	When an END instruction executed	8100	TEST MODE TIME EXCEEDED

6.7.1 LED display for error

When an error occurs, the LEDs on the front of the CPU module light up and flash.
(☞ Section 6.17)

6.7.2 Cancel the error

The CPU module can carry out the operations canceling errors in programs as long as the error allows the program operations to continue.

The occurring continuation error can be checked by the bit which is turned "1" of SD81 (error factor). Error factor/continuation error corresponding to the bit number of SD81 is shown in Table6.12.

Table6.12 Error factor/error code corresponding to bit number of SD81

Bit number of SD81/error factor corresponding to continuation error		Continuation error corresponding to bit number of SD81	
Bit number	Error factor	Error code	Error message
0	Instantaneous power failure	1500	AC/DC DOWN
1	Battery low	1600	BATTERY ERROR
2	Standard ROM write count excess	1610	EXCEED MAX FLASH ROM REWRIT.ERR.
3	Test mode continuous RUN tolerance timeout	8100	TEST MODE TIME EXCEEDED
4	Scan timeout	5010	PROGRAM SCAN TIME OVER
5	Annunciator ON	9000	F**** (**** indicates the annunciator number.)
6	Safety remote station detection error	8300	CC-LINK REMOTE DETECTION ERROR
7	Safety remote station product information mismatch	8310	CC-LINK PRODUCT INFO. MISMATCH
8	Initial monitoring timeout error	8320	CC-LINK DATA RECEPTION TIMEOUT
	Safety monitoring timeout	8321	
	Error monitoring timeout error	8322	
9	Safety remote station command error	8330	CC-LINK RECEIVED DATA ERROR
	Safety remote station data split error	8331	
	Safety remote station link ID error	8332	
	Safety remote station running number error	8333	
	Safety remote station reception data error	8334	

(1) Error canceling procedure

Cancel an error with the following procedure.

- 1) Read out SD81 with GX Developer and check the cause of the current continuation error occurring in the CPU module.
- 2) Eliminate the cause of the error.
- 3) Store the canceling error code in special register SD50.
- 4) Turn special relay SM50 OFF → ON.
- 5) Again read out SD81 with GX Developer and check that the bit corresponding to the current continuation error canceled is OFF.

6) Turn special relay SM50 OFF.

(a) Error canceling procedure for multiple errors

Because the description of the error information special relays/registers (SM0, SM1, SM5, SM16, SD0 to 26) are cleared when the last error to occur (the error stored in special register SD0) is canceled, the information on errors that have not been canceled cannot be obtained from the special relays/registers.

Cancel errors that have not been canceled by obtaining errors that have occurred in the past from the error history (➡ Section 6.8).

(2) State after error canceled

If the CPU module is recovered by canceling the error, the special relays, special registers, and LEDs related to errors return to the pre-error states.

The error history does not change.

If the same error occurs again after it has been canceled, it is recorded into the error history again.

(3) Canceling annunciator

When canceling multiple detected annunciators, only the F number first detected is canceled.

(4) Canceling errors when multiple errors occur

When multiple continuation errors occur and an error is canceled, the CPU module LED display and error information are as follows.

Error canceling state	LED display Añ1 (ERR. LED, BAT.LED, USER LED)	Error information (SM0, SM15, SM16, SD0 - 26)
Before error canceled	ON	The error information for the continuation error that occurred last is stored.
↓		
The continuation error that occurred last is canceled. (There are continuation errors remaining that have not been canceled.)	ON	Returns to the no-error state.
A continuation error other than the last one is canceled. (There are continuation errors remaining that have not been canceled.)	ON	No change (The error information for the continuation error that occurred last is retained.)
↓		
All the continuation errors are canceled.	OFF	No error

- * 1: (1) When error code: 1600("BATTERY ERROR") occurs, only the "BAT." LED lights up.
When error code: 1600 is canceled, the "BAT." LED goes out.
(2) When error code: 9000(F****) occurs, only the "USER" LED lights up.
When error code: 9000 is canceled, the "USER" LED goes out.

POINT

1. When the error code for the error to be canceled is stored in SD50 and the error is canceled, the bottom 1-digit code number is ignored.
(Example)
If error code 2100 or 2106 occurred, when error code 2100 is canceled, error code 2106 is canceled too.
If error code 2100 or 2125 occurred, even when error code 2100 is canceled, error code 2125 is not canceled.
2. If an error occurred due to a cause other than the CPU module, even if the error is canceled using a special relay (SM50) and special register (SD50), the cause of the error cannot be eliminated.
(Example)
For "INTELLIGENT FUNCTION MODULE DOWN", because this error occurred in the base unit, intelligent module, or the like, even if the error is canceled using a special relay (SM50) and special register (SD50), the cause of the error cannot be eliminated.
Refer to the error code list in the QSCPU User's Manual (Hardware Design, Maintenance and Inspection) and eliminate the cause of the error.

6.8 Recording the operation contents and self-diagnostics error occurrence contents (operation/error history function)

(1) What the operation/error history function is

The operation/error history function records the operations that have been executed to the CPU module from the outside and the self-diagnostics errors that have occurred in the CPU module in the past. The objective of this function is to make troubleshooting easier.

(2) Data stored in the operation/error history area

The CPU module stores the operations that have been executed to the CPU module from the outside and the self-diagnostics errors in the operation/error history area.




Diagram 6.13 Recording the operation/error history to the CPU module

(a) Operations executed to the CPU module from the outside

The following are stored as operations executed to the CPU module from the outside.

- Online operations from GX Developer
- Operations with the CPU module RUN/STOP/RESET
- Input power supply ON/OFF

Table6.13 shows the operations stored in the operation/error history.

Table 6.13 Operations stored in the operation/error history

Classification	Operation code	Operation message	Operation description
System	OP001	SYSTEM INITIALIZE OPERATION MODE	Because the safety CPU operation mode is not retained correctly, the CPU module initialized the safety CPU operation mode in TEST MODE.
	OP002	SYSTEM INITIALIZE PROGRAM MEMORY	Because the program memory contents are not retained correctly, the CPU module formatted the program memory.
	OP003	SYSTEM INITIALIZE OPE./ERROR LOG	Because the operation/error history contents are not retained correctly, the operation/error history was initialized into 0 incidents.
	OP004	SYSTEM INITIALIZE SYSTEM CLOCK	Because the system clock data is not correct, the CPU module initialized the system clock data.
	OP005	SYSTEM INITIALIZE PLC MEMORY	The CPU module executed the PLC memory initialization function.
	OP006	SYSTEM INITIALIZE ROM WRITE INF.	Because the write to ROM information is not retained correctly, the CPU module initialized the ROM information.
System (CPU operation status)	OP010	SYSTEM SWITCH TO RUN	The CPU operation status of the CPU module switched to the RUN state.
	OP011	SYSTEM SWITCH TO STOP	The CPU operation status of the CPU module switched to the STOP state.
Power supply operation	OP100	POWER ON	The PLC was power-on. Or the CPU module reset was canceled.
Drive operation	OP144	WRITE PROGRAM MEMORY TO ROM	The write to ROM of program memory data → standard ROM was executed.
Remote operation	OP160	SWITCH TO RUN REMOTELY	The remote RUN operation was executed.
	OP161	SWITCH TO STOP REMOTELY	The remote STOP operation was executed.
Safety CPU operation mode operation	OP180	SWITCH SAFETY PC OPERATION MODE	The safety CPU operation mode was switched.
History operation	OP200	CLEAR OPERATION/ERROR LOG	The operation/error history in the CPU module was cleared.
Clock operation	OP210	ADJUST SYSTEM CLOCK	The CPU module clock was set.
CPU access password operation	OP220	MODIFY ACCESS PASSWORD	In the CPU module, the CPU access password was set.

(b) Self-diagnostics error

The contents of the self-diagnostics error detected by the CPU module are stored. For details on self-diagnostics errors, refer to the following manual.

☞ QSCPU User's Manual (Hardware Design · Maintenance and Inspection)

(3) Operation · history capacity

The contents of 3000 operations and errors can be stored in the operation/error history of the CPU module.

When the total number of operations and errors exceeds 3000, the oldest content is overwritten with the latest one in order.


(4) Displaying operation/error history using GX Developer

The contents of the operation/error history can be displayed on the GX Developer PLC diagnostics screen.

(a) PLC diagnostics screen display


Table6.14 shows the display of the operation/error history on the GX Developer PLC diagnostics screen.

Table6.14 Contents of the PLC diagnostics screen and the operation/error history item


PLC diagnostics screen	Description of PLC diagnostics screen	
	Item	Description
	Type	The history type is displayed. Ope: Operation history Err: Error history
	No.	The operation/error number is displayed.
	Detailed code	The 4-digit code corresponding to the operation history and the CC-Link Safety remote I/O unit error history is displayed. If there is no detailed code, ---- is displayed.
	Present error/Error Message	The operation content · error message recorded in the operation/error history is displayed. If the history is damaged, "BROKEN OPERATION/ERROR LOG" is displayed.

(b) Operation/error history details screen

When double-clicking a history in the history list or an error currently occurring on the PLC diagnostics screen, the detailed information in Diagram 6.14 can be displayed.



(a) Operation history



(b) Error history

Diagram 6.14 Operation history/Error history details screen

(5) Operation/error history clear

The operation/error history of the CPU module can be cleared by pressing the "Clear log" button on the GX Developer PLC Diagnostics screen.

The operation/error history clear operation is only valid when the CPU module safety CPU operation mode is TEST MODE. When the operation/error history is cleared, the CPU module stores the operation contents OP200 : "CLEAR OPERATION/ERROR LOG" in the operation/error history.

☒ POINT

The operation/error history is retained by the CPU module battery.

At the power-on or the reset cancel, the CPU module checks if the operation/error history has not been lost or damaged.

When the CPU module detects that the operation/error history has been lost or damaged due to battery low etc., the CPU module initializes the operation/error history.

When the CPU module initializes the operation/error history, operation contents OP003 : "SYSTEM INITIALIZE OPE./ERROR LOG" is stored in the operation/error history.

6.9 Constant scan

(1) Definition of Constant Scan

The scan time differs because the processing time differs depending on whether the instruction, which is used in the sequence program, is executed or not.

Constant scan is a function to execute the sequence program repeatedly while maintaining the scan time at a constant time.

(2) Applications of constant scan

I/O refresh is performed before sequence program execution.

Using the constant scan function, the I/O refresh intervals can be made constant if the sequence program execution time varies.




Diagram 6.15 Constant scan operation

(3) Setting the constant scanning time

The constant scanning time is set at the "PLC RAS" tab screen in the "(PLC) Parameter" dialog box.

The constant scan time can be set in the range of 1 to 2000 ms (in units of 1 ms).

When executing constant scanning, set the constant scanning time.

When not executing a constant scanning, leave the constant scanning time blank.




Diagram 6.16 When constant scanning time is set to 10ms

(a) Setting time condition

As the constant scan time, set a value that satisfies the following relational expression.

$$\begin{aligned} &(\text{WDT Set Time}) > (\text{Constant Scan Set Time}) \\ &> (\text{Sequence Program maximum Scan Time}) \end{aligned}$$

If the sequence program scan time is longer than the constant scan setting time, the CPU module detects "PROGRAM SCAN TIME OVER" (error code: 5010). In this case, the constant scan setting is ignored and the sequence program is executed based on its scan time.




Diagram 6.17 Operation when the Scan Time is longer than the Constant Scan setting time

If the sequence program scan time is longer than the WDT setting time, the CPU module detects a WDT error.

In this case, the program execution is stopped.

(4) Waiting time from when END processing is executed until next scan starts

Sequence program processing is stopped during the waiting time from when the END processing of a sequence program is executed until the next scan starts.

(5) Constant scan accuracy

Refer to CHAPTER 10 for the constant scan accuracy.

6.10 Setting of Output (Y) Status when Changing between STOP and RUN

(1) Definition

When changed from the RUN status to the STOP status, the CPU module stores the output (Y) in the RUN status into the PLC and turns all outputs (Y) OFF. Status when changing from STOP to RUN can be selected from the following two options with parameters in GX Developer.

- The output (Y) status prior to STOP is output.
- The output (Y) is cleared.

(2) Setting applications

Using a holding circuit or similar, it is possible to select whether the output is resumed from the previous status or not when the STOP status is changed to the RUN status.



Diagram 6.18 Holding circuit

- When the output (Y) status prior to STOP is set to output




Diagram 6.19 Timing chart when output (Y) status prior to STOP is set to output

- When output (Y) is set to clear




Diagram 6.20 Timing chart when output (Y) is set to clear

(3) Operation switching from STOP status to RUN status

(a) Output (Y) status prior to STOP is output (Default)

After the output (Y) status before the STOP status is output, the sequence program calculations are performed.

(b) Output is cleared

The output becomes OFF status.

The output (Y) is output after the operation of sequence program.

Refer to (5) for the operation when performing forced ON of output(Y) at STOP status.




Diagram 6.21 Processing when Change from STOP Status to RUN Status

(4) Setting the Output (Y) Status when Changing from STOP Status to RUN Status

Set the output (Y) status when changing from the STOP status to the RUN status in the PLC system of the PLC parameter dialog box.




Diagram 6.22 PLC system screen

(5) Precaution

When performing forced ON at STOP status of the CPU module, the output at switching from STOP status to RUN status is as shown in Table6.15.

Table6.15 Output at switching from STOP status to RUN status after performing forced ON to output (Y)

Output mode at switching from STOP to RUN	Output at switching from STOP status to RUN status
Output (Y) status prior to STOP is output	Output the status before STOP If the output (Y) is OFF before STOP, ON status is not maintained
Outputs (Y) is cleared.	Maintain ON status

6.11 Clock Function

(1) Definition of Clock Function

The clock function reads the internal clock data of the CPU module to use it for time management.

The clock data is used by the CPU module system to perform time management, e.g. storage of date into the operation/error history.

(2) Clock operation at power OFF and momentary power failure

Clock operation is continued by the internal battery of the CPU module during power OFF of the PLC or when a power failure longer than the permissible momentary power failure time occurs.

(3) Clock Data

Clock data is used in the CPU module and includes the data indicated in Table6.16.

Table6.16 Clock data details

Data Name	Contents	
Year	Four digits in AD (Countable from 1980 to 2079)	
Month	1 to 12	
Day	1 to 31 (Automatic leap year calculation)	
Hour	0 to 23 (24 hours)	
Minute	0 to 59	
Second	0 to 59	
Day of the week	0	Sunday
	1	Monday
	2	Tuesday
	3	Wednesday
	4	Thursday
	5	Friday
	6	Saturday

(4) Changing and reading the clock data

(a) Changing the clock data

Clock data are changed with GX Developer.

Using [Online] → [Set clock], GX Developer displays the clock setting window where the CPU module clock data is changed.




Diagram 6.23 Clock data write from GX Developer

POINT

When the CPU module clock data is changed using GX Developer, the CPU module records OP210: "ADJUST SYSTEM CLOCK" in the operation/error history.

(b) Reading Time Data

The special relay (SM213) and special registers (SD210-213) read clock data. For details on the special relay, refer to Appendix 1; for details on the special registers, refer to Appendix 2.

(5) Precautions

(a) Initial clock data setting

The clock data is not factory-set.

The clock data is used by the CPU module system for error · operation history, etc. When using the CPU module for the first time, be sure to set the precise time.

(b) Clock data when battery is low

The CPU measures the time even if the power fails module, using a battery mounted on the CPU module.

Therefore, if the CPU module's battery capacity falls, the clock data value may become inaccurate.

When the PLC power-on or the CPU module reset is canceled, the CPU module checks if the clock data value is within the range shown in this Section (3).

If the clock data value is incorrect, the clock data value is initialized to January 1, 2005, 00:00:00.

At this time, the CPU module records OP004: "SYSTEM INITIALIZE SYSTEM CLOCK" in the operation/error history.

(The time recorded in the operation/error history is the value of the clock data after the clock data was initialized.)

(6) Accuracy of Clock Data

The accuracy of the clock function differs with the ambient temperature, as shown below:

Table6.17 Accuracy of clock data

Ambient Temperature (°C)	Accuracy (Day difference, S)
0	- 3.18 to + 5.25(TYP.+ 2.14)
+ 25	- 3.18 to + 5.29(TYP.+ 2.07)
+ 55	- 12.97 to + 3.63(TYP.-3.16)

6.12 Remote Operation

Remote operation changes the operating status of the CPU module by the operation performed from outside (e.g. GX Developer, remote contact).

The following two options are available for remote operations:

- Remote RUN/STOP :  Section 6.12.1
- Remote RESET :  Section 6.12.2

6.12.1 Remote RUN/STOP

(1) Definition of Remote RUN/STOP

The remote RUN/STOP performs RUN/STOP of the CPU module externally with the CPU module RUN/STOP/RESET switch at RUN.

(2) Applications of remote RUN/STOP

Using remote RUN/STOP for the following remote operations are useful:

- When the CPU module is at a position out of reach
- When performing RUN/STOP of the control board CPU module externally

(3) Calculations during Remote RUN/STOP

The program calculation that performs remote RUN/STOP is as follows:

(a) Remote STOP

Executes the program to the END instruction and enters the STOP status.

(b) Remote RUN

When remote RUN is performed while in the STOP status using remote STOP, the status changes to RUN and executes the program from step 0.

(4) Method with Remote RUN/STOP

Remote RUN/STOP operation can be performed either by the RUN contact or by GX Developer.

(a) Method with RUN contact

The RUN contact is set at the PLC system tab screen in the (PLC) Parameter dialog box of GX Developer.

The range of devices that can be set is input X0 to 17FF.

By turning the set RUN contact ON/OFF, the remote RUN/STOP can be performed.

- When the RUN contact is OFF, the CPU module enters the RUN status.
- When the RUN contact is ON, the CPU module enters the STOP status.




Diagram 6.24 Time Chart for RUN/STOP with RUN Contact

(b) Method by GX Developer

RUN/STOP of the CPU module can be executed by performing remote RUN/STOP operation with GX Developer.

Operate GX Developer by choosing [Online] → [Remote operation].




Diagram 6.25 Remote RUN/STOP by GX Developer

(5) Precautions

Take note of the following, because STOP has priority in CPU module:

(a) Timing of changing to STOP status

The CPU module is put in the STOP status when remote STOP is executed from any of the followings: RUN contact, GX Developer.

(b) To put CPU module in RUN status again after remote STOP

When placing the CPU module in the RUN status again after putting it in the STOP status by remote STOP, perform remote RUN in the order that remote STOP was executed first.

☒ POINT

1 . The RUN/STOP status is described below:

- RUN Status.....Status in which the calculations are repeatedly executed from step 0 to the END/FEND instruction in the sequence program.
- STOP Status.....Status in which the sequence program calculations are stopped and the output (Y) is all OFF.

2 . After being reset, the CPU module is put to RUN/STOP status according to the RUN/STOP/RESET switch setting.

6.12.2 Remote RESET

(1) Definition of Remote RESET

A remote reset is an operation that resets the CPU module using GX Developer when the CPU module is in the STOP status.

Even if RUN/STOP/RESET switch is in RUN, the reset can be performed when the CPU module is stopped and an error that can be detected by the self-diagnosis function occurs.

(2) Applications of remote RESET

A remote reset can reset the CPU module using GX Developer when an error that is beyond the reach of the CPU module occurs.

(3) Remote RESET method

Remote RESET operation can be performed by only GX Developer.

To perform the remote RESET, follow the following steps:

- When the CPU module is in RUN status, use remote STOP to arrange the STOP status.
- Reset CPU module by the remote RESET operation.
For the GX Developer, this is performed by [Online] →[Remote operation.]

(4) Precautions

(a) Remote RESET in RUN status

Remote RESET cannot be performed when the CPU module is in RUN status. Perform remote RESET after placing the CPU module in the STOP status by performing remote STOP or similar operation.

(b) Status after reset processing completion

After the reset processing is complete, the CPU module will enter operation status set by the RUN/STOP/RESET switch.

- With the RUN/STOP/RESET switch in the STOP position, the CPU module enters into the STOP status.
- With the RUN/STOP/RESET switch in the RUN position, the CPU module enters into the RUN status.

(c) When error occurs due to noise

Take care that Remote RESET does not reset CPU module if an error occurs in the CPU module due to noise.

When the CPU module cannot be reset by the remote reset, either reset with the RUN/STOP/RESET switch or restart-up the PLC.

POINT

1. If remote RESET is performed with the CPU module stopping due to an error, note that the CPU module is placed in the operation status set by the RUN/STOP/RESET switch upon completion of the reset processing.
2. Remote processing in GX Developer can be completed without setting Remote reset to "Allow" in the PLC system setting screen of PLC parameter. However, the reset processing is not performed to the CPU module, accordingly the CPU module will not be reset.
When the CPU module status does not change with Remote reset in GX Developer, check if the Remote reset on the "PLC system" setting screen is set to "Allow".

6.12.3 Relationship of remote operation and CPU's RUN/STOP status

(1) Relationship of the Remote Operation and CPU module Switch

The CPU module operation status is as shown in Table6.18 with the combination of remote operations to RUN/STOP switch.

Table6.18 Relation between RUN/STOP status and remote operation

RUN/STOP status	Remote operation		
	RUN ^{*1}	STOP	RESET
RUN	RUN	STOP	Cannot operate ^{*2}
STOP	STOP	STOP	RESET ^{*3}

* 1 : When performing the operation with RUN contact, "RUN-PAUSE contact" must be set at the "PLC system" tab screen in the "(PLC) Parameter" dialog box.

* 2 : RESET can be performed if the CPU module changed to the STOP status by a remote operation.

* 3 : This includes a situation where the CPU module is stopped due to error.

(2) Remote Operations from the Same GX Developers

When remote operations are performed from the same GX Developer, the status of the remote operation that is executed last will be effective.

6.13 Monitor Function

(1) Definition of Monitoring Function

This is a function to read the program, device and intelligent function module status of the CPU module by using GX Developer.

The monitor functions that can be executed are shown below.

- Ladder monitor
- Device/buffer memory batch monitor
- Device registration monitor
- Device test
- Program monitor list
- Ladder registration monitor

For details on GX Developer monitor functions, refer to the following manual.

- GX Developer Operating Manual

(2) Monitor request processing timing and displayed data

The CPU module performs the END processing to handle monitor requests from GX Developer.

The results of CPU module END processing are displayed on the GX Developer side.

6.14 Writing in Program during CPU Module RUN

With the CPU module, writing during RUN is possible in ladder mode.

6.14.1 Online change in ladder mode

(1) Writing data in the circuit mode during RUN Status

Writing data in the circuit mode during RUN is a function to write a program during the CPU module RUN status.

Writing data in the circuit mode during RUN can be executed only at TEST MODE.

The program can be changed without stopping the process in CPU module program by performing writing data in the circuit mode during RUN status.




Diagram 6.26 Outline of online change in ladder mode

(2) Precautions

Take a note of the following when online change is performed:

(a) Memory enabled for online change

The memory that can be written during RUN is only program memory.

(b) Online change performed during boot run

When writing during RUN is executed, the boot source program is not changed.

Write the contents of program memory to standard ROM before the PLC power-off or the CPU module reset after writing during RUN.

(c) Number of steps enabled for online change at once

A maximum of 512 steps can be written at once during RUN.

(d) Changing the "allocate memory for online change" for online change

The following explains the precautions for changing the "allocate memory for online change" for online change.

1) The allocate memory for online change

A program file has steps secured for online change to support online change that changes the program file capacity.

The program file capacity is the sum of the created program capacity and "allocate memory for online change".

2) When program file capacity increases from the secured capacity

If the capacity secured for the program file capacity (capacity including the allocate memory for online change) is exceeded at the time of online change, the allocate memory for online change can be re-set for online change. Hence, online change can be executed when the user memory area has a free area.

3) Scan time increased when allocate memory for online change are set again

The scan time increases, when the online change reserve step is re-set in online change.

For increased scan time, refer to Section 10.1.3.

(e) Instructions do not operate normally at online change

When online change is performed, the following instructions do not operate normally.

- Trailing edge instruction
- Leading edge instruction

1) Trailing edge instruction

The trailing edge instruction is executed when the instruction is in a writing range even the execution condition(ON → OFF) is not established at the completion of online change.




Diagram 6.27 Trailing edge instruction operation

The corresponding instructions are LDF,ANDF,ORF,MFF,PLF.

2) Leading edge instruction

The leading edge instruction is not executed when the instruction is in a writing range even the execution condition(OFF → ON) is established at the completion of online.




Diagram 6.28 Leading edge instruction operation

The corresponding instructions are PLS, □P.

6.15 Watchdog Timer (WDT)

(1) Definition of Watchdog Timer (WDT)

The watchdog timer is an internal sequence timer to detect CPU module hardware and sequence program error.

(2) Watchdog Timer Setting and Reset

(a) Watchdog timer setting

The watchdog timer setting can be changed at the "PLC RAS" tab screen in the "(PLC) Parameter" dialog box.

The default value of the watchdog timer is 200 ms.

The setting range is 10 to 2000 ms (in 10ms units).

(b) Watchdog timer resetting

CPU module resets the watchdog timer during the END processing.

- When the END instruction is executed within the set value of the watchdog timer in the sequence program and the CPU module is operating correctly, the watchdog timer does not time out.
- When the scan time of a sequence program is extended due to the CPU module hardware error, and END instruction cannot be executed within the set watchdog timer value, the watchdog timer times out.

(3) When watchdog timer expires

When the watchdog timer expires, a watchdog timer error occurs.

The CPU module responds to the watchdog timer error as follows:

- 1) The CPU module turns off all outputs.
- 2) The front-mounted "RUN" LED turned off, and the "ERR." LED starts flicking.
- 3) SM0, SM1 turns ON and the error code 5001 ("WDT ERROR") is stored into SD0.

(4) Precautions

(a) Watchdog timer error

An error of 0 to 10 ms occurs in the measurement time of the watchdog timer. Set the watchdog timer for a desired value by taking such an error into account.

☒ POINT

1. The scan time is the time taken for the execution of the sequence program, starting from step 0 and ending at step 0.
The scan time is not the same for each scan, which differs according to the execution or non-execution of the instructions used in the program.
2. To execute at the same scan time at every scan, use the constant scan function. (☞ Section 6.9)

6.16 CPU Module System Display by GX Developer

After GX Developer is connected to the CPU module, the following items can be checked in the system monitor.

- Installed status
- Parameter status
- Module's detailed information
- Product information




Diagram 6.29 System monitor screen

(1) Installed status

The names and number of modules mounted on the base unit can be checked.

"Not mounted" is displayed for slots in which no module is mounted.

For slots for which "empty" is set in the PLC parameter I/O assignment, even if a module is mounted, the module name is not displayed.

(2) Parameter status

The I/O numbers, module type, and points for the each slot of the base unit can be checked.

If an assignment error or empty 0 is displayed for the operation status, the PLC parameter I/O assignment is different from the loading status.

Match the PLC parameter I/O assignments to the loading status.

(3) Base

The state of the mounted modules and the base unit can be checked.

When even one error module exists, the module column becomes the state color for that module.

(4) Diagnostics

This function is used to confirm the status of the CPU module and errors.

This is used to check detailed information on the selected module.
For detailed information on intelligent function modules, refer to the manual for each intelligent function module.

Enables the "Overall Information" and "Base Information" to be confirmed.


Enables the number of base units in use and the number of modules mounted on the base units to be confirmed.

Enables the base name, the number of slots, the base type and the number of modules mounted onto the base for the selected base unit to be confirmed.

Enables the individual information for mounted CPU modules and intelligent function modules to be confirmed (type, series, model, number, head I/O, control PLC, serial No., function version.)

Diagram 6.30 Product information list

Refer to the following manual for details of the system monitor of GX Developer.

 GX Developer Operating Manual

6.17 LED Display

The LEDs on the front of the CPU module show the CPU module operation status.




Diagram 6.31 LED on CPU module front

Remark

Refer to the following manual for details of the LED indications.

➞ QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

6.17.1 Method to turn off the LED

The LED that is on can be turned off by the following operation. (Except for the reset operation.)

Table6.19 LED turning off method

Method to Turn LED Off	Applicable LED			
	ERR.	USER	BAT.	BOOT
After the cause of error is resolved, cancel the error by operating the special relay SM50 and special register SD50. (Only for the operation continue errors.) *1	○	○	○	×

○ : Valid × : Invalid

* 1 : Special relay and special register contents

SM50...When switch from OFF to ON, the error is canceled for the error code stored in the SD50.

SD50...The error code for the error to be canceled is stored.

Refer to the following manual for the error codes.

➞ QSCPU User's Manual (Hardware Design/Maintenance and Inspection)

CHAPTER7 COMMUNICATION WITH INTELLIGENT FUNCTION MODULE

7.1 Communication with CC-Link Safety master module

Communication between the CPU modules and the CC-Link Safety master module is executed by auto refresh.

When auto refresh is executed, the remote input, remote output, and remote register refresh devices are set with the GX Developer network parameter CC-Link settings.

For details on the items set in the network parameter CC-Link settings, refer to Section 8.2.

Remark

For details on the network parameter CC-Link settings, refer to the manual below.

 CC-Link Safety System Master Module User's Manual

7.2 Communications with MELSECNET/H module

Communication between CPU modules and the MELSECNET/H module is carried out with auto refresh.

When executing auto refresh, the refresh parameters are set with the GX Developer network parameter MELSECNET settings.

For details on the items set in the MELSECNET settings, refer to Section 8.2.


POINT

When using a MELSECNET/H module with a safety CPU module, the functions that can be used are restricted.

For details on the restrictions when using a MELSECNET/H module, refer to Appendix 4.

Remark

.....
For details on the network parameter MELSECNET settings, refer to the manual below.

 Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC Networks)
.....

CHAPTER8 PARAMETERS

This chapter explains the parameters that are set when a PLC system is configured.

(1) Parameter types

There are the following CPU module parameters.

- PLC parameter (☞ Section 8.1)
Set when the PLC is used independently.
- Network parameter (☞ Section 8.2)
Set when the CC-Link Safety master modules and MELSECNET/H module are used in combination with the PLC.

(2) Parameter setting method

Set the parameters by GX Developer.

Refer to the following manual for the setting operation on GX Developer.

For details on basic operations using GX Developer, refer to the following manual.

☞ GX Developer Operating Manual

POINT

In GX Developer, since the functions are not available to the CPU module being used, it is not necessary to set the setting items displayed in gray (cannot be selected) that are not explained in this section.

Remark

- When an error occurs in the parameter setting, the corresponding parameter No. indicated in the tables of this chapter is stored into the special register (SD16 to 26).
Refer to Appendix 3 for the list of the parameter No.
- Refer to CHAPTER 11 for the parameter reflection procedure.

8.1 PLC Parameters

This section explains the PLC parameter list and parameter details.

(1) PLC name

Set the label and comment of the used CPU module.

Setting the label and comment in the PLC name does not affect the actual operation.




Diagram 8.1 PLC name

Table8.1 PLC name list

Item	Parameter No.	Description	Setting range	Default value	Reference
Label	0000 _H	Set the label (name, application) of the CPU module.	Max. 10 characters	No setting	----
Comment	0001 _H	Set the comment of the CPU module label.	Max. 64 characters	No setting	----

(2) PLC system

Make the settings necessary to use the CPU module.

The parameters may be the default values to perform control.




Diagram 8.2 PLC system

Table 8.2 PLC system setting list

Item	Parameter No.	Description	Setting range	Default value	Reference
Timer limit setting	1000 _H	Set the time limit of the low speed timer/high speed timer.	1ms to 1000ms (1ms unit)	100ms	Section 9.2.8
			0.1ms to 100.0ms (0.1ms unit)	10.0ms	Section 9.2.8
RUN-PAUSE contact	1001 _H	Set the contact that controls RUN of the CPU module.	X0 to 17FF	No setting	Section 6.12.1
Remote reset	1002 _H	Set enable/disable of remote reset operation from GX Developer.	Enable/Disable	Enable	Section 6.12.2
Output mode at STOP to Run	1003 _H	Set the output (Y) status when the STOP status is switched to the RUN status.	Provide output (Y) status before STOP/Clear output (Y) (output one scan later)	Provide output (Y) status before STOP	Section 6.10
Points occupied by empty slot	1007 _H	Set the number of empty slots on the main base unit.	0 points/16 points/32 points/64 points/128 points/256 points/512 points/1024 points	16 points	Section 4.2.1

(Continued on next page)

(3) PLC RAS

Make the various settings for the RAS function.

The screenshot shows the 'QS Parameter' dialog box with the 'PLC RAS' tab selected. The 'WDT (Watchdog timer) setting' section includes 'WDT Setting' (200 ms), 'Initial execution monitoring time' (10ms~2000ms), and 'Low speed execution monitoring time' (10ms~2000ms). The 'Error check' section has three unchecked checkboxes: 'Carry out battery check', 'Carry out fuse blown check', and 'Carry out I/O module comparison'. The 'Constant scanning' section has a value of 1 ms. The 'Low speed program execution time' is set to 1 ms. The 'Breakdown history' section has 'Record in PLC RAM' selected. The 'Corresponding memory' is set to 'error'. The 'File name' and 'History No.' fields are empty. The 'History No.' is limited to 16~100 items. At the bottom, there are buttons for 'Acknowledge XY assignment', 'Multiple CPU settings', 'Default', 'Check', 'End', and 'Cancel'.

Diagram 8.3 PLC RAS

Table8.3 PLC RAS list

Item	Parameter No.	Description	Setting range	Default value	Reference
WDT (watchdog timer) setting	3000 _H	Set the watchdog timer value of the CPU module.	10ms to 2000ms (10ms unit)	200ms	Section 3.2
Constant scanning	3003 _H	Set the constant scan time.	1ms to 2000ms (1ms unit)	No setting	Section 6.9

(4) Device

Set the number of used points and latch range for each device.

	Sym.	Dig.	Dev. point	Latch(1) start	Latch(1) end	Latch(2) start	Latch(2) end	Local dev. start	Local dev. end
Input relay	X	16	6K						
Output relay	Y	16	6K						
Internal relay	M	10	6K						
Latch relay	L	10							
Link relay	B	16	2K						
Annunciator	F	10	1K						
Link special	SB	16	1536						
Edge relay	V	10	1K						
Step relay	S	10							
Timer	T	10	512						
Retentive timer	ST	10	0K						
Counter	C	10	512						
Data register	D	10	6K						
Link register	W	16	2K						
Link special	SW	16	1536						

Device total: 12.1 K words The total number of device points is up to 12384 words.

Word device: 10.5 K words High speed area X0 - C511

Bit device: 13.5 K bits

Acknowledge XY assignment Multiple CPU settings Default Check End Cancel

Diagram 8.4 Device

Table8.4 Device list

Item	Parameter No.	Description	Setting range	Default value	Reference
Device points	2000 _H	Set the number of used device points according to the system.	<p>X (6k points), Y (6k points), 1536, SB (1536 points) and SW (1536 points) are fixed.</p> <p>Can be set within the range of total 12384 words, including the above number of points (2400 words).</p> <p>• 1 device: Max. 32k points</p>	<p>X : 6k points</p> <p>Y : 6k points</p> <p>M : 6k points</p> <p>B : 2k points</p> <p>F : 1k points</p> <p>SB : 1536 points</p> <p>V : 1k points</p> <p>T : 512 points</p> <p>ST : 0k points</p> <p>C : 512 points</p> <p>D : 6k points</p> <p>W : 2k points</p> <p>SW : 1536 points</p>	Section 9.1

(5) Boot file

Set whether a boot from the standard ROM will be executed or not.




Diagram 8.5 Boot file

Table8.5 Boot file list

Item	Parameter No.	Description	Setting range	Default value	Reference
Boot file	7000 _H	At TEST MODE, set whether to boot from the standard ROM or not.	Do not execute boot/Execute boot	Do not execute boot	Section 5.1.4

POINT

In SAFETY MODE, boot operation is executed regardless of the boot file settings.

(6) I/O assignment

Set the mounting status of each module in the system.

Diagram 8.6 I/O assignment

Table8.6 I/O assignment list

Item	Parameter No.	Description	Setting range	Default value	Reference
I/O assignment	Type	Set the type of the mounted module.	Empty/intelli.	No setting	Section 4.3
	Model name	Set the model name of the mounted module. (User memo. Not used for the CPU module.)	16 characters	No setting	
	points	Set the number of points of each slot.	0 points/16 points/32 points/ 48 points/64 points/ 128 points/256 points/ 512 points/1024 points	No setting	
	Start XY (Start I/O No.)	Set the start I/O number of each slot.	0 _H to 3F0 _H	No setting	
Standard setting	Base model name	Set the model name of the used main base unit. (User memo. Not used for the CPU module.)	16 characters	No setting	Section 4.4
	Power model name	Set the model name of the power supply module mounted on the main base unit. (User memo. Not used for the CPU module.)	16 characters	No setting	
	Extension cable	Set the extension cable model name. (User memo. Not used for the CPU module.)	16 characters	No setting	
	Slots	Set the number of slots of the main base unit.	4	No setting	
Switch setting	0407 _H	Unusable	Unusable	----	----

(7) X/Y assignment

Check the data set in the I/O assignment, MELSECNET/Ethernet setting and CC-Link setting.

XY No.	Type		Slot	Module type	Points	Model name	Duplication
	Network	I/O Assign					
0000							
0010							
0020							
0030							
0040							
0050							
0060							
0070							
0080							
0090							
00A0							
00B0							
00C0							
00D0							

In the I/O assignment setting, It is not possible to check correctly, when there is a slot of the unsetting on the way.

Close

Diagram 8.7 X/Y assignment

Table8.7 X/Y assignment list

Item	Parameter No.	Description	Setting range	Default value	Reference
X/Y assignment	---	The data set in the I/O assignment, MELSECNET setting and CC-Link setting can be checked.	---	---	---

(8) Safety settings

Set the operation settings in continuous RUN in test mode and for remote station error status.




Diagram 8.8 Safety settings

Table 8.8 Safety settings

Item	Parameter No.	Description	Setting range	Default value	Reference
Continuous RUN in test mode	6000H	Set the continuous RUN tolerance time in TEST MODE.	1 second to 86400 seconds	10 seconds	Section 6.5
Operation settings for remote station error status		Set the operation settings for remote station errors	Stop/Continue	Continue	----

8.2 Network Parameters

This section explains the network parameter list and parameter details.

■ mn, N and M in the Parameter No. field of this section

mn, N and M in the Parameter No. field of this section indicate the following.


mn : Indicates a "start I/O No. \div 16" value.

N : Indicates the module number.

M : Indicates the network type.

Table8.9 In the case of MELSECNET/H setting ( (1) in this section)

M	Network type
2 _H	MELSECNET/10 mode (Normal station), MELSECNET/H mode (Normal station), MELSECNET/H. Extended mode (Normal station)

Table8.10 In the case of CC-Link setting ( (2) in this section)

M	Network type
0 _H	Master station

(1) MELSECNET/H setting

Set the MELSECNET/H network parameters.

Network parameters Setting the number of MNET/10H.

	Module 1	Module 2	Module 3	Module 4
Network type	MNET/H mode (Normal station)	None		
Starting I/O No.	0020			
Network No.	1			
Total stations				
Group No.	1			
Station No.				
Mode	On line			
Refresh parameters				

Necessary setting: ☐ No setting / ☐ Already set Set if it is needed: ☐ No setting / ☐ Already set

Start I/O No.: Valid module during other station access

Interlink transmission parameters: Please input the starting I/O No. of the module in HEX(16 bit) form

Acknowledge XY assignment: ☐ Routing parameters: ☐ Assignment image: ☐ Group Settings: ☐ Check: End: Cancel:

Diagram 8.9 Network parameters Setting the number of MNET/10H

Table8.11 MELSECNET/H setting list

Item	Parameter No.	Description	Setting range	Default value	Reference
Number of MELSECNET	5000 _H	Set the MELSECNET/H network parameters.	Refer to the Q Corresponding MELSECNET/H Manual.	----	----
Starting I/O No.	5NM0 _H				
Network No.	05mn _H				
Group No.	5NM0 _H				
Mode	5NM1 _H				
Refresh parameters					

(2) CC-Link setting

Set the CC-Link parameters.

Network parameters: Setting the CC-Link list.

No. of boards in module: 1 Boards Blank: no setting.

	1	2	3	4
Start I/O No.				
Operational setting	Operational settings			
Type	Safety master station			
Station No.	0			
Master station data link type	PLC parameter auto start			
Mode	Safety remote net(Ver. 1 mode)			
Transmission speed	156k-bps			
Safety refresh monitoring time	200			
Link ID	0			
All connect count	64			
Remote input(RX)				
Remote output(RY)				
Remote register(RWrl)				
Remote register(RWw)				
Special relay(SB)				
Special register(SW)				
Retry count	3			
Automatic reconnection station count	1			
PLC down select	Stop			
Scan mode setting	Synchronous			
Delay information setting	0			
Station information setting	Station information			
Remote device station initial setting				

Indispensable settings(No setting / Already set) Set if it is needed(No setting / Already set)

Setting item details: Please input the start I/O No. where the CC-Link is connected in 16-point unit.

Acknowledge XY assignment Clear Check End Cancel

Diagram 8.10 Network parameters Setting the CC-Link list

Table8.12 Network parameters Setting the CC-Link list

Item	Parameter No.	Description	Setting range	Default value	Reference
Number of CC-Link	C000 _H	Set the CC-Link safety parameters.	Refer to the CC-Link safety Manual.	----	----
Starting I/O No.	CNM2 _H				
Operational settings					
Mode setting					
Transmission settings					
Safety refresh monitoring time					
Link ID					
All connect count					
Remote input (RX)	CNM1 _H				
Remote output (RY)					
Remote register (RW _r)					
Remote register (RW _w)					
Special relay (SB)					
Special register (SW)	CNM2 _H				
Retry count					
Automatic reconnection station count					
Scan mode setting					
Station information setting					

(Continued on next page)

CHAPTER9 DEVICE EXPLANATION

This chapter describes all devices that can be used in the CPU module.

9.1 Device List

The names and data ranges of devices which can be used in the CPU module are shown in Table9.1.

Table9.1 Device List

Class	Type	Device Name	Default Values			Parameter Designated Setting Range	Reference Section
			Number of Points	Range Used			
Internal user devices	Bit devices	Input	6144 points	X0 to 17FF	Hexadecimal	Changeable within 12384 words.*2	Section 9.2.1
		Output	6144 points	Y0 to 17FF	Hexadecimal		Section 9.2.2
		Internal relay	6144 points	M0 to 6143	Decimal		Section 9.2.3
		Annunciator	1024 points	F0 to 1023	Decimal		Section 9.2.4
		Edge relay	1024 points	V0 to 1023	Decimal		Section 9.2.5
		Link relay	2048 points	B0 to 7FF	Hexadecimal		Section 9.2.6
		Special link relay	1536 points	SB0 to 5FF	Hexadecimal		Section 9.2.7
	Word devices	Timer*1	512 points	T0 to 511	Decimal		Section 9.2.8
		Retentive timer*1	0 points	--	Decimal		Section 9.2.9
		Counter*1	512 points	C0 to 511	Decimal		Section 9.2.10
		Data register	6144 points	D0 to 6143	Decimal		Section 9.2.11
		Link register	2048 points	W0 to 7FF	Hexadecimal		Section 9.2.12
	Link special register	1536 points	SW0 to 5FF	Hexadecimal			
Internal system devices	Bit devices	Special relay	5120 points	SM0 to 5119	Decimal	Unchangeable	Section 9.3.1
	Word devices	Special register	5120 points	SD0 to 5119	Decimal		Section 9.3.2
Nesting	--	Nesting	15 points	N0 to 14	Decimal	Unchangeable	Section 9.4
Constants	--	Decimal constants	K-2147483648 to 2147483647				Section 9.5.1
		Hexadecimal constants	H0 to FFFFFFFF				Section 9.5.2

* 1 : For the timers, retentive timers and counters, their contacts and coils are bit devices and their current values are word devices.

* 2 : Can be changed in the PLC parameter dialog box of GX Developer. (Except the input, output, step relay, link special relay and link special register.) (☞ Section 9.2)

9.2 Internal User Devices

(1) Definition

Internal user devices can be used for various user applications.

The "number of usable points" setting is designated in advance (default value) for internal user devices.

However, this setting can be changed at the "Device" tab screen in the "(PLC) Parameter" dialog box.

	Sym	Dig	Dev. point	Latch(1) start	Latch(1) end	Latch(2) start	Latch(2) end	Local dev. start	Local dev. end
Input relay	X	16	6K						
Output relay	Y	16	6K						
Internal relay	M	10	6K						
Latch relay	L	10							
Link relay	B	16	2K						
Annunciator	F	10	1K						
Link special	SB	16	1536						
Edge relay	V	10	1K						
Step relay	S	10							
Timer	T	10	512						
Retentive timer	ST	10	0K						
Counter	C	10	512						
Data register	D	10	6K						
Link register	W	16	2K						
Link special	SW	16	1536						

Device total: 12.1 K words The total number of device points is up to 12384 words.

Word device: 10.5 K words High speed area X0 - C511

Bit device: 13.5 K bits

Acknowledge XY assignment Multiple CPU settings Default Check End Cancel

Default value
For device whose number of points can be changed, number of used points can be changed.

Diagram 9.1 Device in PLC parameter dialog box

(2) Internal user device setting range

The number of used points of internal user devices other than CPU module input (X), output (Y), link special relay (SB), or link special register (SW) can be changed within the range of 9.75k words with the PLC parameter device settings.

The following gives more information.

(a) Setting range

The number of device points is designated in 16-point units.

A maximum of 32 k points can be designated for one device.

1 point is calculated as 2 points (1 for coil, 1 for contact) for the timer, retentive timer, and counter.

(3) Memory capacity

Use the following expression to obtain the memory capacity of an internal user device.

$$(\text{Bit device capacity}) + (\text{Word device capacity}) + (\text{Timer, retentive timer and counter capacity}) \leq 12384 \text{ words}$$

(a) For bit devices:

For bit devices, 16 points are calculated as 1 word.

$$(\text{Bit device capacity}) = \frac{(\text{Total number of points of X, Y, M, B, F, SB, V})}{16} \text{ (words)}$$

(b) For timer (T) retentive timer (ST), and Counter (C):

For the timer, retentive timer, and counter, 16 points are calculated as 18 words.

$$(\text{Timer, retentive, counter capacity}) = \frac{(\text{Total number of points of T, ST, C})}{16} \times 18 \text{ (words)}$$

(c) For word devices:

For data registers (D), link registers (W), and special register(SD), 16 points are calculated as 16 words.

$$(\text{Word device capacity}) = \frac{(\text{Total number of points of D, W, SD})}{16} \times 16 \text{ (words)}$$

POINT

When the number of used points of internal user devices is changed with the PLC parameters, any sequence program created with the pre-change parameters cannot be used as it is.

When the number of used points of internal user devices is changed, write the parameters and sequence program to the CPU module.

(4) Device point assignment example

A device point assignment example is shown in Table9.2.

Table9.2 Device point assignment example

Device name	Symbol	Numeric notation	Number of device points ^{*1*2}		Restriction check		
			Number of points	Number	Capacity (Word) ^{*3}		Number of bit points ^{*2}
Input relay	X	16	6k (6144) points	X0000 to 17FF	÷ 16	384 words	× 1 6144 points
Output relay	Y	16	6k (6144) points	Y0000 to 17FF	÷ 16	384 words	× 1 6144 points
Internal relay	M	10	8k (8192) points	M0 to 8191	÷ 16	512 words	× 1 8192 points
Link relay	B	16	1k (1024) points	B0000 to 03FF	÷ 16	64 words	× 1 1024 points
Annunciator	F	10	1k (1024) points	F0 to 1023	÷ 16	64 words	× 1 1024 points
Link special relay	SB	16	1.5k (1536) points	SB0000 to 05FF	÷ 16	96 words	× 1 1536 points
Edge relay	V	10	1k (1024) points	V0 to 1023	÷ 16	64 words	× 1 1024 points
Timer	T	10	1k (1024) points	T0 to 1023	× $\frac{18}{16}$	1152 words	× 2 2048 points
Retentive timer	ST	10	1k (1024) points	ST0 to 1023	× $\frac{18}{16}$	1152 words	× 2 2048 points
Counter	C	10	1k (1024) points	C0 to 1023	× $\frac{18}{16}$	1152 words	× 2 2048 points
Data register	D	10	4k (4096) points	D0 to 4095	× 1	4096 words	--
Link register	W	16	1k (1024) points	W0000 to 03FF	× 1	1024 words	--
Link special register	SW	16	1.5k (1536) points	SW0000 to 05FF	× 1	1536 words	--
Device total						11680 words (12384 words or less)	31232 points

* 1 : ☐ The hatched number of points is fixed. (Unchangeable)

* 2 : The maximum number of points of one device is 32k points.

* 3 : Enter the value that is obtained by multiplying (or dividing) the number of device points by the numeral indicated in the capacity (Word) field.

9.2.1 Input (X)

(1) Definition

Inputs transmit commands or data to the CPU module from an external device such as push-button switches, selector switches, limit switches, digital switches.




Diagram 9.2 Commands from external devices to CPU module

(2) Concept of input (X)

If the input point is the Xn virtual relay inside the CPU module, the program uses the Xn's N/O contact or N/C contact.




Diagram 9.3 Inputs(X)

(3) Number of used N/O and N/C contacts

There are no restrictions on the number of Xn N/O contacts and N/C contacts used in a program, provided the program capacity is not exceeded.




Diagram 9.4 Input(X) Used in Program

POINT

When debugging a program, an input (X) can be set to ON/OFF as described below.

- GX Developer test operation
- OUT Xn instruction




Diagram 9.5 Input(X) ON/OFF by the OUT Xn instruction

9.2.2 Output (Y)

(1) Definition

Outputs give out the program control results to the external devices such as solenoid, electromagnetic switch, signal lamp and digital display.

Outputs give out the result equivalent to one N/O contact.




Diagram 9.6 Output from CPU module to external devices

(2) Number of used N/O and N/C contacts

There are no restrictions on the number of output Yn N/O contacts and N/C contacts used in a program, provided the program capacity is not exceeded.




Diagram 9.7 Use of output (Y) in program

(3) Using outputs as internal relays (M)

An output (Y) corresponding to a region with no module mounted can be used in place of an internal relay (M).




Diagram 9.8 Substitute for internal relay

9.2.3 Internal relay (M)

(1) Definition

Internal relays are auxiliary relays used in the CPU module.

All internal relays are switched OFF at the following times:

- When the PLC is powered OFF and then ON
- When the CPU module is reset

(2) Number of used N/O and N/C contacts

There are no restrictions on the number of contacts (N/O contacts, N/C contacts) used in the program, provided the program capacity is not exceeded.




Diagram 9.9 Use of internal relays in program

(3) Procedure for external outputs

Outputs (Y) are used to output sequence program operation results to an external destination.

9.2.4 Annunciator (F)

(1) Definition

Annunciators are internal relays used for fault detection programs created by the user.

(2) Special relay and special registers at annunciator ON

When annunciators switch ON, a special relay (SM62) switches ON, and the Nos. and quantity of the annunciators which switched ON are stored at the special registers (SD62 to 79).

- Special relay : SM62 Switches ON if even one annunciator switches ON.
- Special register : SD62 No. of first annunciator which switched ON is stored here.
- SD63 The number (quantity) of annunciators which are ON is stored here.
- SD64 to 79 Annunciator Nos. are stored in the order in which they switched ON.
(The same annunciator No. is stored at SD62 and SD64.)

Annunciator numbers stored in SD62 are also recorded in the operation • error history storage area.

POINT

Even if multiple annunciators are switched ON while the PLC is power-on, only one annunciator number is stored in the operation • error history storage area. When an error is ended on a CPU module, the other annunciator numbers that are ON can be stored in the error history storage area.

(3) Applications of annunciators

Using annunciators for a fault detection program, an equipment fault or fault presence/absence (annunciator number) can be checked by monitoring the special register (SD62 to 79) when the special relay (SM62) switches ON.

Example

The program which outputs the No. of the ON annunciator (F5).




Diagram 9.10 Detection and storage of annunciator ON

(4) Number of used N/O and N/C contacts

There are no restrictions on the number of contacts (N/O contacts, NC contacts) used in the program, provided the program capacity is not exceeded.

(5) Annunciator ON procedure

(a) Annunciator ON procedure

The annunciator can be turned ON by either of the following instructions.

1) SET F□ instruction

The SET F□ instruction turns ON the annunciator only on the leading edge (OFF to ON) of the input condition.

If the input condition turns OFF, the annunciator is held ON.

The scan time can be reduced by using many annunciators, compared with the OUT F□ instruction.

2) OUT F□ instruction

The annunciator can be turned ON/OFF by the OUT F□ instruction, but it takes longer time than the SET F□ instruction since it performs processing every scan.

If the annunciator is turned OFF by the OUT F□ instruction, the RST F□ instruction must be executed. For these reasons, use the SET F□ instruction to turn ON the annunciator.



✖POINT

If switched ON by any method other than the SET F□ and OUT F□ instructions, the annunciator functions in the same way as the internal relay.

Does not switch ON at SM62, and annunciator Nos. are not stored at SD62, SD64 to 79.

(b) Processing at annunciator ON

1) Data stored at special registers (SD62 to 79)

- Nos. of annunciators which switched ON are stored in order at SD64 to 79.
- The annunciator No. which was stored at SD64 is stored at SD62.
- "1" is added to the SD63 value.




Diagram 9.11 Processing at annunciator ON

2) Processing at CPU

The "USER" LED on the module front turns ON.

(6) Annunciator OFF procedure and processing content

(a) Annunciator OFF procedure

The annunciator can be turned OFF by any of the following instructions.

1) RST F□ instruction

The RST F□ instruction turns OFF an annunciator at leading edges (OFF to ON) of the input condition.

If an annunciator is turned OFF by the RST F□ instruction, processing at annunciator OFF shown in 9.2.4(6)(b) will be performed.

2) OUT F□ instruction

Although an annunciator can be turned ON/OFF by OUT F□ instruction, it takes time longer than when using the RST F□ instruction since every scan is processed.

However, if an annunciator is switched OFF by the OUT F□ instruction, the "processing at annunciator OFF" ((6)(b) in this section) is not performed.

Execute the RST F□ instruction after the annunciator has been switched OFF by the OUT F□ instruction.




Diagram 9.12 Example of turning OFF the annunciators

Remark

Refer to the following manual for details of each instruction.

☞ QSCPU Programming Manual (Common Instructions)

(b) Processing at annunciator OFF

1) Special register (SD62 to 79) data operation when annunciator is turned OFF by executing the RST F instruction

- The annunciator No. specified by the RST instruction is deleted, and the stored annunciator Nos. after the deleted annunciator No. are shifted up.
- If the annunciator No. stored at SD64 was switched OFF, the new annunciator No. which is stored at SD64 is stored at SD62.
- 1 is subtracted from the SD63 value.
- If the SD63 value is "0", SM62 is switched OFF.




Diagram 9.13 Processing at annunciator OFF (when RST F instruction is executed)

2) LED indication

When the annunciator Nos. in SD64 to 79 all turn OFF, the "USER" LED, which was turned ON as the annunciator turned ON, turns OFF.

9.2.5 Edge relay (V)

(1) Definition

An edge relay is a device which stores the operation results (ON/OFF information) from the beginning of the ladder block.

Edge relays can only be used at contacts, and cannot be used as coils.




Diagram 9.14 Edge relay

(2) Precautions

The edge relay of the same No. cannot be set in multiple steps of a program.

9.2.6 Link relay (B)

(1) Definition

Link relays are CPU module side relays used when refreshing the link relay (LB) data of the MELSECNET/H module, etc. to the CPU module or when refreshing the CPU module data to the link relays (LB) of the MELSECNET/H module, etc.




Diagram 9.15 Link refresh

(2) Number of used N/O and N/C contacts

There are no restrictions on the number of contacts (N/O contacts, N/C contacts) used in the program.




Diagram 9.16 Link Relay

(3) Using link relays in the network system

In order to use link relays in the network system, a network parameter setting is required.

The link relay range where network parameter setting has not been made (not used by the MELSECNET/H network system, etc.) is available as the internal relays.


POINT

The MELSECNET/H module includes 16384 link relay points, while the CPU module includes 2048 points (default).

When using the link relays after the above points, change the number of link relay points in the device setting of the PLC parameter dialog box.

Remark

Refer to the following manual for the network parameters.

 Q Corresponding MELSECNET/H Network System Reference Manual
(PLC to PLC network)

9.2.7 Link special relay (SB)

(1) Definition

The link special relays show the communication status • error detection of the CC-Link Safety master module and MELSECNET/H module.

ON/OFF of the link special relays are controlled by various causes that occur during data link.

By monitoring the link special relays, the communication status, error status and others of data link can be grasped.

(2) Number of link special relay points

The number of link special relay points is as described in Table9.3.

Table9.3 Number of link special relay points of each CPU module

CPU module	Number of link special relay points
Safety CPU	1536 points (SB0 to 5FF).
	512 points are assigned to link special relays for the CC-Link Safety master module and MELSECNET/H module.
	The link special relays can be assigned as shown below.
	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> SB0 { SB1FF SB200 { SB3FF SB400 { SB5FF </div> <div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Link special relay</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">For 1st network module</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">For 2nd network module</div> <div style="border: 1px solid black; padding: 5px;">For 3rd network module</div> </div> <div style="margin-left: 10px;"> <div style="font-size: 2em;">}</div> 512 points <div style="font-size: 2em;">}</div> 512 points <div style="font-size: 2em;">}</div> 512 points <div style="font-size: 3em;">}</div> 1536 points </div> </div>

Remark

Refer to the following manual for the link special relay.



CC-Link Safety Master Module User's Manual



Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

9.2.8 Timer (T)

(1) Definition

A timer (T) is a device that starts counting when its coil turns ON, and times-out and turns ON its contact when the current value reaches or exceeds the set value.

The timer is of an up-counting type.

The current value matches the set value when a "time-out" occurs.

(2) Timer types

There are two types of timers: a low/high speed that allows the current value to return to "0" when a timer coil switches OFF, and a retentive timer that retains the current value even when a timer coil switches OFF.




Diagram 9.17 Timer types

(3) How to use timers

With a timer setting (instruction format), a device is assigned for a low speed timer or high speed timer. The OUT T0 instruction is used to assign a device for a low -speed timer. The OUTH T0 instruction is used to assign a device for a high speed timer.

With a timer setting (instruction format), a device is assigned for a low speed retentive timer or high speed retentive timer. The OUT T0 instruction is used to assign a device for a low speed retentive timer. The OUTH T0 instruction is used to assign a device for a high speed retentive timer.

(4) Low-speed timers


(a) Definition

Low-speed timers perform counting in 1 to 1000ms units.

The timer is valid only while its coil is ON.

The time measurement begins when the timer's coil switches ON, and the contact switches ON when a "time-out" occurs. When the timer's coil switches OFF, the current value becomes "0", and the contact switches OFF.

[Ladder example]



[Time chart]




Diagram 9.18 Ladder example and timing chart of low-speed timer

(b) Measurement units

The default time measurement units setting for low speed timers is 100 ms. The time measurement units setting can be designated in 1 ms units within a 1 ms to 1000 ms range.

This setting is designated at the "PLC system" tab screen in the "(PLC) Parameter" dialog box.

(5) High-speed timers


(a) Definition

High-speed timers performs counting in 0.1 to 100ms units.

The timer is valid only while its coil is ON, and has a symbol "H".

The time measurement begins when the timer's coil switches ON, and the contact switches ON when the time elapses. When the timer's coil switches OFF, the current value becomes "0", and the contact switches OFF.

[Ladder example]



[Time chart]




Diagram 9.19 Ladder example and timing chart of high-speed timer

(b) Measurement units

The default time measurement units setting for high speed timers is 10 ms.

The time measurement units setting can be designated in 0.1ms units within a 0.1 ms to 100 ms range.

This setting is designated at the "PLC system" tab screen in the "(PLC) Parameter" dialog box.

(6) Retentive timers

(a) Definition

Retentive timers measure the "coil ON" time.

The measurement begins when the timer coil switches ON, and the contact switches ON when a time-out (coil OFF) occurs.

Even when the timer coil is OFF, the current value and the contact ON/OFF status are saved. When the coil is switched ON again, the time measurement resumes from the current value which was saved.


(b) Retentive timer types

There are 2 retentive timer types: low speed retentive timer, and high speed retentive timer.

(c) Retentive timer clear

The RST ST \square instruction is used to clear (reset) the current value and switch the contact OFF.

[Ladder example]



[Time chart]




Diagram 9.20 Ladder example and timing chart of retentive timer

(d) Measurement units

The measurement units settings for retentive timers are the same as those for low speed timers and high speed timers.

- Low speed retentive timer : Same as low speed timer
- High speed retentive timer : Same as high speed timer

POINT


In order to use retentive timers, a retentive timer "number of points used" setting must be designated at the "Device" tab screen in the "(PLC) Parameter" dialog box.

(7) Timer Processing and accuracy

(a) Processing method

When an OUT T□ instruction is executed, the following is processed: timer coil ON/OFF, current value update and contact ON/OFF processing. Timer current value update and contact ON/OFF processing are not performed at END processing.

[Ladder example]



[Processing at execution of OUT T0 instruction]





Diagram 9.21 Processing at execution of OUT T0 instruction

(b) Accuracy


Measured value at END instruction is added to the current value when the OUT T \square instruction is executed.

If the timer coil is OFF when the OUT T \square instruction is executed, the current value is not updated.

[Ladder example]



[Current value update timing]



(8) Precautions for using timers

The following are a few precautions regarding timer use:

(a) Use of the same timer

A given timer cannot be designated (by OUT T□) more than once in a single scan.

This designation results in measurement, since the timer current value is updated at execution of each OUT T□ instruction.




Diagram 9.23 When the same timer is used

(b) When set value is 0

If the timer set value is "0", the contact turns ON when the OUT T□ instruction is executed.

(c) When set value is changed after time-out

If the set value changes to a value which is higher than the current value following a timer "time-out", the "time-out" status will remain in effect, and timer operation will not be performed.

9.2.9 Counter (C)

(1) Definition

A counter is a device which counts the number of input condition leading edges in sequence programs.

When the count value matches the set value, the counter counts up and its contact turns ON.

The counter is of an up-counting type.

(2) Count processing

(a) When OUT C□ instruction is executed

When an OUT C□ instruction is executed, the following counter processing occurs: coil ON/OFF, current value update (count value + 1), and contact ON/OFF. Counter current value update and contact ON/OFF processing are not performed at END processing.





Diagram 9.24 Execution and processing of OUT C□ instruction

(b) Current value update (count value + 1)

The current value update (count value + 1) is performed at the leading edge (OFF to ON) of the OUT C□ instruction.

The current value is not updated in the following OUT C□ instruction statuses: OFF, ON to ON, ON to OFF

[Ladder example]



[Current value update timing]





Diagram 9.25 Current value update timing

(c) Resetting the counter

Counter current values are not cleared even if the OUT C□ instruction switches OFF. Use the RST C□ instruction to clear the counter's current value and switch the contact OFF.

The count value is cleared and the contact is switched OFF at execution of when the RST C□ instruction.

[Ladder example]



[Counter reset timing]




Diagram 9.26 Counter resetting

1) Precautions for resetting the counter

When the RST C□ instruction is executed, the coil of C□ also turns OFF.

If the execution condition of the OUT C□ instruction is still ON after execution of the RST C□ instruction, the coil of C□ is turned ON at the execution of the OUT C□ instruction to update the current value (increment the count value by 1).

[Ladder example]




Diagram 9.27 Counter resetting ladder example

In the above ladder example, when M0 turns from OFF to ON, the coil of C0 turns ON, updating the current value. When C0 reaches the preset value finally, the contact of C0 turns ON, and the execution of the RST C0 instruction clears the current value of C0. At this time, the coil of C0 also turns OFF. When M0 is still ON in the next scan, the current value is updated since the coil of C0 turns from OFF to ON at the execution of the OUT C0 instruction. (The current value turns to 1.)




Diagram 9.28 Current value update timing

To prevent the above, it is recommended to insert the N/C contact of the OUT C0 instruction as the execution condition of the RST C0 instruction so that the coil of C0 does not turn OFF while the execution condition (M0) of the OUT C0 instruction is ON.




Diagram 9.29 Counter resetting ladder example (recommended example)

(d) Maximum counting speed

The counter can count only when the input condition ON/OFF time is longer than the execution interval of the corresponding OUT C□ instruction.

The maximum counting speed is calculated by the following expression:

$$\text{Maximum counting speed (Cmax)} = \frac{n}{100} \times \frac{1}{T} \text{ [times/s]}$$

n: Duty(%)^{*1}

T: Execution interval of the OUT C□ instruction (sec)

* 1 : The "duty" is the count input signal's ON-OFF time ratio expressed as a percentage value.

- When $T1 \geq T2$, $n = \frac{T2}{T1+T2} \times 100\%$
- When $T1 < T2$, $n = \frac{T1}{T1+T2} \times 100\%$




Diagram 9.30 Duty ratio

9.2.10 Data register (D)

(1) Definition

Data registers are memory devices which store numeric data (-32768 to 32767, or 0000H to FFFFH).

(2) Bit configuration of data register

(a) Bit configuration and read and write units

Data registers, which consist of 16 bits per point, read and write data in 16-bit units.




Diagram 9.31 Bit configuration of data register

POINT

Data register data are handled as signed data.

For HEX (hexadecimal), 0000H to FFFFH can be stored. However, since the most significant bit is a sign bit, the range of a value that can be specified is -32768 to 32767.

(b) When data register is used for 32-bit instruction

If the data registers are used for 32-bit instructions, the data will be stored in registers Dn and Dn + 1. The lower 16 bits of data are stored at the data register No. (Dn) designated in the sequence program, and the higher 16 bits of data are stored in the designated register No. + 1 (Dn + 1). For example, if register D12 is designated in the DMOV instruction, the lower 16 bits are stored in D12, and the upper 16 bits are stored in D13.




Diagram 9.32 Data transfer by 32-bit instruction and storage destination

Two data registers can store a range of numeric data from -2147483648 to 2147483647 or from 0H to FFFFFFFFH. (The most significant bit in a 32-bit configuration is a sign bit.)

(3) Holding of stored data

The data stored in the data register is held until the other data is stored.

The data stored in the data register is initialized when the PLC is powered OFF or the CPU module is reset.

9.2.11 Link register (W)

(1) Definition

A link register is the CPU module memory used to refresh the CPU module with data from the link registers (LW) of MELSECNET/H module.




Diagram 9.33 Link refresh

Link registers are used to store numeric data (-32768 to 32767, or 0000H to FFFFH).

(2) Bit configuration of link register

(a) Bit configuration and read and write units

Link registers, which consist of 16 bits per point, read and write data in 16 bit units.




Diagram 9.34 Bit configuration of link register

POINT

1. Link register data are handled as signed data.
For HEX (hexadecimal), 0000H to FFFFH can be stored. However, since the most significant bit is a sign bit, the range of a value that can be specified is -32768 to 32767.
2. When used outside the MELSECNET/H system's range, link registers can serve as data registers.

(b) When link register is used for 32-bit instruction

If the link registers are used for 32-bit instructions, the data is stored in registers W_n and $W_n + 1$. The lower 16 bits of data are stored in the link register No. (W_n) designated in the sequence program, and the higher 16 bits of data are stored in the designated register No. + 1 ($W_n + 1$).

For example, if link register W_{12} is designated in the DMOV instruction, the lower 16 bits are stored in W_{12} , and the upper 16 bits are stored in W_{13} .




Diagram 9.35 Data transfer by 32-bit instruction and storage destination

Two link registers can store a range of numeric data from -2147483648 to 2147483647 or from 0H to FFFFFFFFH. (The most significant bit in a 32-bit configuration is a sign bit.)

(3) Holding of stored data

Data stored by the link register is maintained until another data is save.

The data stored in the link register is initialized when the PLC is powered OFF or the CPU module is reset.

POINT

The MELSECNET/H module includes 16384 link register points , while the CPU module includes 2048 points (default).

When using the link registers after the above points, change the number of link register points in the device setting of the PLC parameter dialog box.

(4) Using link registers in a network system

In order to use link registers in the network system, network parameter settings must be made.

Link registers not set in the network parameter settings can be used as data registers.

Remark

Refer to the following manual for the network parameters.

☞ Q Corresponding MELSECNET/H Network System Reference Manual
(PLC to PLC network)

9.2.12 Link special register (SW)

(1) Definition

The link special register stores the CC-Link Safety master module and MELSECNET/H module communication status • error definition.

Because the data link information is stored as numeric data, the link special registers serve as a tool for identifying the locations and causes of faults.

(2) Number of link special register points

The number of link special register points is as described in Table9.4.

Table9.4 Number of link special register points of each CPU module

CPU module	Number of link special relay points
Safety CPU	1536 points (SW0 to 5FF).
	512 points are assigned to each CC-Link Safety master module and MELSECNET/H module.
	The link special registers can be assigned as shown below.
	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> SW0 ⋮ SW1FF SW200 ⋮ SW3FF SW400 ⋮ SW5FF </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> Link special register For the 1st network module For the 2nd network module For the 3rd network module </div> <div style="margin-left: 10px;"> 512 points 512 points 512 points 1536 points </div> </div>

Remark

Refer to the following manual for the link special register.

☞ CC-Link Safety Master Module User's Manual

☞ Q Corresponding MELSECNET/H Network System Reference Manual
(PLC to PLC network)

9.3 Internal System Devices

Internal system devices are used for system operations.

The allocations and sizes of internal system devices are fixed, and cannot be changed by the user.

9.3.1 Special relay (SM)

(1) Definition

Special relay stores the CPU module states (error diagnostics, system information, etc.).

(2) Special relay classifications

Special relays are classified according to their applications, as shown in Table9.5.

Table9.5 Special relay classification list

Classification	Special relay
Diagnostics information	SM0 to 99
System information	SM200 to 399
System clock/system counter	SM400 to 499
Safety CPU	SM560 to 599
Boot	SM600 to 699
Instruction related	SM700 to 799
CC-Link Safety	SM1000 to 1299

(3) Special relay that can be used in the program that achieves the safety function

In the program that achieves the safety function, only SM1000 to SM1299 can be used.

Remark

For details on special relays which can be used by the CPU module, refer to Appendix 1.

9.3.2 Special register (SD)

(1) Definition

A special register is used to store CPU module status data (error diagnostics and system information).

(2) Special register classifications

Special registers are classified according to their applications, as shown in Table9.6.

Table9.6 Special register classification list

Classification	Special register
Diagnostics information	SD0 to 99
System information	SD200 to 399
System clock/system counter	SD400 to 499
Scan information	SD500 to 559
Safety CPU	SD560 to 599
Memory	SD600 to 699
CC-Link Safety	SD1000 to 1299

(3) Special register that can be used in the program that achieves the safety function

In the program that achieves the safety function, only SD1000 to SD1299 can be used.

Remark

For details on special relays refer to Appendix 2.

9.4 Nesting (N)

(1) Definition

Nesting is a device used in the master control instruction (MC instruction, MCR instruction) to program operation conditions in a nesting structure.

(2) Specifying method in master control instruction

The master control instruction opens/closes a common ladder bus to create a sequence program of efficient ladder switching.

Specify nesting in ascending order (in order of N0 to N14), starting from the outside of the nesting structure.

Refer to the following manual for how to use nesting.

☞ QSCPU Programming Manual (Common Instructions)




Diagram 9.36 Program example using nesting

9.5 Constants

9.5.1 Decimal constant (K)

(1) Definition

Decimal constants are devices that designate decimal data in sequence programs.

Specify it as K□□ (example: K1234) in a sequence program.

It is stored in binary (BIN) into the CPU module. (☞ Section 3.7.1)

(2) Designation range

The designation ranges for decimal constants are as follows:

- For word data (16 bits).....K-32768 to 32767
- For 2-word data (32 bits)K-2147483648 to 2147483647

☒ POINT

The most significant bit is a sign bit.

9.5.2 Hexadecimal constant (H)

(1) Definition

Hexadecimal constants are devices which designate hexadecimal or BCD data in sequence programs.

(For BCD data designations, 0 to 9 digit designations are used.)

Hexadecimal constants are designated as "H□□ " settings (e.g. H1234).

(☞ Section 3.7.2)

(2) Designation range

The setting ranges for hexadecimal constants are as follows:

- For word data (16 bits).....H0 to FFFF
(H0 to 9999 for BCD)
- For 2-word data (32 bits)H0 to FFFFFFFF
(H0 to 99999999 for BCD)

CHAPTER10 CPU MODULE PROCESSING TIME

This chapter explains the CPU module processing time.

10.1 Scan Time


This section explains the scan time structures and CPU module processing time.

10.1.1 structure and calculation of scan time

(1) Scan time structure

The CPU module scan time consists of the followings processings.

The CPU module performs the following processings cyclically in the RUN status.



* 1 : Program end indicates the timing when the END, S.QS ABORT instruction is executed.

* 2 : Indicates a calendar update or error clear.

Diagram 10.1 Scan time structure Safety CPU

(2) Calculation of scan time

The scan time is calculated from the following formula.

$$SM = Tru + Tio + Tie + Tend + Ts + Tc \text{ (ms)}$$

- SM : Scan time
- Tru : Module refresh time
- Tio : I/O refresh time
- Tie : Instruction execution time
- Tend: Execution time for each function processed by the END
- Ts : Service processing time
- Tc : Common processing time

10.1.2 Time required for each processing included in scan time

This section explains how to calculate the processing and execution times shown in Section 10.1.1.

(1) Module refresh time

The module refresh time is the total of the time for the auto refresh of the MELSECNET/H and the CC-Link Safety set with the network parameters.

(a) Refresh of MELSECNET/H

This indicates the time taken to refresh data between the link devices of the MELSECNET/H network and those of the CPU module.

The refresh time (Tmnet) of MELSECNET/H is calculated from the following formula.

$$Tmnet = 1.85 \times (\text{number of refresh words}) + 1000 \text{ (}\mu\text{s)}$$

Refer to the following manual for the number of refresh words.

☞ Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

(b) Auto refresh of CC-Link

This indicates the time taken to refresh data between the CC-Link Safety master module and CPU module.

Refer to the following manual for the auto refresh time of CC-Link Safety.

☞ CC-Link Safety System Master Module User's Manual

(2) I/O refresh time

The I/O refresh time is the refresh time for I/O data between the CC-Link Safety master module and MELSECNET/H module.

I/O refresh time (Tio) is calculated from the following formula.

$$Tio = (\text{number I/O points}) \times 0.224 + 310 \text{ (}\mu\text{s)}$$

(3) Instruction execution time

The instruction execution time is the sum of processing times of the instructions used in the program to be executed by the CPU module.

Refer to the following manual for the processing time of each instruction.

 QSCPU Programming Manual (Common Instructions)

(4) Execution time of various functions processed at END

The execution time for each function processed with END is the total of the time required for reading out the clock data and error ending.

(a) Reading out the clock data processing time

This is the time for reading out the clock data in END processing when a clock data read request (SM213 ON) is executed.

Table10.1 Calendar update processing time

CPU module	When clock data read request is issued
QS001CPU	0.02ms

(b) Error clear processing

This indicates the time taken to clear the continuation error stored in SD50 when SM50 (error clear) rises (changes from OFF to ON).

Table10.2 Error clear processing time

CPU module	Error clear processing time
QS001CPU	0.13ms

(5) Service processing time

Service processing indicates the processing for communication with GX Developer

- Monitor by GX Developer

This indicates the processing time taken to execute monitor by GX Developer.

Table10.3 Monitor processing time by GX Developer

Function	QS001CPU
Read of program from PLC ^{*1}	1.4ms
Device monitor ^{*2}	1.0ms
Online change ^{*3}	4.0ms
Operation/error history display ^{*4}	6.1ms

* 1 : Time taken to read an 8k-step program from the program memory.

* 2 : Time taken when 32 points have been set in registration monitor.

* 3 : Time taken when a 100-step ladder is added.

* 4 : Time taken to update the display, specifying [All log].

(6) Common processing time

This indicates the processing time common to the CPU modules.

Table10.4 shows the common processing time for each CPU module model.

Table10.4 Common processing time

CPU module	Common processing time
QS001CPU	6.2 to 8.2ms

10.1.3 Factors that increase the scan time

When the following functions or operations are performed, this will increase the scan time of the CPU module.

When executing any of them, make sure to allow for the processing time (the value given in this section to the value calculated in Section 10.1.2).

(1) Online change executed in ladder mode

The scan time increases by the value indicated in Table10.5 after online change.

Table10.5 Increased time when online change is in ladder mode

CPU module model name	Allocate memory for online change	
	No change	Re-setting
QS001CPU	Max. 1.7ms	Max. 36ms

(2) Functions that increase scan time

The scan time also increases by use of the following functions.

- System monitor
- General data processing

(3) Self-diagnostics executed in certain cycle


The CPU module has the self-diagnostics processing in a certain cycle (10ms) regardless of the scan.

Table10.6 Processing time for self-diagnostics in a certain cycle


CPU module model name	Processing time
QS001CPU	0.2 to 3.0ms

Therefore, scan time changes due to processing time for self-diagnostics processing in a certain cycle.

When scan time calculated from calculating formula in Section 10.1.1 is 15ms, change of scan time due to self-diagnostics processing in a certain cycle is shown in Diagram 10.2.



(a) When the processing time for self-diagnostics processing in a certain cycle is maximum



(b) When the processing time for self-diagnostics processing in a certain cycle is minimum

Diagram 10.2 Change of scan time due to processing time for self-diagnostics processing in a certain cycle

10.2 Other Processing Times

This section explains the processing times other than those described in Section 10.1.

(1) Constant scan accuracy

Table10.7 indicates the constant scan accuracy.

Table10.7 Constant scan accuracy

CPU module	Constant scan accuracy
QS001CPU	2ms

With monitor : Indicates the status in which monitor is being executed with GX Developer connected.


Without monitor : Indicates the status in which monitor is not executed by GX Developer.

CHAPTER 11 PROCEDURE FOR WRITING PROGRAM TO CPU MODULE

This chapter describes the procedure for writing program created at the GX Developer to the CPU module.

The CPU module startup procedure is not described in this manual.


Refer to the following manuals for the CPU module startup procedure.

 QSCPU User's Manual (Hardware Design, Maintenance and Inspection)


11.1 Items to be examined for program creation

To create a program with the CPU module, the program capacity, the number of device points used, etc. must be determined in advance.

(1) Program size considerations

Consider whether a program can be stored within the program capacity that can be executed with CPU modules (14 k steps) or not. ( Section 5.3.3)



(2) Applications of devices and setting of their numbers of points

Consider the applications of the devices used in a program and their number of points. ( CHAPTER 9)

(3) Boot operation considerations

When boot operation is executed in TEST MODE, set the PLC parameter boot file settings.

(In SAFETY MODE, execute boot run regardless of the PLC parameter boot file settings.)



( Section 5.1.4,  Section 11.3)


11.2 Procedure for writing program


This section explains the procedure for writing the parameters and program created by GX Developer to the CPU module.

This section explains the procedure for writing a program to the program memory (☞ Section 5.1.2).


When storing a program in standard ROM and booting in TEST MODE, execute the procedure in 11.3 after executing the procedure in this item.

Procedural steps shown in  boxes are performed at the GX Developer, and those shown in  boxes are performed in the CPU module.





Write to PLC screen



QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

QSCPU User's Manual (Hardware Design, Maintenance and Inspection)

Diagram 11.1 Flowchart for writing program

11.3 Boot run procedure

This section explains a boot run procedure.

In the following procedure, □ indicates the operation on the GX Developer side, and □ indicates that on the CPU module side.




Diagram 11.2 Boot run flowchart

APPENDICES

Appendix 1 Special Relay List

Special relays, SM, are internal relays whose applications are fixed in the PLC.

For this reason, they cannot be used by sequence programs in the same way as the normal internal relays.

However, they can be turned ON or OFF as needed in order to control the CPU module and remote I/O modules.

The heading descriptions in the following special relay lists are shown in TableApp.1.

TableApp.1 Descriptions of the special relay lists headings

Item	Function of Item
Number	• Indicates special register number
Name	• Indicates name of special register
Meaning	• Indicates contents of special register
Explanation	• Discusses contents of special register in more detail
Set by (When set)	<p>• Indicates whether the relay is set by the system or user, and, if it is set by the system, when setting is performed.</p> <p><Set by></p> <p>S : Set by system</p> <p>U : Set by user (sequence programs or test operations from GX Developer)</p> <p>S/U : Set by both system and user</p> <p><When set></p> <p>Indicated only for registers set by system</p> <p>Every END : Set during every END processing</p> <p>Initial : Set only during initial processing (when power supply is turned ON, or when going from STOP to RUN)</p> <p>Status change : Set only when there is a change in status</p> <p>Error : Set when error occurs</p> <p>Instruction execution : Set when instruction is executed</p> <p>Request : Set only when there is a user request (through SM, etc.)</p>

For details on the following items, refer to the following manuals:

- Networks → CC-Link Safety Master Module User's Manual
- Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

POINT

In the program that achieves the safety function, only SM1000 to SM1299 can be used.

Special relay other than SM1000 to SM1299 cannot be used in the program that achieves the safety function.

(1) Diagnostic Information

TableApp.2 Descriptions of the special relay headings

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM0	Diagnostic errors	OFF : No error ON : Error	<ul style="list-style-type: none"> Turns ON when an error is detected by diagnostics (Includes when an annunciator is ON) Remains ON if the condition is restored to normal thereafter. 	S (Error)	QS
SM1	Self-diagnosis error	OFF : No self-diagnosis errors ON : Self-diagnosis	<ul style="list-style-type: none"> Turns ON when an error is detected by self-diagnostics (Does not include when an annunciator is ON) Remains ON if the condition is restored to normal thereafter. 	S (Error)	
SM5	Error common information	OFF : No error common information ON : Error common information	<ul style="list-style-type: none"> When SM0 is ON, ON if there is error common information 	S (Error)	
SM16	Error individual information	OFF : No error individual information ON : Error individual information	<ul style="list-style-type: none"> When SM0 is ON, ON if there is error individual information 	S (Error)	
SM50	Error reset	OFF → ON: Error reset	<ul style="list-style-type: none"> Conducts error reset operation 	U	
SM51	Battery low latch	OFF : Normal ON : Battery low	<ul style="list-style-type: none"> ON if battery voltage at CPU module or memory card drops below rated value. Remains ON if the battery voltage returns to normal thereafter. Synchronous with BAT. LED 	S (Error)	
SM52	Battery low	OFF : Normal ON : Battery low	<ul style="list-style-type: none"> Same as SM51, but goes OFF subsequently when battery voltage returns to normal. 	S (Error)	
SM53	AC DOWN detection	OFF : AC DOWN not detected ON : AC DOWN detected	<ul style="list-style-type: none"> Turns ON if an instantaneous power failure of within 20ms occurs during use of the AC power supply module. Reset when the power supply is switched OFF, then ON. 	S (Error)	
SM56	Operation error	OFF : Normal ON : Operation error	<ul style="list-style-type: none"> ON when operation error is generated Remains ON if the condition is restored to normal thereafter. 	S (Error)	
SM61	I/O module verify error	OFF : Normal ON : Error	<ul style="list-style-type: none"> Turns ON if the I/O module differs from the status registered at power on. Remains ON if the condition is restored to normal thereafter. 	S (Error)	
SM62	Annunciator detection	OFF : Not detected ON : Detected	<ul style="list-style-type: none"> Goes ON if even one annunciator F goes ON. 	S (Instruction execution)	










(2) System information

TableApp.3 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM203	STOP contact	STOP status	• Goes ON at STOP status	S (Status change)	QS
SM213	Clock data read request	OFF : Ignored ON : Read request	• When this relay is ON, clock data is read to SD210 to SD213 as BCD values.	U	
SM232	Number of writes to ROM	OFF : Within the number of writes ON : Over the number of writes	• Turns ON when the number of writes to ROM exceeds 100,000.	S (Error)	

(3) System clocks/counters

TableApp.4 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM400	Always ON	ON _____ OFF	• Normally is ON	S (Every END)	QS
SM401	Always OFF	ON _____ OFF _____	• Normally is OFF	S (Every END)	
SM402	After RUN, ON for 1 scan only	ON  OFF 	• After RUN, ON for 1 scan only.	S (Every END)	
SM403	After RUN, OFF for 1 scan only	ON  OFF 	• After RUN, OFF for 1 scan only.	S (Every END)	
SM410	0.1 second clock		• Repeatedly changes between ON and OFF at each designated time interval. • When PLC power supply is turned OFF or a CPU module reset is performed, goes from OFF to start.	S (Status change)	
SM411	0.2 second clock				
SM412	1 second clock				
SM413	2 second clock				
SM414	2n second clock		• This relay alternates between ON and OFF at intervals of the time (unit: s) specified in SD414. • When PLC power supply is turned OFF or a CPU module reset is performed, goes from OFF to start.	S (Status change)	

(4) Safety CPU

TableApp.5 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM560	TEST MODE flag	OFF : Other than TEST MODE ON : TEST MODE	<ul style="list-style-type: none"> Turns ON when operating on the TEST MODE. Turns OFF when operating on the other mode (SAFETY MODE, SAFETY MODE (wait-for-restart)). 	S (Status change)	QS
SM561	Continuous RUN of tolerance time setting for the TEST MODE	OFF : Within the setting time ON : Over the setting time	• Turns ON when the continuous RUN of tolerance time set for the TEST MODE in the parameter is exceeded.	S (Error)	

(5) Boot operation

TableApp.6 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM660	Boot operation	OFF : Program memory execution ON : During boot operation	(On the TEST MODE) • Turns ON during the boot operation from standard ROM. • Turns OFF when the boot operation from standard ROM is not run. (On the SAFETY MODE) • Always ON	S (Initial)	QS

(6) Instruction-Related Special Relays

TableApp.7 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM722	BIN/DBIN instruction error disabling flag	OFF : Error detection performed ON : Error detection not performed	• Turned ON when "OPERATION ERROR" is suppressed for BIN or DBIN instruction.	U	QS

(7) CC-Link Safety

TableApp.8 Special relay

Number	Name	Meaning	Explanation	Set by (When Set)	Corresponding CPU
SM1004	Safety station refresh communication status (Safety master module 1)	OFF : Nomal ON : Communication error	The safety station refresh communication status is stored. (The status of each station are stored in SD1004 to SD1007.)	S (Status change)	QS
SM1204	Safety station refresh communication status (Safety master module 2)	OFF : Nomal ON : Communication error	The safety station refresh communication status is stored. (The status of each station are stored in SD1204 to SD1207.)	S (Status change)	

Appendix 2 Special Register List

The special registers, SD, are internal registers with fixed applications in the PLC. For this reason, it is not possible to use these registers in sequence programs in the same way that normal registers are used. However, data can be written as needed in order to control the CPU modules and remote I/O modules. Data stored in the special registers are stored as BIN values if no special designation has been made to the contrary.

The heading descriptions in the following special register lists are shown in TableApp.9.

TableApp.9 Descriptions of the special register list headings

Item	Function of Item
Number	• Indicates special register number
Name	• Indicates name of special register
Meaning	• Indicates contents of special register
Explanation	• Discusses contents of special register in more detail
Set by (When set)	<ul style="list-style-type: none"> • Indicates whether the relay is set by the system or user, and, if it is set by the system, when setting is performed. <p><Set by></p> <ul style="list-style-type: none"> S : Set by system U : Set by user (sequence programs or test operations from GX Developer) S/U : Set by both system and user <p><When set></p> <p>Indicated only for registers set by system</p> <ul style="list-style-type: none"> Every END : Set during every END processing Initial : Set only during initial processing (when power supply is turned ON, or when going from STOP to RUN) Status change : Set only when there is a change in status Error : Set when error occurs Instruction execution : Set when instruction is executed Request : Set only when there is a user request (through SM, etc.) Writing to ROM : Set when writing to ROM

For details on the following items, refer to the following manuals:

- Networks → CC-Link Safety Master Module User's Manual
→ Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

POINT

In the program that achieves the safety function, only SD1000 to SD1299 can be used.

Special register other than SD1000 to SD1299 cannot be used in the program that achieves the safety function.

(1) Diagnostic Information

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD0	Diagnostic errors	Diagnosis error code	<ul style="list-style-type: none">Error codes for errors detected by diagnostics are stored as BIN data.Contents identical to latest fault history information.	S (Error)	QS
SD1	Clock time for diagnosis error occurrence	Clock time for diagnosis error occurrence	<ul style="list-style-type: none">Stores the year (last two digits) and month when SD0 data was updated as BCD 2-digit code. <div><div>b15 to b8</div><div>b7 to b0</div><div>(Example) September, 2006</div><div>Year (0 to 99) Month (1 to 12)</div><div>H0609</div></div>	S (Error)	
SD2			<ul style="list-style-type: none">Stores the day and hour when SD0 data was updated as BCD 2-digit code. <div><div>b15 to b8</div><div>b7 to b0</div><div>(Example) 10 a.m. on 25th</div><div>Day (1 to 31) Hour (0 to 23)</div><div>H2510</div></div>		
SD3			<ul style="list-style-type: none">Stores the minute and second when SD0 data was updated as BCD 2-digit code. <div><div>b15 to b8</div><div>b7 to b0</div><div>(Example) 35 min. 48 sec.</div><div>Minutes (0 to 59) Seconds (0 to 59)</div><div>H3548</div></div>		
SD4	Error information categories	Error information category code	<p>Category codes to identify what type of error information is stored in the common information (SD5 to SD15) or in the individual information (SD16 to SD26).</p> <div><div><div>b15 to b8</div><div>Individual information category codes</div></div><div><div>b7 to b0</div><div>Common information category codes</div></div></div> <ul style="list-style-type: none">The common information category codes store the following codes: 0 : No error 1: Module No./Base No. 2: File name/Drive name 3: Time (value set) 4: Program error location 9: CC-Link Safety information 10: Module No./Station No.The individual information category codes store the following codes: 0: No error 2: File name/Drive name 3: Time (value actually measured) 4: Program error location 5: Parameter number 6: Annunciator (F) number 9: Error information 10: CC-Link Safety information 11: Program abort information 12: File diagnostics information	S (Error)	

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD5	Error common information	Error common information	<div><div><div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><div></div><div></div></div><div><</div></div></div></div>		

Remark

*3 : Extensions are shown in TableApp.11.

TableApp.11 Extension name

SDn	SDn+1		Extension name	File type
	Higher 8 bits	Lower 8 bits		
51H	50H	41H	QPA	Parameters
51H	50H	47H	QPG	Sequence program
51H	43H	44H	QCD	Device comment

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																						
SD5	Error common information	Error common information	3) Time (value set) <table><tr><th>Number</th><th>Meaning</th></tr><tr><td>SD5</td><td>Time : 1μs units (0 to 999μs)</td></tr><tr><td>SD6</td><td>Time : 1ms units (0 to 65535ms)</td></tr><tr><td>SD7</td><td rowspan="9">(Empty)</td></tr><tr><td>SD8</td></tr><tr><td>SD9</td></tr><tr><td>SD10</td></tr><tr><td>SD11</td></tr><tr><td>SD12</td></tr><tr><td>SD13</td></tr><tr><td>SD14</td></tr><tr><td>SD15</td></tr></table>	Number	Meaning	SD5	Time : 1μs units (0 to 999μs)	SD6	Time : 1ms units (0 to 65535ms)	SD7	(Empty)	SD8	SD9	SD10	SD11	SD12	SD13	SD14	SD15	S (Error)	QS						
Number			Meaning																								
SD5			Time : 1μs units (0 to 999μs)																								
SD6			Time : 1ms units (0 to 65535ms)																								
SD7			(Empty)																								
SD8																											
SD9																											
SD10																											
SD11																											
SD12																											
SD13																											
SD14																											
SD15																											
SD6																											
SD7			4) Program error location <table><tr><th>Number</th><th>Meaning</th></tr><tr><td>SD5</td><td rowspan="4">File name (ASCII code: 8 characters)</td></tr><tr><td>SD6</td></tr><tr><td>SD7</td></tr><tr><td>SD8</td></tr><tr><td>SD9</td><td>Extension *3 2EH(.)</td></tr><tr><td>SD10</td><td>(ASCII code: 3 characters)</td></tr><tr><td>SD11</td><td>(Empty)</td></tr><tr><td>SD12</td><td>Block No. *4</td></tr><tr><td>SD13</td><td>Step No. *4</td></tr><tr><td>SD14</td><td>Sequence step No. (L)</td></tr><tr><td>SD15</td><td>Sequence step No. (H)</td></tr></table>	Number	Meaning	SD5	File name (ASCII code: 8 characters)	SD6	SD7	SD8	SD9	Extension *3 2EH(.)	SD10	(ASCII code: 3 characters)	SD11	(Empty)	SD12	Block No. *4	SD13			Step No. *4	SD14	Sequence step No. (L)	SD15	Sequence step No. (H)	
Number	Meaning																										
SD5	File name (ASCII code: 8 characters)																										
SD6																											
SD7																											
SD8																											
SD9	Extension *3 2EH(.)																										
SD10	(ASCII code: 3 characters)																										
SD11	(Empty)																										
SD12	Block No. *4																										
SD13	Step No. *4																										
SD14	Sequence step No. (L)																										
SD15	Sequence step No. (H)																										
SD8																											
SD9	*4: "0" is stored to the block number and the step number. 9) CC-Link Safety information <table><tr><th>Number</th><th>Meaning</th></tr><tr><td>SD5</td><td>Error classification*5</td></tr><tr><td>SD6</td><td>Error item*5</td></tr><tr><td>SD7</td><td>Link ID</td></tr><tr><td>SD8</td><td>Station No.</td></tr><tr><td>SD9</td><td>System area 1</td></tr><tr><td>SD10</td><td>System area 2</td></tr><tr><td>SD11</td><td>System area 3</td></tr><tr><td>SD12</td><td>System area 4</td></tr><tr><td>SD13</td><td>System area 5</td></tr><tr><td>SD14</td><td>System area 6</td></tr><tr><td>SD15</td><td>System area 7</td></tr><tr><td>SD16</td><td>System area 8</td></tr></table>	Number	Meaning	SD5	Error classification*5	SD6	Error item*5	SD7	Link ID	SD8	Station No.	SD9	System area 1	SD10	System area 2	SD11	System area 3	SD12	System area 4	SD13	System area 5	SD14	System area 6	SD15	System area 7	SD16	System area 8
Number	Meaning																										
SD5	Error classification*5																										
SD6	Error item*5																										
SD7	Link ID																										
SD8	Station No.																										
SD9	System area 1																										
SD10	System area 2																										
SD11	System area 3																										
SD12	System area 4																										
SD13	System area 5																										
SD14	System area 6																										
SD15	System area 7																										
SD16	System area 8																										
SD10																											
SD11	*5: The error classification and error item are stored only when the error code is 8300 (CC-LINK REMOTE DETECTION ERROR). 0 is stored when the error coad is other than 8300.																										
SD12	10) Module No./Station No. <table><tr><th>Number</th><th>Meaning</th></tr><tr><td>SD5</td><td>Slot No.</td></tr><tr><td>SD6</td><td>I/O No.</td></tr><tr><td>SD7</td><td>Station No.</td></tr><tr><td>SD8</td><td rowspan="8">(Empty)</td></tr><tr><td>SD9</td></tr><tr><td>SD10</td></tr><tr><td>SD11</td></tr><tr><td>SD12</td></tr><tr><td>SD13</td></tr><tr><td>SD14</td></tr><tr><td>SD15</td></tr></table>	Number	Meaning	SD5	Slot No.	SD6	I/O No.	SD7	Station No.	SD8	(Empty)	SD9	SD10	SD11	SD12	SD13	SD14	SD15									
Number	Meaning																										
SD5	Slot No.																										
SD6	I/O No.																										
SD7	Station No.																										
SD8	(Empty)																										
SD9																											
SD10																											
SD11																											
SD12																											
SD13																											
SD14																											
SD15																											
SD13																											
SD14																											
SD15																											

*4: "0" is stored to the block number and the step number.

9) CC-Link Safety information

Number	Meaning
SD5	Error classification*5
SD6	Error item*5
SD7	Link ID
SD8	Station No.
SD9	System area 1
SD10	System area 2
SD11	System area 3
SD12	System area 4
SD13	System area 5
SD14	System area 6
SD15	System area 7
SD16	System area 8

*5: The error classification and error item are stored only when the error code is 8300 (CC-LINK REMOTE DETECTION ERROR).

0 is stored when the error code is other than 8300.

10) Module No./Station No.

Number	Meaning
SD5	Slot No.
SD6	I/O No.
SD7	Station No.
SD8	(Empty)
SD9	
SD10	
SD11	
SD12	
SD13	
SD14	
SD15	

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																										
SD16	Error individual information	Error individual information	<ul style="list-style-type: none">Individual information corresponding to error codes (SD0) is stored here.There are the following nine different types of information are stored.	S (Error)	QS																										
SD17			2) File name/Drive name																												
SD18			<table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td>Drive</td></tr><tr><td>SD17</td><td rowspan="4">File name (ASCII code: 8 characters)</td></tr><tr><td>SD18</td></tr><tr><td>SD19</td></tr><tr><td>SD20</td></tr><tr><td>SD21</td><td>Extension *3</td><td>2EH(.)</td></tr><tr><td>SD22</td><td colspan="2">(ASCII code: 3 characters)</td></tr><tr><td>SD23</td><td colspan="2" rowspan="4">(Empty)</td></tr><tr><td>SD24</td></tr><tr><td>SD25</td></tr><tr><td>SD26</td></tr></table> <div>(Example) File name = MAIN.QPG b15 to b8 b7 to b0 41H(A) 40H(M) 43H(N) 49H(I) 20H(SP) 20x(SP) 20H(SP) 20H(SP) 51H(Q) 2EH(.) 47H(G) 50H(P)</div>			Number	Meaning	SD16	Drive	SD17	File name (ASCII code: 8 characters)	SD18	SD19	SD20	SD21	Extension *3	2EH(.)	SD22	(ASCII code: 3 characters)		SD23	(Empty)		SD24	SD25	SD26					
Number			Meaning																												
SD16			Drive																												
SD17			File name (ASCII code: 8 characters)																												
SD18																															
SD19																															
SD20																															
SD21			Extension *3			2EH(.)																									
SD22			(ASCII code: 3 characters)																												
SD23			(Empty)																												
SD24																															
SD25																															
SD26																															
SD19			3) Time (value Actually measured)																												
SD20			<table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td>Time : 1 μs units (0 to 999 μs)</td></tr><tr><td>SD17</td><td>Time : 1ms units (0 to 65535ms)</td></tr><tr><td>SD18</td><td rowspan="9">(Empty)</td></tr><tr><td>SD19</td></tr><tr><td>SD20</td></tr><tr><td>SD21</td></tr><tr><td>SD22</td></tr><tr><td>SD23</td></tr><tr><td>SD24</td></tr><tr><td>SD25</td></tr><tr><td>SD26</td></tr></table>			Number	Meaning	SD16	Time : 1 μs units (0 to 999 μs)	SD17	Time : 1ms units (0 to 65535ms)	SD18	(Empty)	SD19	SD20	SD21	SD22	SD23	SD24	SD25	SD26										
Number			Meaning																												
SD16	Time : 1 μs units (0 to 999 μs)																														
SD17	Time : 1ms units (0 to 65535ms)																														
SD18	(Empty)																														
SD19																															
SD20																															
SD21																															
SD22																															
SD23																															
SD24																															
SD25																															
SD26																															
SD21	4) Program error location																														
SD22	<table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td rowspan="4">File name (ASCII code: 8 characters)</td></tr><tr><td>SD17</td></tr><tr><td>SD18</td></tr><tr><td>SD19</td></tr><tr><td>SD20</td><td>Extension *3</td><td>2EH(.)</td></tr><tr><td>SD21</td><td colspan="2">(ASCII code: 3 characters)</td></tr><tr><td>SD22</td><td colspan="2">(Empty)</td></tr><tr><td>SD23</td><td colspan="2">Block No. *6</td></tr><tr><td>SD24</td><td colspan="2">Step No. *6</td></tr><tr><td>SD25</td><td colspan="2">Sequence step No. (L)</td></tr><tr><td>SD26</td><td colspan="2">Sequence step No. (H)</td></tr></table>	Number	Meaning	SD16	File name (ASCII code: 8 characters)	SD17	SD18	SD19	SD20	Extension *3	2EH(.)	SD21	(ASCII code: 3 characters)		SD22	(Empty)		SD23	Block No. *6		SD24	Step No. *6		SD25	Sequence step No. (L)		SD26	Sequence step No. (H)			
Number	Meaning																														
SD16	File name (ASCII code: 8 characters)																														
SD17																															
SD18																															
SD19																															
SD20	Extension *3	2EH(.)																													
SD21	(ASCII code: 3 characters)																														
SD22	(Empty)																														
SD23	Block No. *6																														
SD24	Step No. *6																														
SD25	Sequence step No. (L)																														
SD26	Sequence step No. (H)																														
SD23	*6: "0" is stored to the block number and the step number.																														
SD24	5) Parameter No. 6) Annunciator number																														
SD25	<table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td>Parameter No.</td></tr><tr><td>SD17</td><td rowspan="10">(Empty)</td></tr><tr><td>SD18</td></tr><tr><td>SD19</td></tr><tr><td>SD20</td></tr><tr><td>SD21</td></tr><tr><td>SD22</td></tr><tr><td>SD23</td></tr><tr><td>SD24</td></tr><tr><td>SD25</td></tr><tr><td>SD26</td></tr></table> <table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td>No.</td></tr><tr><td>SD17</td><td rowspan="10">(Empty)</td></tr><tr><td>SD18</td></tr><tr><td>SD19</td></tr><tr><td>SD20</td></tr><tr><td>SD21</td></tr><tr><td>SD22</td></tr><tr><td>SD23</td></tr><tr><td>SD24</td></tr><tr><td>SD25</td></tr><tr><td>SD26</td></tr></table>	Number	Meaning	SD16	Parameter No.	SD17	(Empty)	SD18	SD19	SD20	SD21	SD22	SD23	SD24	SD25	SD26	Number	Meaning	SD16	No.	SD17	(Empty)	SD18	SD19	SD20	SD21	SD22	SD23	SD24	SD25	SD26
Number	Meaning																														
SD16	Parameter No.																														
SD17	(Empty)																														
SD18																															
SD19																															
SD20																															
SD21																															
SD22																															
SD23																															
SD24																															
SD25																															
SD26																															
Number	Meaning																														
SD16	No.																														
SD17	(Empty)																														
SD18																															
SD19																															
SD20																															
SD21																															
SD22																															
SD23																															
SD24																															
SD25																															
SD26																															
SD26	9) Error information																														
	<table><tr><td>Number</td><td>Meaning</td></tr><tr><td>SD16</td><td>Error information 1</td></tr><tr><td>SD17</td><td>Error information 2</td></tr><tr><td>SD18</td><td>Error information 3</td></tr><tr><td>SD19</td><td>Error information 4</td></tr><tr><td>SD20</td><td>Error information 5</td></tr><tr><td>SD21</td><td>Error information 6</td></tr><tr><td>SD22</td><td>Error information 7</td></tr><tr><td>SD23</td><td>Error information 8</td></tr><tr><td>SD24</td><td>Error information 9</td></tr><tr><td>SD25</td><td>Error information 10</td></tr><tr><td>SD26</td><td>Error information 11</td></tr></table>	Number	Meaning	SD16	Error information 1	SD17	Error information 2	SD18	Error information 3	SD19	Error information 4	SD20	Error information 5	SD21	Error information 6	SD22	Error information 7	SD23	Error information 8	SD24	Error information 9	SD25	Error information 10	SD26	Error information 11						
Number	Meaning																														
SD16	Error information 1																														
SD17	Error information 2																														
SD18	Error information 3																														
SD19	Error information 4																														
SD20	Error information 5																														
SD21	Error information 6																														
SD22	Error information 7																														
SD23	Error information 8																														
SD24	Error information 9																														
SD25	Error information 10																														
SD26	Error information 11																														

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																								
SD16	Error individual information	Error individual information	10) CC-Link Safety information <table><tr><th>Number</th><th>Meaning</th></tr><tr><td>SD16</td><td>Number of items for individual information</td></tr><tr><td>SD17</td><td>individual information 1</td></tr><tr><td>SD18</td><td>individual information 2</td></tr><tr><td>SD19</td><td>individual information 3</td></tr><tr><td>SD20</td><td>individual information 4</td></tr><tr><td>SD21</td><td>individual information 5</td></tr><tr><td>SD22</td><td>individual information 6</td></tr><tr><td>SD23</td><td>individual information 7</td></tr><tr><td>SD24</td><td>individual information 8</td></tr><tr><td>SD25</td><td>individual information 9</td></tr><tr><td>SD26</td><td>individual information 10</td></tr></table>	Number	Meaning	SD16	Number of items for individual information	SD17	individual information 1	SD18	individual information 2	SD19	individual information 3	SD20	individual information 4	SD21	individual information 5	SD22	individual information 6	SD23	individual information 7	SD24	individual information 8	SD25	individual information 9	SD26	individual information 10	S (Error)	QS
Number			Meaning																										
SD16			Number of items for individual information																										
SD17			individual information 1																										
SD18			individual information 2																										
SD19			individual information 3																										
SD20			individual information 4																										
SD21			individual information 5																										
SD22			individual information 6																										
SD23			individual information 7																										
SD24			individual information 8																										
SD25			individual information 9																										
SD26			individual information 10																										
SD17																													
SD18																													
SD19																													
SD20																													
SD21																													
SD22																													
SD23																													
SD24																													
SD25																													
SD26																													
SD27																													
SD28																													
SD29																													
SD30																													
SD31																													
SD32																													
SD33																													
SD34																													
SD35																													
SD36																													
SD37																													
SD38																													
SD39																													
SD40																													
SD41																													
SD42																													
SD43																													
SD44																													
SD45																													
SD46																													
SD47																													
SD48																													
SD49																													
SD50																													
SD51																													
SD52																													
SD53																													
SD54																													
SD55																													
SD56																													
SD57																													
SD58																													
SD59																													
SD60																													
SD61																													
SD62																													
SD63																													
SD64																													
SD65																													
SD66																													
SD67																													
SD68																													
SD69																													
SD70																													
SD71																													
SD72																													
SD73																													
SD74																													
SD75																													
SD76																													
SD77																													
SD78																													
SD79																													
SD80																													
SD81																													
SD82																													
SD83																													
SD84																													
SD85																													
SD86																													
SD87																													
SD88																													
SD89																													
SD90																													
SD91																													
SD92																													
SD93																													
SD94																													
SD95																													
SD96																													
SD97																													
SD98																													
SD99																													
SD100																													
SD101																													
SD102																													
SD103																													
SD104																													
SD105																													
SD106																													
SD107																													
SD108																													
SD109																													
SD110																													
SD111																													
SD112																													
SD113																													
SD114																													
SD115																													
SD116																													
SD117																													
SD118																													
SD119																													
SD120																													
SD121																													
SD122																													
SD123																													
SD124																													
SD125																													
SD126																													
SD127																													
SD128																													
SD129																													
SD130																													
SD131																													
SD132																													
SD133																													
SD134																													
SD135																													
SD136																													
SD137																													
SD138																													
SD139																													
SD140																													
SD141																													
SD142																													
SD143																													
SD144																													
SD145																													
SD146																													
SD147																													
SD148																													
SD149																													
SD150																													
SD151																													
SD152																													
SD153																													
SD154																													
SD155																													
SD156																													
SD157																													
SD158																													
SD159																													
SD160																													
SD161																													
SD162																													
SD163																													
SD164																													
SD165																													
SD166																													
SD167																													
SD168																													
SD169																													
SD170																													
SD171																													
SD172																													
SD173																													
SD174																													
SD175																													
SD176																													
SD177																													
SD178																													
SD179																													
SD180																													
SD181																													
SD182																													
SD183																													
SD184																													
SD185																													
SD186																													
SD187																													
SD188																													
SD189																													
SD190																													
SD191																													
SD192																													
SD193																													
SD194																													
SD195																													
SD196																													
SD197																													
SD198																													
SD199																													
SD200																													
SD201																													
SD202																													
SD203																													
SD204																													
SD205																													
SD206																													
SD207																													
SD208																													
SD209																													
SD210																													
SD211																													
SD212																													
SD213																													
SD214																													
SD215																													
SD216																													
SD217																													
SD218																													
SD219																													
SD220																													
SD221																													
SD222																													
SD223																													
SD224																													
SD225																													
SD226																													
SD227																													
SD228																													
SD229																													
SD230																													
SD231																													
SD232																													
SD233																													
SD234																													
SD235																													
SD236																													
SD237																													
SD238																													
SD239																													
SD240																													
SD241																													
SD242																													
SD243																													
SD244																													
SD245																													
SD246																													
SD247																													
SD248																													
SD249																													
SD250																													
SD251																													
SD252																													
SD253																													
SD254																													
SD255																													
SD256																													
SD257																													
SD258																													
SD259																													
SD260																													
SD261																													
SD262																													
SD263																													
SD264																													
SD265																													
SD266																													
SD267																													
SD268																													
SD269																													
SD270																													
SD271																													
SD272																													
SD273																													
SD274																													
SD275																													
SD276																													
SD277																													
SD278																													
SD279																													
SD280																													
SD281																													
SD282																													
SD283																													
SD284																													
SD285																													
SD286																													
SD287																													
SD288																													
SD289																													
SD290																													
SD291																													
SD292																													
SD293																													
SD294																													
SD295																													
SD296																													
SD297																													
SD298																													
SD299																													
SD300																													
SD301																													
SD302																													
SD303																													
SD304																													
SD305																													
SD306																													
SD307																													
SD308																													
SD309																													
SD310																													
SD311																													
SD312																													
SD313																													
SD314																													
SD315																													
SD316																													
SD317																													
SD318																													
SD319																													
SD320																													
SD321																													
SD322																													
SD323																													
SD324																													
SD325																													
SD326																													
SD327																													
SD328																													
SD329																													
SD330																													
SD331																													
SD332																													
SD333																													
SD334																													
SD335																													
SD336																													
SD337																													
SD338																													
SD339																													
SD340																													
SD341																													
SD342																													
SD343																													
SD344																													
SD345																													
SD346																													
SD347																													
SD348																													
SD349																													
SD350																													
SD351																													
SD352																													
SD353																													
SD354																													
SD355																													
SD356																													
SD357																													
SD358																													
SD359																													
SD360																													
SD361																													
SD362																													
SD363																													
SD364																													
SD365																													
SD366																													
SD367																													
SD368																													
SD369																													
SD370																													
SD371																													
SD372																													
SD373																													
SD374																													
SD375																													
SD376																													
SD377																													
SD378																													
SD379																													
SD380																													
SD381																													
SD382																													
SD383																													
SD384																													
SD385																													
SD386																													
SD387																													
SD388																													
SD389																													
SD390																													
SD391																													
SD392																													
SD393																													
SD394																													
SD395																													
SD396																													
SD397																													
SD398																													
SD399																													
SD400																													
SD401																													
SD402																													
SD403																													
SD404																													
SD405																													
SD406																													
SD407																													
SD408																													
SD409																													
SD410																													
SD411																													
SD412																													
SD413																													
SD414																													
SD415																													
SD416																													
SD417																													
SD418																													
SD419																													
SD420																													
SD421																													
SD422																													
SD423																													
SD424																													
SD425																													
SD426																													
SD427																													
SD428																													
SD429																													
SD430																													
SD431																													
SD432																													
SD433																													
SD434																													
SD435																													
SD436																													
SD437																													
SD438																													
SD439																													
SD440																													
SD441																													
SD442																													
SD443																													
SD444																													
SD445																													
SD446																													
SD447																													
SD448																													
SD449																													
SD450																													
SD451																													
SD452																													
SD453																													
SD454																													
SD455																													
SD456																													
SD457																													
SD458																													
SD459																													
SD460																													
SD461																													
SD462																													
SD463																													
SD464																													
SD465																													
SD466																													
SD467																													
SD468																													
SD469																													
SD470																													
SD471																													
SD472																													
SD473																													
SD474																													
SD475																													
SD476																													
SD477																													
SD478																													
SD479																													
SD480																													
SD481																													
SD482																													
SD483																													
SD484																													
SD485																													
SD486																													
SD487																													
SD488																													
SD489																													
SD490																													
SD491																													
SD492																													
SD493																													
SD494																													
SD495																													
SD496																													
SD497																													
SD498																													
SD499																													
SD500																													
SD501																													
SD502																													
SD503																													
SD504																													
SD505																													
SD506																													
SD507																													
SD508																													
SD509																													
SD510																													
SD511																													
SD512																													
SD513																													
SD514																													
SD515																													
SD516																													
SD517																													
SD518																													
SD519																													
SD520																													
SD521																													
SD522																													
SD523																													
SD524																													
SD525																													
SD526																													
SD527																													
SD528																													
SD529																													
SD530																													
SD531																													
SD532																													
SD533																													
SD534																													
SD535																													
SD536																													
SD537																													
SD538																													
SD539																													
SD540																													
SD541																													
SD542																													
SD543																													
SD544																													
SD545																													
SD546																													
SD547																													
SD548																													
SD549																													
SD550																													
SD551																													
SD552																													
SD553																													
SD554																													
SD555																													
SD556																													
SD557																													
SD558																													
SD559																													
SD560																													
SD561																													
SD562																													
SD563																													
SD564																													
SD565																													
SD566																													
SD567																													
SD568																													
SD569																													
SD570																													
SD571																													
SD572																													
SD573																													
SD574																													
SD575																													
SD576																													
SD577																													
SD578																													
SD579																													
SD580																													
SD581																													
SD582																													
SD583																													
SD584																													
SD585																													
SD586																													
SD587																													
SD588																													
SD589																													
SD590																													
SD591																													
SD592																													
SD593																													
SD594																													
SD595																													
SD596																													
SD597																													
SD598																													
SD599																													
SD600																													
SD601																													
SD602																													
SD603																													
SD604																													
SD605																													
SD606																													
SD607																													
SD608																													
SD609																													
SD610																													
SD611																													
SD612																													
SD613																													
SD614																													
SD615																													
SD616																													
SD617																													
SD618																													
SD619																													
SD620																													
SD621																													
SD622																													
SD623																													
SD624																													
SD625																													
SD626																													
SD627																													
SD628																													
SD629																													
SD630																													
SD631																													
SD632																													
SD633																													
SD634																													
SD635																													
SD636																													
SD637																													
SD638																													
SD639																													
SD640																													
SD641																													
SD642																													
SD643																													
SD644																													
SD645																													
SD646																													
SD647																													
SD648																													
SD649																													
SD650																													
SD651																													
SD652																													
SD653																													
SD654																													
SD655																													
SD656																													
SD657																													
SD658																													
SD659																													
SD660																													
SD661																													
SD662																													
SD663																													
SD664																													
SD665																													
SD666																													
SD667																													
SD668																													
SD669																													
SD670																													
SD671																													
SD672																													
SD673																													
SD674																													
SD675																													
SD676																													
SD677																													
SD678																													
SD679																													
SD680																													
SD681																													
SD682																													
SD683																													
SD684																													
SD685																													
SD686																													
SD687																													
SD688																													
SD689																													
SD690																													
SD691																													
SD692																													
SD693																													
SD694																													
SD695																													
SD696																													
SD697																													
SD698																													
SD699																													
SD700																													
SD701																													
SD702																													
SD703																													
SD704																													
SD705																													
SD706																													
SD707																													
SD708																													
SD709																													
SD710																													
SD711																													
SD712																													
SD713																													
SD714																													
SD715																													
SD716																													
SD717																													
SD718																													
SD719																													
SD720																													
SD721																													
SD722																													
SD723																													
SD724																													
SD725																													
SD726																													
SD727																													
SD728																													
SD729																													
SD730																													
SD731																													
SD732																													
SD733																													
SD734																													
SD735																													
SD736																													
SD737																													
SD738																													
SD739																													
SD740																													
SD741																													
SD742																													
SD743																													
SD744																													
SD745																													
SD746																													
SD747																													
SD748																													
SD749																													
SD750																													
SD751																													
SD752																													
SD753																													
SD754																													
SD755																													
SD756																													
SD757																													
SD758																													
SD759																													
SD760																													
SD761																													
SD762																													
SD763																													
SD764																													
SD765																													
SD766																													
SD767																													
SD768																													
SD769																													
SD770																													
SD771																													
SD772																													
SD773																													
SD774																													
SD775																													
SD776																													
SD777																													
SD778																													
SD779																													
SD780																													
SD781																													
SD782																													
SD783																													
SD784																													
SD785																													
SD786																													
SD787																													
SD788																													
SD789																													
SD790																													
SD791																													
SD792																													
SD793																													
SD794																													
SD795																													
SD796																													
SD797																													
SD798																													
SD799																													
SD800																													
SD801																													
SD802																													
SD803																													
SD804																													
SD805																													
SD806																													
SD807																													
SD808																													
SD809																													
SD810																													
SD811																													
SD812																													
SD813																													
SD814																													
SD815																													
SD816																													
SD817																													
SD818																													
SD819																													
SD820																													
SD821																													
SD822																													
SD823																													
SD824																													
SD825																													
SD826																													
SD827																													
SD828																													
SD829																													
SD830																													
SD831																													
SD832																													
SD833																													
SD834																													
SD835																													
SD836																													
SD837																													
SD838																													
SD839																													
SD840																													
SD841																													
SD842																													
SD843																													
SD844																													
SD845																													
SD846																													
SD847																													
SD848																													
SD849																													
SD850																													
SD851																													
SD852																													
SD853																													
SD854																													
SD855																													
SD856																													
SD857																													
SD858																													
SD859																													
SD860																													
SD861																													
SD862																													
SD863																													
SD864																													
SD865																													
SD866																													
SD867																													
SD868																													
SD869																													
SD870																													
SD871																													
SD872																													
SD873																													
SD874																													
SD875																													
SD876																													
SD877																													
SD878																													
SD879																													
SD880																													
SD881																													
SD882																													
SD883																													
SD884																													
SD885																													
SD886																													
SD887																													
SD888																													
SD889																													
SD890																													
SD891																													
SD892																													
SD893																													
SD894																													
SD895																													
SD896																													
SD897																													
SD898																													
SD899																													
SD900																													
SD901																													
SD902																													
SD903																													
SD904																													
SD905																													
SD906																													
SD907																													
SD908																													
SD909																													
SD910																													
SD911																													
SD912																													
SD913																													
SD914																													
SD915																													
SD916																													
SD917																													
SD918																													
SD919																													
SD920																													
SD921																													
SD922																													
SD923																													
SD924																													
SD925																													
SD926																													
SD927																													
SD928																													
SD929																													
SD930																													
SD931																													
SD932																													
SD933																													
SD934																													
SD935																													
SD936																													
SD937																													
SD938																													
SD939																													
SD940																													
SD941																													
SD942																													
SD943																													
SD944																													
SD945																													
SD946																													

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																							
SD61	I/O module verify error number	I/O module verify error module number	<ul style="list-style-type: none">The lowest I/O number of the module where the I/O module verification number took place.	S (Error)	QS																							
SD62	Annunciator number	Annunciator number	<ul style="list-style-type: none">The first annunciator number (F number) to be detected is stored here.	S (Instruction execution)																								
SD63	Number of annunciators	Number of annunciators	<ul style="list-style-type: none">Stores the number of annunciators searched.	S (Instruction execution)																								
SD64	Table of detected annunciator numbers	Annunciator detection number	<ul style="list-style-type: none">When F goes ON due to OUT F or SET F, the F numbers which go progressively ON from SD64 through SD79 are registered.The F numbers turned OFF by RST F are deleted from SD64 - SD79, and the F numbers stored after the deleted F numbers are shifted to the preceding registers. After 16 annunciators have been detected, detection of the 17th will not be stored from SD64 through SD79. <div><div>SET SET SET RST SET SET SET SET SET SET SET RST</div><div>F50 F25 F99 F25 F15 F70 F65 F38 F110 F151 F210 F50</div><div>SD62 0 50 50 50 50 50 50 50 50 50 50 99 (Number detected)</div><div>SD63 0 1 2 3 2 3 4 5 6 7 8 9 8 (Number of annunciators detected)</div><div>SD64 0 50 50 50 50 50 50 50 50 50 50 99</div><div>SD65 0 0 25 25 99 99 99 99 99 99 99 15</div><div>SD66 0 0 0 99 0 15 15 15 15 15 15 15 70</div><div>SD67 0 0 0 0 0 0 0 70 70 70 70 70 65</div><div>SD68 0 0 0 0 0 0 0 65 65 65 65 65 38</div><div>SD69 0 0 0 0 0 0 0 0 38 38 38 38 110</div><div>SD70 0 0 0 0 0 0 0 0 0 110 110 110 151</div><div>SD71 0 0 0 0 0 0 0 0 0 0 151 151 210</div><div>SD72 0 0 0 0 0 0 0 0 0 0 0 210 0</div><div>SD73 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD74 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD75 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD76 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD77 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD78 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>SD79 0 0 0 0 0 0 0 0 0 0 0 0 0</div><div>(Number detected)</div></div>	S (Instruction execution)																								
SD65																												
SD66																												
SD67																												
SD68																												
SD69																												
SD70																												
SD71																												
SD72																												
SD73																												
SD74																												
SD75																												
SD76																												
SD77																												
SD78																												
SD79																												
SD81	Cause of error	Cause of error	<ul style="list-style-type: none">When a continuation error occurs, the corresponding bits are all set to ON.Canceling the error, starting up the safety PLC power or canceling the safety CPU module reset after eliminating the cause of the error makes the bits go OFF. <table><tr><th>Bit No.</th><th>Name of the cause</th></tr><tr><td>0</td><td>Instantaneous power failure</td></tr><tr><td>1</td><td>Battery low</td></tr><tr><td>2</td><td>Standard ROM write count excess</td></tr><tr><td>3</td><td>TEST MODE continuous RUN tolerance timeout</td></tr><tr><td>4</td><td>Scan timeout</td></tr><tr><td>5</td><td>Annunciator ON</td></tr><tr><td>6</td><td>Safety remote station detection error</td></tr><tr><td>7</td><td>Safety remote station product information mismatch</td></tr><tr><td>8</td><td>Initial monitoring timeout error Safety monitoring timeout error Error monitoring timeout error</td></tr><tr><td>9</td><td>Safety remote station data split error Safety remote command error Safety remote station link ID error Safety remote station running number error Safety remote station reception data error</td></tr><tr><td>10 to 15</td><td>Empty (fixed to 0)</td></tr></table>	Bit No.		Name of the cause	0	Instantaneous power failure	1	Battery low	2	Standard ROM write count excess	3	TEST MODE continuous RUN tolerance timeout	4	Scan timeout	5	Annunciator ON	6	Safety remote station detection error	7	Safety remote station product information mismatch	8	Initial monitoring timeout error Safety monitoring timeout error Error monitoring timeout error	9	Safety remote station data split error Safety remote command error Safety remote station link ID error Safety remote station running number error Safety remote station reception data error	10 to 15	Empty (fixed to 0)
Bit No.	Name of the cause																											
0	Instantaneous power failure																											
1	Battery low																											
2	Standard ROM write count excess																											
3	TEST MODE continuous RUN tolerance timeout																											
4	Scan timeout																											
5	Annunciator ON																											
6	Safety remote station detection error																											
7	Safety remote station product information mismatch																											
8	Initial monitoring timeout error Safety monitoring timeout error Error monitoring timeout error																											
9	Safety remote station data split error Safety remote command error Safety remote station link ID error Safety remote station running number error Safety remote station reception data error																											
10 to 15	Empty (fixed to 0)																											

TableApp.10 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD150	I/O module verify error	Bit pattern, in units of 16 points, indicating the modules with verify errors. 0: No I/O verify errors 1: I/O verify error present	<ul style="list-style-type: none">When I/O modules, of which data are different from those entered at power-on, have been detected, the I/O module numbers (in units of 16 points) are entered in bit pattern. (Preset I/O module numbers set in parameters when parameter setting has been performed.) <div><div><div><div>b15b14b13b12b11b10b9b8b7b6b5b4b3b2b1b0</div><div><div>SD150</div><div>00000000000000</div><div>SD151</div><div>00000000000000</div><div>SD153</div><div>00000000000000</div></div><div><div><div><div><div><div>1</div><div>(X_Y)₀</div></div></div><div><div><div><div>1</div><div>(X_Y)₀</div></div></div></div><div><div><div><div>1</div><div>(X_Y)₀</div></div></div></div></div><div>Indicates an I/O module verify error</div></div></div></div></div></div>	S (Error)	QS
SD151					
SD152					
SD153					
			<ul style="list-style-type: none">Not cleared even if the blown fuse is replaced with a new one. This flag is cleared by error resetting operation.		

(2) System information

TableApp.12 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD200	Status of switch	Status of CPU switch	<ul style="list-style-type: none"> The CPU switch status is stored in the following format. 	S (Every END)	QS
SD201	LED status	Status of CPU-LED	<ul style="list-style-type: none"> The following bit patterns are used to store the statuses of the LEDs on the CPU module: 0 is off, 1 is on, and 2 is flicker. 	S (Status change)	
SD203	Operating status of CPU	Operating status of CPU	<ul style="list-style-type: none"> The CPU operating status is stored as indicated in the following figure: 	S (Every END)	

TableApp.12 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD210	Clock data	Clock data (year, month)	<div><div><div><div><div></div></div><div></div><div></div><div></div></div><div>b15 to b12</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b11 to b8</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b7 to b4</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b3 to b0</div></div><div>Example: September, 2006 0609_H</div><div>YearMonth</div></div>	S (Request)	QS
SD211	Clock data	Clock data (day, hour)	<div><div><div><div><div></div></div><div></div><div></div><div></div></div><div>b15 to b12</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b11 to b8</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b7 to b4</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b3 to b0</div></div><div>Example: 25st, 10 a.m. 2510_H</div><div>DayHour</div></div>		
SD212	Clock data	Clock data (minute, second)	<div><div><div><div><div></div></div><div></div><div></div><div></div></div><div>b15 to b12</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b11 to b8</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b7 to b4</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b3 to b0</div></div><div>Example: 35 min., 48 sec. 3548_H</div><div>MinuteSecond</div></div>		
SD213	Clock data	Clock data (later digits of year, day of week)	<div><div><div><div><div></div></div><div></div><div></div><div></div></div><div>b15 to b12</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b11 to b8</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b7 to b4</div><div><div><div></div></div><div></div><div></div><div></div></div><div>b3 to b0</div></div><div>Example: 2006, Monday 2001_H</div><div>Higher digits of year (0 to 99)</div><div><div>Day of the week</div><div><div>0</div><div>Sunday</div></div><div><div>1</div><div>Monday</div></div><div><div>2</div><div>Tuesday</div></div><div><div>3</div><div>Wednesday</div></div><div><div>4</div><div>Thursday</div></div><div><div>5</div><div>Friday</div></div><div><div>6</div><div>Saturday</div></div></div></div>		
SD232	ROM write count	ROM write count up to now	• Store the ROM write count up to now.	S (Writing to ROM)	
SD240	Base mode	0: Automatic mode	• Stores the base mode.(0 fixed)	S (Initial)	
SD241	Extension stage number	0: Main base only	• Stores the maximum number of the extension bases being installed. (0 fixed)	S (Initial)	

TableApp.12 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD242	Installed Q base presence/absence	Base type differentiation 0: Base not installed 1: QS**B is installed	<div><div>b15to b1 b0</div><div>Empty</div><div>➔ Main base unit</div></div>	S (Initial)	QS
SD243	No. of base slots (Operation status)	No. of base slots	<div><div>b15to b4 b3 to b0</div><div>SD243EmptyMain</div><div>SD244Empty</div></div> <div>• As shown above, each area stores the number of slots being installed. (Number of set slots when parameter setting has been made)</div>	S (Initial)	
SD244					
SD245	No. of base slots (Mounting status)	No. of base slots	<div><div>b15to b4 b3 to b0</div><div>SD245EmptyMain</div><div>SD246Empty</div></div> <div>• As shown above, each area stores the numbers of module-mounted slots of the base unit (actual number of slots of the installed base unit).</div>	S (Initial)	
SD246					
SD250	Loaded maximum I/O	Loaded maximum I/O No.	• The upper 2 digits of the final I/O number plus 1 of the modules loaded are stored as BIN values.	S (Initial)	
SD254	MELSECNET /H information	Number of modules installed	• Indicates the number of mounted MELSECNET/H module.	S (Initial)	
SD255		I/O No.	• Indicates I/O number of mounted MELSECNET/H module		
SD256		Network No.	• Indicates network No. of mounted MELSECNET/H module		
SD257		Group number	• Indicates group No. of mounted MELSECNET/H module		
SD258		Station No.	• Indicates station No. of mounted MELSECNET/H module		
SD290	Device allocation (Same as parameter contents)	Number of points allocated for X	• Stores the number of points currently set for X devices	S (Initial)	
SD291		Number of points allocated for Y	• Stores the number of points currently set for Y devices		
SD292		Number of points allocated for M	• Stores the number of points currently set for M devices		
SD294		Number of points allocated for B	• Stores the number of points currently set for B devices		
SD295		Number of points allocated for F	• Stores the number of points currently set for F devices		
SD296		Number of points allocated for SB	• Stores the number of points currently set for SB devices		
SD297		Number of points allocated for V	• Stores the number of points currently set for V devices		
SD299		Number of points allocated for T	• Stores the number of points currently set for T devices		
SD300		Number of points allocated for ST	• Stores the number of points currently set for ST devices		
SD301		Number of points allocated for C	• Stores the number of points currently set for C devices		
SD302		Number of points allocated for D	• Stores the number of points currently set for D devices		
SD303		Number of points allocated for W	• Stores the number of points currently set for W devices		
SD304		Number of points allocated for SW	• Stores the number of points currently set for SW devices		

(3) System clocks/counters

TableApp.13 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD412	1 second counter	Number of counts in 1-second units	<ul style="list-style-type: none"> Following programmable controller CPU module RUN, 1 is added each second Count repeats from 0 to 32767 to -32768 to 0 	S (Status change)	QS
SD414	2n second clock setting	2n second clock units	<ul style="list-style-type: none"> Stores value n of 2n second clock (Default is 30) Setting can be made between 1 to 32767 	U	
SD420	Scan counter	Number of counts in each scan	<ul style="list-style-type: none"> Incremented by 1 for each scan execution after the CPU module is set to RUN. Count repeats from 0 to 32767 to -32768 to 0 	S (Every END)	

(4) Scan information

TableApp.14 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD520	Current scan time	Current scan time (in 1 ms units)	<ul style="list-style-type: none">• The current scan time is stored into SD520 and SD521. (Measurement is made in 100 μs units.) SD520: Stores the value of ms. (Storage range: 0 to 6553) SD521: Stores the value of μs. (Storage range: 0 to 900) (Example) When the current scan time is 23.6ms, the following values are stored. SD520 = 23 SD521 = 600• The accuracy of processing time of scantime is ± 0.1ms.	S (Every END)	QS
SD521		Current scan time (in 100 μ s units)			
SD524	Minimum scan time	Minimum scan time (in 1 ms units)	<ul style="list-style-type: none">• Stores the minimum value of the scan time into SD524 and SD525. (Measurement is made in 100 μs units.) SD524: Stores the ms place. (Storage range: 0 to 6553) SD525: Stores the μs place. (Storage range: 0 to 900)• The accuracy of processing time of scantime is ± 0.1ms.	S (Every END)	
SD525		Minimum scan time (in 100 μ s units)			
SD526	Maximum scan time	Maximum scan time (in 1 ms units)	<ul style="list-style-type: none">• Stores the maximum value of the scan time into SD526 and SD527. (Measurement is made in 100 μs units.) SD526: Stores the ms place. (Storage range: 0 to 6553) SD527: Stores the μs place. (Storage range: 0 to 900)• The accuracy of processing time of scantime is ± 0.1ms.	S (Every END)	
SD527		Maximum scan time (in 100 μ s units)			
SD540	END processing time	END processing time (in 1 ms units)	<ul style="list-style-type: none">• Stores the time from when the scan program ends until the next scan starts into SD540 and SD541. (Measurement is made in 100 μs units.) SD540: Stores the ms place. (Storage range: 0 to 6553) SD541: Stores the μs place. (Storage range: 0 to 900)• The accuracy of NED processing time is ± 0.1ms.	S (Every END)	
SD541		END processing time (in 100 μ s units)			
SD542	Constant scan wait time	Constant scan wait time (in 1 ms units)	<ul style="list-style-type: none">• Stores the wait time for constant scan setting into SD542 and SD543. (Measurement is made in 100 μs units.) SD542: Stores the ms place. (Storage range: 0 to 6553) SD543: Stores the μs place. (Storage range: 0 to 900)• The accuracy of constant scan wait time is ± 0.1ms.	S (Every END)	
SD543		Constant scan wait time (in 100 μ s units)			
SD548	Scan program execution time	Scan program execution time (in 1 ms units)	<ul style="list-style-type: none">• Stores the execution time of a scan program during one scan into SD548 and SD549. (Measurement is made in 100 μs units.) SD548: Stores the ms place. (Storage range: 0 to 6553) SD549: Stores the μs place. (Storage range: 0 to 900)• Stored every scan.• The accuracy of scan program execution time is ± 0.1ms.	S (Every END)	
SD549		Scan program execution time (in 100 μ s units)			

(5) Safety CPU

TableApp.15 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD560	Safety CPU operation mode	Safety CPU operation mode	<div><div><div>• Stores the safety CPU operation mode.</div><div><div>b15to b2 b1 b0</div><div><div>Empty</div><div><div></div><div></div></div></div></div><div>→ 00 : SAFETY MODE 01 : TEST MODE 10 : SAFETY MODE (Wait-for-restart)</div></div></div>	S (Status change)	QS
SD561	TEST MODE continuous RUN time	TEST MODE continuous RUN time (seconds)	<div><div><div>• Stores the TEST MODE continuous RUN time. (Measured in seconds) (RUN time in TEST MODE. Start measurement when STOP & RUN (Time when operation is STOP is not included.)</div><div>• Stores the measurement valve with the range of 1 to 2147483647.</div></div></div>	S (Every END)	
SD562					

(6) Memory

TableApp.16 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU
SD620	Memory type	Memory type	<ul style="list-style-type: none"> Indicates the type of built-in memory. <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> b15 to b8 0 </div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> b7 to b4 <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">Drive 4 (Standard ROM)</div> <div style="border: 1px solid black; padding: 2px;">Fixed at "3 (FLASH ROM)"</div> </div> </div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> b3 to b0 0 </div> </div>	S (Initial)	QS
SD623	Drive 4 (ROM) capacity	Drive 4 capacity	<ul style="list-style-type: none"> Drive 4 capacity is stored in 1 kbyte units. 	S (Initial)	

(7) CC-Link Safety

TableApp.17 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																														
SD1000 to SD1003	Safety remote station specification (CC-Link Safety master module 1)	0: No safety remote station specification 1: Safety remote station specification	<ul style="list-style-type: none"> The specified status of safety remote station is stored. "0" is stored for the standard remote station. <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1000</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1001</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1002</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1003</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1000	16	15	to	2	1	SD1001	32	31	to	18	17	SD1002	48	47	to	34	33	SD1003	64	63	to	50	49	S (Initial)	
	b15	b14	-	b1	b0																														
SD1000	16	15	to	2	1																														
SD1001	32	31	to	18	17																														
SD1002	48	47	to	34	33																														
SD1003	64	63	to	50	49																														
SD1004 to SD1007	Safety station refresh communication status (CC-Link Safety master module 1)	0: Normal, Reserved station specified, Unused, Standard remote station 1: Safety station communication error	<ul style="list-style-type: none"> The refresh communication status of safety remote station is stored. "0" is stored for the standard remote station. <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1004</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1005</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1006</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1007</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1004	16	15	to	2	1	SD1005	32	31	to	18	17	SD1006	48	47	to	34	33	SD1007	64	63	to	50	49	S (Status changel)	
	b15	b14	-	b1	b0																														
SD1004	16	15	to	2	1																														
SD1005	32	31	to	18	17																														
SD1006	48	47	to	34	33																														
SD1007	64	63	to	50	49																														
SD1008 to SD1071	Safety station communication status (CC-Link Safety master module 1)	The status of communication with safety station is stored.	<ul style="list-style-type: none"> The status of communication with each safety remote station is stored. SD1008: Station number 1 to SD1071: Station number 64 (0 fixed in the case of standard remote station, reserved station specified, or without connection) <p>0: At normal communication 10: At initial 20: During internal information access 30: Link error 8300: Link error (Safety remote station detection error) 8310: Link error (Product information mismatch) 8320: Link error (Initial monitor timeout) 8321: Link error (Safety monitor timeout) 8322: Link error (Error monitor timeout) 8330: Link error (Command error) 8331: Link error (Data numbering error) 8332: Link error (Link ID error) 8333: Link error (Running number error) 8334: Link error (Received data error)</p>	S (Status changel)	QS																														
SD1072 to SD1075	Safety station interlock status (CC-Link Safety master module 1)	0: Interlock is not executed 1: During interlock	<p>Bit corresponding to the station number turns 1 when the master station goes to the interlock status after the error was detected at the master station.</p> <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1072</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1073</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1074</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1075</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1072	16	15	to	2	1	SD1073	32	31	to	18	17	SD1074	48	47	to	34	33	SD1075	64	63	to	50	49	S (Status changel)	
	b15	b14	-	b1	b0																														
SD1072	16	15	to	2	1																														
SD1073	32	31	to	18	17																														
SD1074	48	47	to	34	33																														
SD1075	64	63	to	50	49																														

TableApp.17 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																														
SD1076 to SD1079	Safety station interlock cancel request (CC-Link Safety master module 1)	0: Not cancel the I/O interlock of safety station 1: Cancel the I/O interlock of safety station	<p>Cancel the I/O interlock of safety station by changing the bit of register from 0 to 1.</p> <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1076</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1077</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1078</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1079</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1076	16	15	to	2	1	SD1077	32	31	to	18	17	SD1078	48	47	to	34	33	SD1079	64	63	to	50	49	U (Request)	
	b15	b14	-	b1	b0																														
SD1076	16	15	to	2	1																														
SD1077	32	31	to	18	17																														
SD1078	48	47	to	34	33																														
SD1079	64	63	to	50	49																														
SD1200 to SD1203	Safety remote station specification (CC-Link Safety master module 2)	0: No safety remote station specification 1: Safety remote station specification	<ul style="list-style-type: none"> The specified status of safety remote station is stored. "0" is stored for the standard remote station. <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1000</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1001</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1002</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1003</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1000	16	15	to	2	1	SD1001	32	31	to	18	17	SD1002	48	47	to	34	33	SD1003	64	63	to	50	49	S (Initial)	
	b15	b14	-	b1	b0																														
SD1000	16	15	to	2	1																														
SD1001	32	31	to	18	17																														
SD1002	48	47	to	34	33																														
SD1003	64	63	to	50	49																														
SD1204 to SD1207	Safety station refresh communication status (CC-Link Safety master module 2)	0: Normal, Reserved station specified, Unused, Standard remote station 1: Safety station communication error	<ul style="list-style-type: none"> The refresh communication status of safety remote station is stored. "0" is stored for the standard remote station. <table border="1"> <thead> <tr> <th></th><th>b15</th><th>b14</th><th>-</th><th>b1</th><th>b0</th></tr> </thead> <tbody> <tr> <td>SD1204</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr> <tr> <td>SD1205</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr> <tr> <td>SD1206</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr> <tr> <td>SD1207</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr> </tbody> </table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1204	16	15	to	2	1	SD1205	32	31	to	18	17	SD1206	48	47	to	34	33	SD1207	64	63	to	50	49	S (Status changel)	QS
	b15	b14	-	b1	b0																														
SD1204	16	15	to	2	1																														
SD1205	32	31	to	18	17																														
SD1206	48	47	to	34	33																														
SD1207	64	63	to	50	49																														
SD1208 to SD1271	Safety station communication status (CC-Link Safety master module 2)	The status of communication with safety station is stored.	<ul style="list-style-type: none"> The status of communication with each safety remote station is stored. SD1208: Station number 1 to SD1271: Station number 64 (0 fixed in the case of standard remote station, reserved station specified, or without connection) <p>0: At normal communication 10: At initial 20: During internal information access 30: Link error 8300: Link error (Safety remote station detection error) 8310: Link error (Product information mismatch) 8320: Link error (Initial monitor timeout) 8321: Link error (Safety monitor timeout) 8322: Link error (Error monitor timeout) 8330: Link error (Command error) 8331: Link error (Data numbering error) 8332: Link error (Link ID error) 8333: Link error (Running number error) 8334: Link error (Received data error)</p>	S (Status changel)																															

TableApp.17 Special register

Number	Name	Meaning	Explanation	Set by (When set)	Corresponding CPU																														
SD1272 to SD1275	Safety station interlock status (CC- Link Safety master module 2)	0: Interlock is not executed 1: During interlock	<p>Bit corresponding to the station number turns 1 when the master station goes to the interlock status after the error was detected at the master station.</p> <table><tr><td></td><td>b15</td><td>b14</td><td>-</td><td>b1</td><td>b0</td></tr><tr><td>SD1272</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr><tr><td>SD1273</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr><tr><td>SD1274</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr><tr><td>SD1275</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr></table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1272	16	15	to	2	1	SD1273	32	31	to	18	17	SD1274	48	47	to	34	33	SD1275	64	63	to	50	49	S (Status changel)	QS
	b15	b14	-	b1	b0																														
SD1272	16	15	to	2	1																														
SD1273	32	31	to	18	17																														
SD1274	48	47	to	34	33																														
SD1275	64	63	to	50	49																														
SD1276 to SD1279	Safety station interlock cancel request (CC-Link Safety master module 2)	0: Not cancel the I/O interlock of safety station 1: Cancel the I/O interlock of safety station	<p>Cancel the I/O interlock of safety station by changing the bit of register from 0 to 1.</p> <table><tr><td></td><td>b15</td><td>b14</td><td>-</td><td>b1</td><td>b0</td></tr><tr><td>SD1276</td><td>16</td><td>15</td><td>to</td><td>2</td><td>1</td></tr><tr><td>SD1277</td><td>32</td><td>31</td><td>to</td><td>18</td><td>17</td></tr><tr><td>SD1278</td><td>48</td><td>47</td><td>to</td><td>34</td><td>33</td></tr><tr><td>SD1279</td><td>64</td><td>63</td><td>to</td><td>50</td><td>49</td></tr></table> <p>1 to 64 in the table indicate station numbers.</p>		b15	b14	-	b1	b0	SD1276	16	15	to	2	1	SD1277	32	31	to	18	17	SD1278	48	47	to	34	33	SD1279	64	63	to	50	49	S (Request)	
	b15	b14	-	b1	b0																														
SD1276	16	15	to	2	1																														
SD1277	32	31	to	18	17																														
SD1278	48	47	to	34	33																														
SD1279	64	63	to	50	49																														

Appendix 3 List of Parameter No.

The parameter No. is stored into the special register (SD16 to 26), when an error occurs in the parameter settings.

The table for the parameter No. and parameter setting area is shown in this section.

TableApp.18 List of parameter No.

Item		Parameter No.	Reference
Label		0000 _H	Section 8.1(1)
Comment		0001 _H	
I/O assignment	Type	0400 _H	Section 4.3 Section 8.1(6)
	Model name		
	points		
	Start XY (Start I/O No.)		
Basic setting	Base model name	0401 _H	Section 8.1(6)
	Power model name		
	Extension cable		
	Slots		
Group No.		0.5 _{mnH}	Section 8.2(1)
Switch setting		0407 _H	Section 8.1(6)
Timer limit setting	Low speed	1000 _H	Section 8.1(2)
	High speed		Section 9.2.8
RUN-PAUSE contact		1001 _H	Section 6.12.1 Section 8.1(2)
Remote reset		1002 _H	Section 6.12.2 Section 8.1(2)
Output mode at STOP to RUN		1003 _H	Section 6.10 Section 8.1(2)
Points occupied by empty slot		1007 _H	Section 4.2.1 Section 8.1(2)
Device points		2000 _H	Section 8.1(4) Section 9.1 Section 9.2
WDT (watchdog timer) setting		3000 _H	Section 3.2 Section 8.1(3)

(Continued on next page)

TableApp.18 List of parameter No.

Item		Parameter No.	Reference
Constant scanning		3003 _H	Section 6.9 Section 8.1(3)
MELSECNET/H setting	Number of MELSECNET	5000 _H	Section 8.2(1)
	Starting I/O No.	5NM0 _H	
	Network No.		
	Mode	5NM0 _H	
	Refresh parameters	5NM1 _H	
Continuous RUN in test mode		6000 _H	Section 6.5
Operation mode at the time of a remote station error			Section 8.1(8)
Boot file setting		7000 _H	Section 5.1.4 Section 8.1(5)
CC-Link setting	Number of CC-Link	C000 _H	Section 8.2(2)
	Remote input (RX)	CNM1 _H	
	Remote output (RY)		
	Remote register (RWr)		
	Remote register (RWw)		
	Special relay (SB)		
	Special register (SW)		
	Operational settings	CNM2 _H	
	Mode setting		
	Transmission settings		
	Safety refresh monitoring time		
	Link ID		
	All connect count		
	Retry count		
	Automatic reconnection station count		
	Scan mode setting		
	Station information setting		

Appendix 4 Restrictions on Using MELSECNET/H Module in the Safety CPU Module

(1) Network parameter which can be set in the safety CPU module

When using MELSECNET/H module in the safety CPU module, network parameter of MELSECNET/H which can be set in GX Developer is shown in TableApp.19.

TableApp.19 List for network parameter which can be set in GX Developer

Parameter setting item		Use permitted/prohibited
Network type	MNET/H mode (control station), MNET/H EX (control station)	×
	MNET/H mode (normal station), MNET/H EX (normal station)	○
	MNET/10 mode (control station)	×
	MNET/10 mode (normal station)	○
	MNET/H standby station	×
Starting I/O No.		○
Network No.		○
Total number of (slave) stations		×
Group No.		○
Mode		○
Network range assignment (common parameters)		×
Station inherent parameters		×
Refresh parameters		○
Interrupt setting		×
Control station return setting		×
Standby station compatible module		×
Redundant setting		×
Inter-link data transfer		×
Routing parameters		×
Valid unit in access to another station		×

○ : Available, × : Not available

Remark

For network parameter of MELSECNET/H, refer to the following manual.

☞ Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

(2) Function of MELSECNET/H network system that can be used in the safety CPU module

The function of MELSECNET/H network system and the function which can be used in the safety CPU module are shown in TableApp.20.


TableApp.20 Function of MELSECNET/H network system and its availability in the safety CPU module

Function		Use permitted/prohibited
Cyclic transmission function	Communication using LB/LW	○
	Communication using LX/LY	○
	MELSECNET/H extended mode	○
	Refresh parameter	○
	Common parameter	○
	Station inherent parameter	×
	Inter-link data transfer function	×
	Designation of reserved station	○
	Low-speed cyclic transmission function	○
	Redundant system function	×
Transient transmission function	Communication function	×
	Routing function	×
	Group function	×
	Message transmission function using logical channel numbers	×
	Data sending/receiving (SEND/RECV)	×
	Other station word device read/write (READ/SREAD/WRITE/SWRITE)	×
	Other station transient request (REQ)	×
	Other station word device read/write (ZNRD/ZNWR)	×
	Remote RUN/Remote STOP (RRUN/RSTOP)	×
	Reading and writing other station CPU module's clock data (RTMRD/RTMWR)	×
RAS function	Automatic return function	○
	Control station switch function	×
	Control station return control function	×
	Loopback function (optical loop system)	○
	Prevention of station failure by using external power supply (Optical loop system)	○
	Station detach function (coaxial bus system)	○
	Transient transmission enabled even at CPU module error	×
	Checking transient transmission abnormal detection time	×
	Diagnostic function	○
Direct access to link devices		×
Starting interrupt sequence program		×
Multiplex transmission function (optical loop system)		○
Simple dual-structured network		×
Stopping/restarting of cyclic transmission and stopping link refresh (network test)		○
Increasing number of send points by installing multiple modules with the same network number		×
Multiple CPU system supported		×
Remote I/O network system.		×
Redundant system supported		×
Network diagnostic (line monitor)		○

○ : used, × : unused

Remark

For the function of MELSECNET/H, refer to the following manual.

 Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

Appendix 5 Precautions for Battery Transportation

When transporting lithium batteries, make sure to treat them based on the transport regulations.

(1) Controlled models

The batteries for the QS Series CPU module (including memory cards) are classified as shown in TableApp.21.

TableApp.21 Models subject to transportation regulations

Product name	Model	Product supply status	Classification for transportation
Q series battery	Q6BAT	Lithium battery	Non-dangerous goods

(2) Transport guidelines

Comply with IATA Dangerous Goods Regulations, IMDG code and the local transport regulations when transporting products after unpacking or repacking, while Mitsubishi ships products with packages to comply with the transport regulations. Also, contact the transporters.

INDEX

[0] to [9]

5VDC internal current consumption 2-2

[A]

Accuracy 9-22
Accuracy of scan time 3-5
Allowable instantaneous power failure period . . . 2-2
Annunciator (F)
 Processing at annunciator OFF 9-13
 Processing at annunciator ON 9-11
Annunciator [F] 2-2

[B]

B (Link relay) 9-15
BCD (binary coded decimal) 3-18
BIN (binary code) 3-16
Boot file setting 5-10
Boot run 5-9

[C]

Cancel the error 6-31
Changing the clock data 6-45
Clearing
 Retentive timer clear 9-20
Clock function 6-44
Concept of I/O assignment 4-5
Constant scan 2-1, 6-38
Constant scanning 6-18
Continuation error 6-28
Control method 2-1
Counter (C) 9-24
 Count processing 9-24
 Resetting the counter 9-26
Counter [C] 2-2
CPU module
 Performance specifications 2-1

[D]

Data register (D) 9-28
Data register [D] 2-2
Data that can be stored into memories 5-2
Decimal constant (K) 9-35
Device
 Annunciator [F] 2-2
 Counter [C] 2-2
 Data register [D] 2-2
 Edge relay [V] 2-2
 Internal relay [M] 2-2
 Link register [W] 2-2
 Link relay [B] 2-2
 Link special register [SW] 2-2
 Link special relay [SB] 2-2
 Special register [SD] 2-2

Special relay [SM] 2-2
Timer [T] 2-2
Device list 9-1
Device setting 8-5
Drive Nos 5-2
Duty 9-27

[E]

Edge relay (V) 9-14
Edge relay [V] 2-2
Extension 5-2

[F]

F (Annunciator) 9-9
Features 1-3
File 5-14
File size units 5-18
Formatting necessities 5-2

[H]

H (Hexadecimal constant) 9-35
HEX (Hexadecimal) 3-17
Hexadecimal constant (H) 9-35
High speed retentive timer 9-20
High-speed timers 9-19
How to check the function version 1-10
How to Check the Serial No. 1-10

[I]

I/O assignment 4-4
I/O assignment setting 4-4
I/O control mode 2-1
I/O number 4-1
I/O number assignment 4-1
I/O refresh 3-8
Initial processing 3-7
Input (X) 9-5
Internal current consumption 2-2
Internal relay (M) 9-8
Internal relay [M] 2-2
Internal User Devices 9-2

[K]

K (Decimal constant) 9-35

[L]

LED
 LED display 6-62
 Method to turn off the LED 6-62
LED display for error 6-31
Link register (W) 9-29
Link register [W] 2-2
Link relay (B) 9-15

Link relay [B]	2-2
Link special register (SW)	9-31
Link special register [SW]	2-2
Link special relay (SB)	9-17
Link special relay [SB]	2-2
Low speed retentive timer,	9-20
Low-speed timers	9-18

[M]

M (Internal relay)	9-8
Max. number of files stored	2-1
Maximum counting speed	9-27
Memory capacities of files	5-17
Memory capacity	2-1
Memory configuration	5-1
Momentary Power Failure	3-11
Monitor	6-53

[N]

N (Nesting)	9-34
Nesting (N)	9-34
Network parameters	8-10
No. of device points	2-2
No. of I/O device points	2-1
Number of empty slots	8-3

[O]

Output (Y) status when changing from the STOP status to the RUN status	6-43
---	------

[P]

Parameter	
Network Parameters	8-10
PLC Parameters	8-2
PLC name setting	8-2
PLC parameters	8-2
Precautions	
Design Precautions	A-2
Disposal Precautions	A-7
Installation Precautions	A-3
Startup and Maintenance precautions	A-5
Wiring Precautions	A-3,A-4
Procedure	
Procedure for boot run	5-10
Write procedure	5-12
Processing method	9-21
Processing speed	2-1
Program capacity	2-1
Program language	2-1
Program memory	5-3
Purpose of I/O assignment	4-4

[R]

Reading time data	6-45
Recording	6-34
Resetting	
Resetting the counter	9-26

RUN status	3-9
RUN/PAUSE contact	2-2

[S]

Safety settings	8-9
SB (Link special relay)	9-17
Scan time	3-5
SD (Special register)	9-33
Self-diagnostics	6-28
Sequence Program	3-1
Serial No.	1-10
SM (Special relay)	9-32
Special register (SD)	9-33
Special register [SD]	2-2
Special Register List	App-5
Special relay (SM)	9-32
Special relay [SM]	2-2
Special Relay List	App-1
Specifications	2-1
ST(Retentive timer)	9-20
Standard ROM	2-1,5-7
Stop error	6-28
STOP status	3-9
SW (Link special register)	9-31
System configuration	
Sequence control language	2-1
System monitor	6-60

[T]

T (Timer)	9-18
Timer [T]	2-2
Timer function	2-2
Timer limit setting	8-3

[U]

User setting system area	5-4
--------------------------------	-----

[V]

V (Edge relay)	9-14
----------------------	------

[W]

W (Link register)	9-29
Watchdog timer setting	6-58
Write	
Write to program memory	5-6

[X]

X (Input)	9-5
X/Y assignment check	8-8,8-9

[Y]

Y (Output)	9-7
------------------	-----

WARRANTY

Please confirm the following product warranty details before using this product.

1. Limited Warranty and Product Support.

- a. Mitsubishi Electric Company ("MELCO") warrants that for a period of eighteen (18) months after date of delivery from the point of manufacture or one year from date of Customer's purchase, whichever is less, Mitsubishi MELSEC Safety programmable logic controllers (the "Products") will be free from defects in material and workmanship.
- b. At MELCO's option, for those Products MELCO determines are not as warranted, MELCO shall either repair or replace them or issue a credit or return the purchase price paid for them.
- c. For this warranty to apply:
 - (1) Customer shall give MELCO (i) notice of a warranty claim to MELCO and the authorized dealer or distributor from whom the Products were purchased, (ii) the notice shall describe in reasonable details the warranty problem, (iii) the notice shall be provided promptly and in no event later than thirty (30) days after the Customer knows or has reason to believe that Products are not as warranted, and (iv) in any event, the notice must be given within the warranty period;
 - (2) Customer shall cooperate with MELCO and MELCO's representatives in MELCO's investigation of the warranty claim, including preserving evidence of the claim and its causes, meaningfully responding to MELCO's questions and investigation of the problem, grant MELCO access to witnesses, personnel, documents, physical evidence and records concerning the warranty problem, and allow MELCO to examine and test the Products in question offsite or at the premises where they are installed or used; and
 - (3) If MELCO requests, Customer shall remove Products it claims are defective and ship them to MELCO or MELCO's authorized representative for examination and, if found defective, for repair or replacement. The costs of removal, shipment to and from MELCO's designated examination point, and reinstallation of repaired or replaced Products shall be at Customer's expense.
 - (4) If Customer requests and MELCO agrees to effect repairs onsite at any domestic or overseas location, the Customer will pay for the costs of sending repair personnel and shipping parts. MELCO is not responsible for any re-commissioning, maintenance, or testing on-site that involves repairs or replacing of the Products.
- d. Repairs of Products located outside of Japan are accepted by MELCO's local authorized service facility centers ("FA Centers"). Terms and conditions on which each FA Center offers repair services for Products that are out of warranty or not covered by MELCO's limited warranty may vary.
- e. Subject to availability of spare parts, MELCO will offer Product repair services for (7) years after each Product model or line is discontinued, at MELCO's or its FA Centers' rates and charges and standard terms in effect at the time of repair. MELCO usually produces and retains sufficient spare parts for repairs of its Products for a period of seven (7) years after production is discontinued.
- f. MELCO generally announces discontinuation of Products through MELCO's Technical Bulletins. Products discontinued and repair parts for them may not be available after their production is discontinued.

2. Limits of Warranties.

- a. MELCO does not warrant or guarantee the design, specify, manufacture, construction or installation of the materials, construction criteria, functionality, use, properties or other characteristics of the equipment, systems, or production lines into which the Products may be incorporated, including any safety, fail-safe and shut down systems using the Products.
- b. MELCO is not responsible for determining the suitability of the Products for their intended purpose and use, including determining if the Products provide appropriate safety margins and redundancies for the applications, equipment or systems into which they are incorporated.
- c. Customer acknowledges that qualified and experienced personnel are required to determine the suitability, application, design, construction and proper installation and integration of the Products. MELCO does not supply such personnel.
- d. MELCO is not responsible for designing and conducting tests to determine that the Product functions appropriately and meets application standards and requirements as installed or incorporated into the end-user's equipment, production lines or systems.
- e. MELCO does not warrant any Product:
 - (1) repaired or altered by persons other than MELCO or its authorized engineers or FA Centers;
 - (2) subjected to negligence, carelessness, accident, misuse, or damage;
 - (3) improperly stored, handled, installed or maintained;
 - (4) integrated or used in connection with improperly designed, incompatible or defective hardware or software;
 - (5) that fails because consumable parts such as batteries, backlights, or fuses were not tested, serviced or replaced;
 - (6) operated or used with equipment, production lines or systems that do not meet applicable and commensurate legal, safety and industry-accepted standards;
 - (7) operated or used in abnormal applications;
 - (8) installed, operated or used in contravention of instructions, precautions or warnings contained in MELCO's user, instruction and/or safety manuals, technical bulletins and guidelines for the Products;
 - (9) used with obsolete technologies or technologies not fully tested and widely accepted and in use at the time of the Product's manufacture;
 - (10) subjected to excessive heat or moisture, abnormal voltages, shock, excessive vibration, physical damage or other improper environment; or
 - (11) damaged or malfunctioning due to Acts of God, fires, acts of vandals, criminals or terrorists, communication or power failures, or any other cause or failure that results from circumstances beyond MELCO's control.

- f. All Product information and specifications contained on MELCO's website and in catalogs, manuals, or technical information materials provided by MELCO are subject to change without prior notice.
- g. The Product information and statements contained on MELCO's website and in catalogs, manuals, technical bulletins or other materials provided by MELCO are provided as a guide for Customer's use. They do not constitute warranties and are not incorporated in the contract of sale for the Products.
- h. These terms and conditions constitute the entire agreement between Customer and MELCO with respect to warranties, remedies and damages and supersede any other understandings, whether written or oral, between the parties. Customer expressly acknowledges that any representations or statements made by MELCO or others concerning the Products outside these terms are not part of the basis of the bargain between the parties and are not factored into the pricing of the Products.
- i. THE WARRANTIES AND REMEDIES SET FORTH IN THESE TERMS ARE THE EXCLUSIVE AND ONLY WARRANTIES AND REMEDIES THAT APPLY TO THE PRODUCTS.
- j. MELCO DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

3. Limits on Damages.

- a. MELCO'S MAXIMUM CUMULATIVE LIABILITY BASED ON ANY CLAIMS FOR BREACH OF WARRANTY OR CONTRACT, NEGLIGENCE, STRICT TORT LIABILITY OR OTHER THEORIES OF RECOVERY REGARDING THE SALE, REPAIR, REPLACEMENT, DELIVERY, PERFORMANCE, CONDITION, SUITABILITY, COMPLIANCE, OR OTHER ASPECTS OF THE PRODUCTS OR THEIR SALE, INSTALLATION OR USE SHALL BE LIMITED TO THE PRICE PAID FOR PRODUCTS NOT AS WARRANTED.
- b. Although MELCO has obtained the certification for Product's compliance to the international safety standards IEC61508, EN954-1/ISO13849-1 from TUV Rheinland, this fact does not guarantee that Product will be free from any malfunction or failure. The user of this Product shall comply with any and all applicable safety standard, regulation or law and take appropriate safety measures for the system in which the Product is installed or used and shall take the second or third safety measures other than the Product. MELCO is not liable for damages that could have been prevented by compliance with any applicable safety standard, regulation or law.
- c. MELCO prohibits the use of Products with or in any application involving power plants, trains, railway systems, airplanes, airline operations, other transportation systems, amusement equipments, hospitals, medical care, dialysis and life support facilities or equipment, incineration and fuel devices, handling of nuclear or hazardous materials or chemicals, mining and drilling, and other applications where the level of risk to human life, health or property are elevated.
- d. MELCO SHALL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, INDIRECT OR PUNITIVE DAMAGES, FOR LOSS OF PROFITS, SALES, OR REVENUE, FOR INCREASED LABOR OR OVERHEAD COSTS, FOR DOWNTIME OR LOSS OF PRODUCTION, FOR COST OVERRUNS, OR FOR ENVIRONMENTAL OR POLLUTION DAMAGES OR CLEAN-UP COSTS, WHETHER THE LOSS IS BASED ON CLAIMS FOR BREACH OF CONTRACT OR WARRANTY, VIOLATION OF STATUTE, NEGLIGENCE OR OTHER TORT, STRICT LIABILITY OR OTHERWISE.
- e. In the event that any damages which are asserted against MELCO arising out of or relating to the Products or defects in them, consist of personal injury, wrongful death and/or physical property damages as well as damages of a pecuniary nature, the disclaimers and limitations contained in these terms shall apply to all three types of damages to the fullest extent permitted by law. If, however, the personal injury, wrongful death and/or physical property damages cannot be disclaimed or limited by law or public policy to the extent provided by these terms, then in any such event the disclaimer of and limitations on pecuniary or economic consequential and incidental damages shall nevertheless be enforceable to the fullest extent allowed by law.
- f. In no event shall any cause of action arising out of breach of warranty or otherwise concerning the Products be brought by Customer more than one year after the cause of action accrues.
- g. Each of the limitations on remedies and damages set forth in these terms is separate and independently enforceable, notwithstanding the unenforceability or failure of essential purpose of any warranty, undertaking, damage limitation, other provision of these terms or other terms comprising the contract of sale between Customer and MELCO.

4. Delivery/Force Majeure.

- a. Any delivery date for the Products acknowledged by MELCO is an estimated and not a promised date. MELCO will make all reasonable efforts to meet the delivery schedule set forth in Customer's order or the purchase contract but shall not be liable for failure to do so.
- b. Products stored at the request of Customer or because Customer refuses or delays shipment shall be at the risk and expense of Customer.
- c. MELCO shall not be liable for any damage to or loss of the Products or any delay in or failure to deliver, service, repair or replace the Products arising from shortage of raw materials, failure of suppliers to make timely delivery, labor difficulties of any kind, earthquake, fire, windstorm, flood, theft, criminal or terrorist acts, war, embargoes, governmental acts or rulings, loss or damage or delays in carriage, acts of God, vandals or any other circumstances reasonably beyond MELCO's control.

5. Choice of Law/Jurisdiction.

These terms and any agreement or contract between Customer and MELCO shall be governed by the laws of the State of New York without regard to conflicts of laws. To the extent any action or dispute is not arbitrated, the parties consent to the exclusive jurisdiction and venue of the federal and state courts located in the Southern District of the State of New York. Any judgment there obtained may be enforced in any court of competent jurisdiction.

6. Arbitration.

Any controversy or claim arising out of, or relating to or in connection with the Products, their sale or use or these terms, shall be settled by arbitration conducted in accordance with the Center for Public Resources (CPR) Rules for Non-Administered Arbitration of International Disputes, by a sole arbitrator chosen from the CPR's panels of distinguished neutrals. Judgment upon the award rendered by the Arbitrator shall be final and binding and may be entered by any court having jurisdiction thereof. The place of the arbitration shall be New York City, New York. The language of the arbitration shall be English. The neutral organization designated to perform the functions specified in Rule 6 and Rules 7.7(b), 7.8 and 7.9 shall be the CPR.

QSCPU

User's Manual

(Function Explanation, Program Fundamentals)

MODEL	QSCPU-U-KP-E
MODEL CODE	13JR93
SH(NA)-080627ENG-B(0706)MEE	



HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.